




APB ProRack-House
Chassis Rear-cover View
w/Power Supply

Remove 3 screws from top flange: 5/64 Allen-head
(hidden from view)



Remove 3 screws from bottom flange: 5/64 Allen-head

APB ProRack-House
Power Supply Removal



Power Supply
DC Cable & connector

Power Supply/Chassis
grounding fingers

Console DC-Input
Connector

APB ProRack-House
Power Supply Removal


Power Supply
DC Cable & connector


There is a locking-ramp on the back-side
of the plug that polarizes and friction-
locks with the mating connector.

Console DC-Input
Connector

Console DC-Input Connector
Use caution when reattaching this connection.
Make sure that the pins are lined-up properly and
not offset from the plug.

APB ProRack-House
Power Supply Removal





Chassis rear cover
(single piece)


To remove rear cover:
Remove 4 screws
Philips-head

Console DC-Input
Connector

Power Supply/Chassis
grounding fingers

To remove rear cover:
Remove 4 screws (each side)
Philips-head

APB ProRack-House
Removing Chassis rear-cover



Input ribbons (8):
To rear connector
chassis

Power Distribution
and filter PCB

(12) Mono
Preamp/EQ
plug-in modules

(4) Stereo
Preamp/EQ
plug-in modules

Master ribbons (3):
To rear connector
chassis

Master Sub-board &
Display PCBs

DC Connector
(to Power supply)

Module Support
brackets

(4) Stereo Input
Fader plug-in modules

Audio Bus ribbon

(12) Mono Input
Fader plug-in modules

DC power harness &
connector
(1 of 5)

Master Main PCB
w/Stereo Chan 13-16

Input Main PCB
Channels 1-12

APB ProRack-House
Main Chassis innards