Firmware upgrade

Model: iKeyboard 3, iKeyboard 4, iKeyboard 5 & iKeyboard 6
Release date: 6th July, 2016
Version: V2.12
Who need to upgrade: All users with the serial number as below:

iKeyboard 3
2013C3433 - 2013C33631
1CJ1436 - 1CJ1585
1CK1318 - 1CK1347
1DK5534 - 1DK5733
1EG00001 - 1EG00200

iKeyboard 4
2013C3728 - 2013C3926
1CJ1240 - 1CJ1433
1CJ0935 - 1CJ0940
1DI1063 - 1DI1162
1DI2753 - 1DI2852
1EG00201 - 1EG00500

iKeyboard 5
2013D0462 - 2013D0659
2013D2431
1CJ0935 - 1CJ0940
1CK1348 - 1CK1547
1DI0963 - 1DI1062
1DI2653 - 1DI2752
1EB0001 - 1EB0200
1EG00501 - 1EG00800
1EI04556 - 1EI05155

iKeyboard 6
2013D0660 - 2013D0857
1CI1898 - 1CI2097
1CK1218 - 1CK1317
1DL0501 - 1DL0700
1EB0201 - 1EB0400
1EG00801 - 1EG01098
1EI05256 - 1EI05755

Upgrade fix or added features:

Fixed the encoder knob midi message from 0-127
(Please note this is not referring to the jog wheel which need to activate with the " Jog Wheel" button)

Update footprint

Version	*Release date*	*Feature added or bug fix*
V2.03	15th Feb., 2015	Improved sustain function
V2.07	8th Sep., 2015	Cancel function of "Modulation" return to "zero" when released
V2.08	26th Nov., 2015	Supporting iOS9 or above
V2.09	22nd Mar., 2016	Reverse button function for button "Octave" and "Transpose"
V2.10	27th Apr.,2016	Added the function of changing the midi channel with the button for live performance.
	Activate:	Press button "Program", it lights, then rotate the jog wheel to change program Press button "Program" once more, it will keep flashing, then rotate the jog wheel to change the MIDI channel of the keyswitch Added the function to change the centre "C" position
	Activate:	While press and hold button "Trans", press a keyswitch to change the "C" position to that pressed keyswitch
V2.11	7th June,2016	"Octave" or "Trans" Up/Down buttons will light if it is not centre. Added feature: Pitch return to "Centre" when released, Modulation return to "0" when released

Remark: