# DTC-59ES

# SERVICE MANUAL

*US Model*
*Canadian Model*
*AEP Model*
*E Model*





**Photo : Black type**

## SPECIFICATIONS

| | |
|---|---|
| Tape | Digital audio tape |
| Recording head | Rotary head |
| Recording time | Standard: 120 minutes.<br>Long-play mode: 240 minutes (with DT-120) |
| Tape speed | Standard: 8.15 mm/s,<br>Long play mode: 4.075 mm/s |
| Drum rotation | Standard: 2,000 rpm,<br>Long-play mode: 1,000 rpm |
| Error correction | Double Read Solomon code |
| **Tape** | |
| Track pitch | 13.6 µm (20.4 µm) |
| Sampling frequency | 48 kHz, 44.1 kHz, 32 kHz |
| Modulation system | 8–10 Modulation |
| Transfer rate | 2.46 Mbit/sec. |
| Number of channel | 2 channels, stereo |
| D/A conversion (Quantization) | Standard: 16-bit linear<br>Long-play mode: 12-bit non-linear |
| Frequency response | Standard: 2–22,000 Hz (±0.5 dB)<br>Long-play mode: 2–14,500 Hz (±0.5 dB) |
| Signal to noise ratio | Standard: more than 92 dB<br>Long-play mode: more than 92 dB |
| Dynamic range | Standard: more than 92 dB<br>Long-play mode: more than 92 dB |
| Total harmonic distortion | Standard: less than 0.0045% (1 kHz)<br>Long-play mode: less than 0.08% (1 kHz) |
| Wow and flutter | Below measurable limit (±0.001% W. PEAK) |

| | |
|---|---|
| Model Name Using Similar Mechanism | NEW |
| Tape Transport Mechanism Type | DATM-102 |

**Input**

| | Jack type | Impedance | Rated input level |
|---|---|---|---|
| **LINE IN** | phono jack | 47 kohms | –4 dBs |
| **DIGITAL IN** | phono jack | 75 ohms | 0.5 Vp-p, ±20% |
| **DIGITAL IN** | optical jack | — | — |

**Output**

| | Jack type | Impedance | Rated output | Load impedance |
|---|---|---|---|---|
| **LINE OUT** | phono jack | 470 ohms | –4 dBs | More than 10 kohms |
| **PHONES** | stereo phone jack | 220 ohms | 0.6 mW | 32 ohms |
| **DIGITAL OUT** | phono jack | 75 ohms | 0.5 Vp-p ±20% | — |

DIGITAL OUT (optical jack): wavelength 660 nm

– continued on next page –

MICROFILM

## DIGITAL AUDIO TAPE DECK

SONY®

**General**

| | |
|---|---|
| Power requirements | 120V AC, 60Hz : US, Canadian model<br>220-230V AC, 50/60Hz : AEP model<br>110-120, 220-240V AC, 50/60Hz : E model |
| Power consumption | 32 W |
| Dimensions | Approx. 470 x 110 x 350 mm (w/h/d)<br>(18 5/8 x 4 3/8 x 13 7/8 inches) |
| Weight | Approx. 6.6 kg (14 lb 10 oz) |

**Remote commander (supplied)**

| | |
|---|---|
| Remote control system | Infrared control |
| Power requirements | 3V DC, with two size AA (R6) batteries |
| Dimensions | Approx. 63 x 19 x 175 mm (w/h/d)<br>(2 1/2 x 3/4 x 7 inches) |
| Weight | Approx. 130 g (4 oz) incl. batteries. |

**Supplied accessories**

Sony batteries SUM-3(NS) (2)
Audio connecting cords (2 phono plugs - 2 phono plugs, stereo for line inputs and outputs) (2)
Screws (4)

Design and specifications are subject to change without notice.

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY MARK ⚠ OR DOTTED LINE WITH MARK ⚠ ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFIÉS PAR UNE MARQUE ⚠ SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER SES COMPOSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPLÉMENTS PUBLIÉS PAR SONY.

## TABLE OF CONTENTS



| Section | Title | Page |
|---|---|---|
| **1.** | **GENERAL** | |
| | Features | 4 |
| | Location and Function of Controls | 5 |
| | Clock Setting | 9 |
| **2.** | **DISASSEMBLY** | **10** |
| **3.** | **ADJUSTMENTS** | |
| 3-1. | Electrical Adjustments | 15 |
| 3-2. | Checks for Date Function | 17 |
| **4.** | **DIAGRAMS** | |
| 4-1. | Circuit Boards Location | 18 |
| 4-2. | Block Diagram | 19 |
| 4-3. | Waveforms | 22 |
| 4-4. | Semiconductor Lead Layouts | 25 |
| 4-5. | Schematic Diagram - MD / Power Supply / Display Section - | 27 |
| 4-6. | Printed Wiring Boards - MD / Power Supply / Display Section - | 31 |
| 4-7. | Printed Wiring Boards - Main Section - | 35 |
| 4-8. | Schematic Diagram - Main Section - | 39 |
| 4-9. | IC Block Diagrams | 43 |
| 4-10. | Pin Functions | 46 |
| **5.** | **EXPLODED VIEWS** | |
| 5-1. | Cabinet Section | 55 |
| 5-2. | Front Panel Section | 56 |
| 5-3. | Chassis Section | 57 |
| 5-4. | Mechanism Section 1 | 58 |
| 5-5. | Mechanism Section 2 | 59 |
| 5-6. | Mechanism Section 3 | 60 |
| 5-7. | Mechanism Section 4 | 61 |
| **6.** | **ELECTRICAL PARTS LIST** | **62** |


**PRECAUTIONS FOR INSPECTIONS AND REPAIR WITH POWER OFF**

Before beginning repair work after turning OFF the main switch, be sure to first remove CN932 (EH8P) of the power board. When assembling the equipment, be sure to plug this connector last.
This is because, even with the main switch turned OFF, electric charges still remain in the smoothing capacitor in the power board. Therefore, if another flexible board is inserted or removed, a terminal of the power supply may short an adjacent terminal while destroying the device.

## MODEL IDENTIFICATION

**– SPECIFICATION LABEL –**




US,Canadian model : AC 120V 60Hz 32W
AEP model : AC 220-230V~ 50/60Hz 32W
E model : AC:110-120, 220-240V~ 50/60Hz 32W

CAUTION
Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the equipment manufacturer. Discard used batteries according to manufacturer's instructions.

ADVERSEL !
Lithiumbatteri – Eksplosionsfare ved fejlagtig håndtering.
Udskiftning må kun ske med batteri
af samme fabrikat og type.
Lever det brugte batteri tilbage til leverandcren.

ADVARSEL
Lithiumbatteri – Eksplosjonsfare.
Ved utskifting benyttes kun batteri som anbefalt av apparatfabrikanten.
Brukt batteri returneres apparatleveranderen.

VARNING
Explosionsfara vid felaktigt batteribyte.
Använd samma batterityp eller en likvärdig typ som rekommenderas av apparattillverkaren.
Kassera använt batteri enligt gällande föreskrifter.

VAROITUS
Paristo voi räjähtää, jos se on virheellisesti asennettu.
Vaihda paristo ainoastaan laitevalmistajan suosittelemaan tyyppiin. Hävitä käytetty paristo valmistajan ohjeiden mukaisesti.

## SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety check before releasing the set to the customer: Check the antenna terminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.

### LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5mA (500 microampers). Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2V AC range are suitable. (See Fig.A)





Fig. A. Using an AC voltmeter to check AC leakage.

# SECTION 1
# GENERAL

This section is extracted from instruction manual.

## Features

**Serial copy management system**
This unit utilizes the serial copy management system that permits digital-to-digital recording for one generation. You can record CD sound or other digital formats through a digital-to-digital connection. (See page 42.)

**Date Function automatically memories the recording date and time**
The year, month, day, day of the week, hour, minute and second are automatically memorized in the subcode area during recording, so that during playback you can display this data to check when the tape was recorded. This function is especially convenient when recording live performances, etc.

**Three sampling frequencies**
Recording/playback can be done with three sampling frequencies (48 kHz, 44.1 kHz and 32 kHz).
48 kHz: For analog and digital input signals in a standard mode.
44.1 kHz: For compact disc and pre-recorded DAT tape.
32 kHz: For analog input signals in a long-play mode.

**Long play mode**
This unit can operate in a long-play mode. Analog input signals can be recorded or playback for up to four consecutive hours when the DT-120 DAT cassette tape is used. The sampling frequency will be 32 kHz in the long-play mode.

**Visible cassette loading**
You can view the tape operation through the lid of the cassette compartment. Due to a revolutionary new transport mechanism, cassette loading time has been significantly reduced.

**Excellent sound quality**
**1-bit A/D converter**
For the A/D converter section which converts analog input signals to digital signals, the unit employs a 1-bit A/D converter which theoretically generates no zero-cross distortion for a clear, elegant sound quality.
**Pulse D/A converter**
Superior playback performance is achieved with a 1-bit D/A converter.


**Rich variety of subcode information**
This unit can record subcode information such as Start IDs, program numbers, Skip IDs, and absolute time data, enabling you to quickly locate tunes and display the playback time in the same manner as when playing compact discs.


**Digital fade-in/fade-out**
Professional sounding fade-in/fade-out of either digital or analog signals can be accomplished by use of the FADER button.

**Post edit recording of sub codes**
You can record or rewrite the following sub codes after the audio signal recording has been completed.
Start ID: Signifies the beginning of a selection.
Program number: Gives a number to the selection.
Skip ID: Signifies the beginning of a portion to be skipped.
End ID: Signifies the end position of recording/playback.
Since sub codes are written on the tape separately from audio signals, the audio signals are not affected.

# Location and Function of Controls

## Front Panel/Remote Commander



[1] **POWER switch**
Turns the power on and off.

[2] **Cassette compartment**
Insert a cassette with the window side up and the safety tab facing you.

[3] **Display window**

[4] **Remote sensor**
Receives the signal from the remote commander.

[5] **MODE button**
Selects the display mode among the absolute time, elapsed time of the current selection, remaining time to the end of whole tape and linear counter (tape running time). Each time you press the button, the display changes sequentially.

[6] **INPUT SELECT selector**
Set according to the signal to be recorded.
**ANALOG:** For recording from the equipment connected to the LINE IN jacks.
**OPTICAL:** For recording from the equipment connected to the DIGITAL IN (OPTICAL) jack.
**COAXIAL:** For recording from the equipment connected to the DIGITAL IN (COAXIAL) jack.

[7] **REC LEVEL (recording level) controls**
Adjust the recording levels and balance for the analog input signals.
The outer knob controls the L (left) channel level and the inner knob the R (right) channel level. The knobs can be adjusted together. To adjust each channel independently, turn the knob while holding the other knob.
When recording digital signals, it is not necessary to adjust the recording levels.

[8] **REC MODE selector**
Normally set to the STANDARD position.
When this selector is set to the LONG position, you can record analog input signals or digital signals with 32 kHz in the long-play mode.

[9] **TIMER switch**
Normally set to the OFF position. When recording or playing back at the desired time using a commercially available audio timer, set to the REC position or the PLAY position respectively.

[10] **PHONES-LEVEL jack and control**
Insert the headphones plug to this jack and turn the control to adjust the headphones volume level.

[11] **Numeric buttons (0–9)**
Designate the desired program number to be played back before starting playback. Designate the desired number in the record-pause mode, the program number is written consecutively from the designated number.

[12] **MUSIC SCAN button**
Press to listen to the beginning of each selection successively.

[13] **FADER button**
Press to fade in or fade out during recording or playback.

[14] **MARGIN RESET button**
Press to reset the margin of peak level.

[15] **CLEAR button**
Press to cancel the program number which has been mistakenly entered.

[16] **RECORDED button**
Press to display the recording day of the tape being played.

[17] **PRESENT button** Press to display the current time.
Each time the RECORDED or PRESENT button is pressed, day, month and year display, the day of the week display or hour, minute and second display is switched sequencially.


[18] **CLOCK SET button**
Press to adjust the time of the clock built in this unit. In this mode, the 0 button and the 9 button function as the + and – buttons respectively.

[19] **START ID buttons**
**AUTO:** Press to turn on and off the AUTO indicator. When the AUTO indicator is lit, the start ID will automatically be written during recording. When the AUTO indicator is not lit, press the START ID WRITE button at the point where you want to write a start ID.
**WRITE:** Press to write the start ID at the desired point during recording or playback.
**ERASE:** Press to erase a start ID. When a start ID and a program number are written on the tape, both codes are simultaneously erased by pressing this button.
**RENUMBER:** Press to renumber all programs on the tape. When only the start IDs are written, pressing this button will insert the proper program numbers beginning with "1". The tape will rewind and start from the beginning to accomplish this function.

[20] **SKIP ID buttons**
**WRITE:** Press at the beginning of the portion you may wish to skip later. A skip ID will be written from the point where you pressed this button.
**ERASE:** Press to erase the nearest skip ID which is before the current position.

[21] **END ID buttons**
**WRITE:** Press to write the ID signifying the end of playback or recording.
**ERASE:** Press to erase the end ID.

## Front Panel/Remote Commander




22 **▲OPEN/CLOSE button**
Press to open or close the cassette compartment.

23 **Tape operating buttons**
■ **(stop):** Press to stop recording or playback.
► **(play):** Press to play back the tape.
**IIPAUSE (pause):** Press to stop for a moment during recording or playback. To restart recording or playback, press this button again or press the ► button.
If the unit is left in the pause mode for about 10 minutes, it will automatically be released and the deck will enter the stop mode. To restart recording or playback from the stop mode, press the ●REC or ► button respectively.
**OREC MUTE (record muting):** Inserts a sound-muted portion (space).
**●REC (recording):** Press to enter the record-pause mode. After pressing this button, press the IIpause or ► button.
**I◄◄/►►I (AMS):** Press to locate the beginning of the selection during the playback.
**◄◄/►► (rewind/review, fast-forward/cue):** In the stop mode, press to rewind/fast-forward the tape. During playback, press to rewind or fast-forward the tape while listening to the sound.

24 **DISPLAY MODE button**
Changes the display mode. (Refer to page 10.)

25 **RESET**
Resets the linear counter to "0M 00S".

26 **RMS play buttons**
**ENTER:** To program the selections in a desired order, press this button after pressing the numeric buttons.
**CHECK:** Press to check the programmed contents.

27 **REPEAT 1/ALL button**
Press to play a desired portion repeatedly. Each time you press the button, the indicatior changes as follows:
REPEAT 1 → REPEAT ALL → off

28 **SKIP PLAY button**
Press to activate the skip ID code function. The portion of the tape previously marked will be skipped.

29 **CD operation buttons**
Operative only for the Sony CD player equipped with a Remote Commander.
**II (pause):** Press this button twice to start playback. Press this button once in the playback mode, the deck enters the pause mode.
**I◄◄/►►I (AMS):** Press to locate the desired selection on the Compact Disc during playback or in the stop mode.

30 **CD SYNCHRO (CD synchronized recording) buttons**
(The playback of the Sony CD player equipped with a Remote Commander and the recording of the DAT deck can be performed simultaneously.)
**STANDBY:** Press to set the unit in the record-standby mode.
**START:** Press to start recording of the DAT deck and then playback of the CD player.
**STOP:** Press to stop the DAT deck recording and the CD player playback.



## Remote Commander Operation


Each button on the remote commander functions in the same way as those having the same name on the front panel.
However, the following operations cannot be performed using the remote commander. Use the front panel controls instead.

- Turing the power on and off
- Selecting digital(optical/coaxial)/analog input source
- Setting the clock
- Adjusting the recording level and balance
- Adjusting the headphones level
- Setting the timer recording/playback
- Selecting the record mode (standard or long)

The following operations can be performed only with the remote commander.

- To activate CD synchronized recording using a Sony CD player and controlling the CD player
- To locate the desired selection on the Compact Disc or to set the CD player in the pause mode (possible only when a Sony CD player is used.)
- Repeat play
- Skip play
- RMS* play
  *RMS: Random Music Sensor
- To reset the linear counter to "0 M 00S"

## Installing Batteries




Insert two size AA (R6) batteries with correct polarity, and close the lid.

**Notes on remote control**
- Do not expose the remote sensor on the deck to strong light such as direct sunlight, lighting apparatus, etc.
- Do not place any obstructions between the Remote Commander and the remote sensor, or else operations will not be performed correctly.
- The controllable range is limited. Point the Remote Commander directly at the remote sensor on the deck.
- When remote control operation distance becomes shorter, the batteries are weak. Replace both batteries with new ones.

**To avoid battery leakage**
When the commander will not be used for a long period of time, remove the batteries to avoid damage caused by battery leakage and corrosion.

**Battery life**
About half a year of normal operation can be expected when using the Sony SUM-3 (NS) batteries.

## Display Window




**To turn off the display window**
When the power is turned on, the display window also is turned on. During recording or playback, all display or some parts of the display can be turned off as follows:
**When operating with the front panel controls**
While pressing the MODE button, press the 0 button.
**When operating with the remote commander**
Press the DISPLAY MODE button.
Each time you press the above buttons, the indicators change as follows:

Normal indicators ◄
↓
Peak level meters and margin indicators go off.
(The DISPLAY OFF indicator lights.)
↓
All the indicators go off during recording or playback*.
(The DISPLAY OFF AUTO indicator lights momentarily just before the indicators go off.)

* When pressing the MODE or DISPLAY MODE button except during recording or playback, the DISPLAY OFF AUTO indicator lights. In this case, all the indicators go off immediately after recording or playback starts.

**To change the brightness of the display window**
While pressing the MODE button on the front panel or the COUNTER MODE button on the remote commander, press one of the numeric buttons 1, 2 and 3. The greater number pressed, the darker the display window becomes.

**1 LONG play mode indicator**
Lights when recording or playback is being performed in the long play mode.

**2 TOC (Table Of Contents) indicator**
When a pre-recorded DAT cassette is played back, this indicator will light.

**3 DATE indicator**
Lights when the RECORDED button is pressed to display the recording day of the tape being played. Flashes when the PRESENT button is pressed to display the current time.

**4 REMAINING (remaining time):** Lights when the counter shows the remaining time of the tape.
**PGM TIME (program time):** Lights when the counter shows the elapsed time of the current selection.
**ABS TIME (absolute time) indicator:** Lights when the counter shows the elapsed time from the beginning of the tape.

**5 Time indicator**
Indicates the tape running time, absolute time, elapsed time of the current selection, remaining time or recording day. Each time the MODE button is pressed, the display is changed.

**6 Fade in/out indicator**
[FADE]: Flashes when recording or playback fades in.
[FADE]: Flashes when recording of playback fades out.

**7 AM/PM indicators**
Show AM or PM of the time.

**8 INPUT selector indicators**
The DIGITAL IN OPTICAL or COAXIAL indicator lights according to the position of the INPUT selector. No indicator lights when the INPUT selector is set to the ANALOG position.

**9 SAMPLING FREQ. (Sampling frequency) indicator**
**48 kHz:** For recording/playback of analog input signals (standard mode).
**44.1 kHz:** For recording/playback of CD or a pre-recorded DAT cassette.
**32 kHz:** For recording/playback of analog input signals (long-play mode).

**10 REPEAT indicators**
**REPEAT 1:** Lights when a desired selection is played back repeatedly.
**REPEAT ALL:** Lights when all the selections are played back repeatedly.

**11 AMS (Automatic Music Sensor)/RMS (Random Music Sensor) indicators**
Show the number of selections to be skipped ahead or behind in the AMS operation. When designating a selection directly by the numeric button and the ► button, the display shows the program number of the target selection while the selection is being searched for. When programming the desired selections in the RMS operation (page 39), the display shows the program number of the selection to be programmed.

**12 DISPLAY OFF/AUTO indicators**
The DISPLAY OFF indicator lights when peak level meters and margin indicators are turned off. The DISPLAY OFF AUTO indicator lights momentarily before all the indicators are turned off.

**13 SKIP PLAY indicator**
When this indicator is lit during playback, the portion marked by the skip ID is skipped and playback continues from the next start ID.

**14 MUSIC SCAN indicator**
Lights after the MUSIC SCAN button is pressed to listen to the beginning of each selection successively.


**15 CAUTION indicator**
Lights when moisture condensation occurs. If this happens, the deck stops functioning automatically. (See page 4.)

**16 START ID mode indicators**
**AUTO:** Lights when the AUTO button is pressed to write the start ID automatically.
**RENUMBER:** Lights when the RENUMBER button is pressed to renumber the program numbers.
**WRITE:** Lights when writing the start ID manually.
**ERASE:** Lights when erasing the start ID.
**AUTO RENUMBER:** Lights when renumbering program numbers automatically.
**SHIFT RENUMBER:** Lights when shifting the start ID and program number position.

**17 SKIP ID mode indicator**
**WRITE:** Lights when writing the skip ID.
**ERASE:** Lights when erasing the skip ID.

**18 END ID mode indicator**
**WRITE:** Lights when writing the end ID.
**ERASE:** Lights when erasing the end ID.

## Display Window




**19** **STEP/PGM NO. indicator**
Shows the program number of the selection being played. When programming the desired selection with the RMS operation (page 39), the display shows the step number of the programmed selection.

**20** **COPY PROHIBIT indicator**
Lights when recording the digital signal with the copy prohibit code. In this case, record with the LINE IN jacks.

**21** **START ID indicator**
Flashes when writing (for 9 or 18 seconds) or erasing a start ID code, and lights when the start ID is detected during playback.

**22** **SKIP ID indicator**
Lights when writing (for 1 or 2 seconds) or erasing a skip ID code or when the skip ID is detected during playback.

**23** **MARGIN indicator**
Shows how much margin there is between the peak level of input audio signal and 0 dB.


**24** **REHEARSAL indicator**
Lights while the rehearsal function is activated (page 29).

**25** **Peak level meters/Frequencies map**
Indicate the signal levels during playback and recording. There are separate meters for each left and right channel. These meters have a peak hold function which indicates the peak level momentarily.
When pressing the 4 button while keeping the MODE button pressed, the sampling frequencies with which the tape was recorded is displayed.

**26** **Tape operation indicators**
REC: Lights during recording or in the record-pause mode.
►: Lights during recording or playback. It also lights in the record-pause mode or in the play-pause mode.
II: Lights in the record-pause mode or in the play-pause mode.



## Rear Panel Jacks




**1** **LINE IN (line input) jacks (phono jack)**
Connect to the recording outputs of an amplifier. Signals supplied by the amplifier can be recorded using the sampling frequency of 48 kHz in the standard play mode or 32 kHz in the long play mode.

**2** **LINE OUT (line output) jacks (phono jack)**
Connect to the DAT or tape inputs of an amplifier. The playback signal of this deck will be output.

**3** **COAXIAL/OPTICAL DIGITAL IN (digital input) jacks (coaxial phono jack/optical jack)**
Connect to the digital outputs of an amplifier having a built-in D/A converter or other digital source, such as a CD player for digital-to-digital recording.

**4** **COAXIAL/OPTICAL DIGITAL OUT (digital output) jack (coaxial phono jack/optical jack)**
Connect to the digital inputs of an amplifier having a built-in D/A converter or another DAT deck, for playback of a DAT cassette or digital-to-digital recording.

**5** **CONTROL-S IN jack**
Connect to the CONTROL-S output of a Sony amplifier or receiver for remote control.

**Notes on connection**
- Use the connecting cords specified in the illustrations.
- Turn off the power for all equipments before making connections.
- Be sure to insert the plugs firmly into the jacks. Loose connections may cause hum and noise. When unplugging, grasp the plug and not the cord.

**Notes on the optical cable**
- Do not bend the cord. When the cord is not used, curl it with a diameter of more than 15 cm (5 $^{7}/_{8}$ inches).
- Do not use it under high temperatures.
- When the optical cable is not connected, cover the OPTICAL IN/OUT jacks with the supplied caps.

**Note on sound signals**
When connecting an optical cable to the DIGITAL IN/ DIGITAL OUT jacks, sound signals (L/R) are transmitted together through the cable.

**Note on the CONTROL-S IN jack**
To remote control this unit through a receiver or amplifier, connect the input of this unit to the CONTROL-S output of a Sony receiver or amplifier, with a CONTROL-S cable. When this connection is used, only remote control commands sent through the receiver or amplifier will be executed. The remote sensor of this unit will not function.

# Clock Setting

This unit employs a built-in clock to keep track of the current date and time. Once you set the date and time, this information will be recorded on the tape along with the audio signal during recording. This function is very convenient because it allows you to check when the tape was recorded when playing the tape later.

## Setting the date and time


**Example:** Setting the clock to 10:30:00 AM, July 4, 1993 (Sunday)

### Setting the day


**1** **Display the current date.**





**2** **Set the year.**




**3** **Set the month.**




**4** **Set the day.**




**5** **Complete the setting procedure.**





### Setting the day of the week

**1** **Display the day of the week.**




**2** **Set the day of the week.**




**3** **Complete the setting procedure.**







### Setting the time


**1** **Display the current time.**





**2** **Set the hour.**




**3** **Set the minutes.**




**4** **Set the seconds to 0.**




**5** **Start the clock simultaneously with the signal from a timecast (telephone, etc.).**




**To confirm the date or time**
Press the PRESENT button to display the date, the day of the week or time. When pressing the PRESENT button once, the date is displayed, when pressing twice, the day of the week is displayed and when pressing three times, the time is displayed. To return to the original counter display, press the MODE button.

**Time display**
The time is displayed in 12-hour format.
Midnight and noon are displayed as follows:
Midnight: 12:00 AM
Noon: 12:00 PM

**Built-in clock**
This unit's built-in clock operates using a quartz oscillator, and time variations caused by changes in temperature, etc., may accumulate. For precise recording of hour, minute, and second data by the built-in date function, it is recommended that you set the clock once a week.

**Precautions when setting the clock**
- Set the clock while the tape is stopped.
- Although this unit's clock automatically adjusts for leap years and long and short months, do not enter a date which does not exist.

**The day of the week is displayed as follows:**

| | |
|---|---|
| Sunday | SU |
| Monday | MO |
| Tuesday | TU |
| Wednesday | WE |
| Thursday | TH |
| Friday | FR |
| Saturday | SA |

**Note**
This unit uses a back-up battery to keep the clock running when the power is turned off. The life of the battery under normal use is approximately seven years. When the battery starts to run down, the clock will stop operating normally. When this occurs, have the battery replaced at your dealer or nearest Sony Service Center (a battery replacement fee is required).

# SECTION 2
# DISASSEMBLY

- **Remove the following devices shown by ❶, etc. In the order of the numbers.**


**[CASE]**

Unscrew the four case attachment screws and remove the case.


**[CASSETTE WINDOW]**

❶ Press the OPEN/CLOSE switch to effect LOADING OUT STATE (if power is not supplied) rotate the pulley in the left side of the Mechanism Deck counterclockwise.)
❷ Remove the cassette by lifting the window up.


## MECHANISM SECTION




## HOLDER




## CASSETTE COMPARTMENT MOTOR (M901), PULLEY, GEAR (CAM) AND SLIDER




Ⓐ


### DRUM

❶ Remove the drum lead wires from connectors.




## DRUM DRIVE BOARD, DRIVING CHASSIS

❶ Remove the lead wires from connectors on the drum drive board.




## CAPSTAN MOTOR (M902)



# SECTION 3
# ADJUSTMENTS


### Notes When Making Adjustments

1. Adjustments should be performed in the order listed.
2. Use the following test tapes :
   TY-7111 (8-909-812-00) ..... Level
   TY-7252 (8-909-822-00) ..... Tracking
   TY-7551 (8-909-814-00) ..... Functions
   TY-30B (8-892-358-00) ..... Blank


   Use the following torque meter:
   TW-7131 (8-909-708-71) ..... FWD

3. Switches and controls should be set as follows unless otherwise specified.
   TIMER switch : OFF
   REC MODE switch : LONG
   INPUT switch : COAXIAL
   REC LEVEL control : Min.
   LEVEL (PHONES) control : Min.

4. Creating an end sensor cassette
   (1) Press the tape slider lock and move the slider in the direction indicated by the arrow.




   (2) Open the lid and cut the tape.





   (3) Turn the hubs until the tape is completely inside the cassette (both T and S sides).
   The end sensor cassette for end sensor adjustment is now ready for use.

5. Cleaning of the Revolving Drum
   (1) Fold a chamois (2-034-697-00) or a knit cloth into 4 or more files, slightly impregnate it with a cleaning liquid (9-919-573-00), and softly touch the drum with it and manually rotate the drum slowly counterclockwise by 2 to 3 turns for cleaning.
   (2) At that time, be careful not to move the chamois vertically to the head tip. Otherwise, the head tip may probably be damaged.

6. Be careful not to move RV1 and RV2 on the RF AMP board in the mechanism assembly.

7. To adjust the tape path and guides, remove the holder assembly as shown in the diagram and use the DAT holder jig (J-8000-002-A). This will make it easier to perform adjustments.

   - First turning the pulley counterclockwise to put it in loading out status will make removal and reattachment of the holder assembly easier.
   - To perform adjustments, turn the pulley clockwise to put it in loading in status, load the cassette tape and set the IN switch to the ON position.




8. Test mode
   The test mode is effected by shorting TP (XTEST MAIN, XTEST SERVO and XTEST DISP) on the main board and the control switch board and GND.
   (1) Test mode (main · servo)
   Turn OFF the power switch, connect XTEST MAIN and XTEST SERVO on the main board to GND and perform the following adjustments.
   - Tape path fine adjustment
   - DPG adjustment
   - ATF pilot (GCA) checking
   - End sensor checking
   - FWD torque adjustment
   - FWD back tension checking and adjustment

   (2) Test mode (display)
   You can check the following FL display tube and the panel switch by turning OFF the power switch, disconnecting CN932 on the power board, removing flexible board CN752 on the control switch board, connecting XTEST DISP to GND, connecting CN932 again and then turning ON the power switch.

Each grid of the FL display tube sequentially lights up while all tubes being lighted up finally.

⇓

Level meters go out one after one.

⇓

Press any of the remote controller for DAT in this state. Thus, all level meters go out. (It may sometimes occur that one or two meters remain lighting up according to switch setting at that time.)

⇓


Everytime a switch on the panel is pressed, display tubes light up sequentially one after one. With all keys once pressed, all level meters go out.

- To reset the test mode, disconnect the wire shorting XTEST and GND. After completion of adjusting, be sure to reset the test mode.


9. Check the following items for correct tape speed, after completion of adjusting.
   (1) Set the REC MODE switch to STANDARD and check for normal recording and playback. (× 1)
   (2) Set the REC MODE switch to LONG and check for normal recording and playback. (× 0.5)
   (3) With QUE (▶ + ▶▶) or REVIEW (▶ + ◀◀), check that qurrr, qurrr sound is heard. (× 3, × 8)
   (4) Check that correct time is displayed after FF (▶▶) or REV (◀◀). (× 16)
   (5) Check that SEARCH (▷▷|, |◁◁) is normal.

**Adjust Parts Location**


— Mechanism assembly —




— Main board —
(Component side)




— Control SW board —
(Conductor side)




## 3-1. ELECTRICAL ADJUSTMENTS

### End Sensor Check

Perform the following adjustment when the holder has been removed or part of the mechanism deck section replaced.

**Check Procedure:**

1. Connect an oscilloscope to the test land SE (in the S side) and TE (in the T side) of the main board.
2. Actuate the test mode (main · servo), mount an end sensor cassette and effect the STOP (■) mode.
3. Check that p-p values of waveform of the oscilloscope satisfy the following.




### FWD Torque Adjustment

**Adjustment Procedure:**


1. Put the set into the test mode (main · servo) and load the FWD torque meter TW-7131 (8-909-708-71).
2. Put the set into the PLAY (▶) mode.
3. Adjust RV601 so that the FWD torque value (take-up side rewinding torque) is between 10 – 13 g·cm (0.14 – 0.18 oz·inch).
4. Confirm that the value indicated by the torque meter is maintained for one full cycle.

**Adjustment Point:** MAIN board

### FWD Back Tension Check and Adjustment

**Check procedure:**

1. Put the set into the test mode (main · servo) and load the FWD torque meter TW-7131 (8-909-708-71)
2. Put the set into the PLAY (▶) mode.
3. Confirm that the back tension (supply side) is between 5 – 6 g·cm (0.07 –0.09 oz·inch).
   If this is not satisfied, adjust back tension by rotating the FWD back tension adjustment screw equipped on the side surface of the mechanical deck. After completion of adjusting, be sure to apply screw lock.
4. Confirm that value indicated by the torque meter is maintained for one full cycle.





To tighten (clockwise) — back tension becomes larger.
To loosen (counterclockwise) — back tension becomes smaller.

### Tape Path Fine Adjustments (× 1.5 FWD Mode)


Perform the following adjustment when the drum has been replaced.

**Adjustment Procedure :**

1. Connect an oscilloscope CH-1 to TP (PBRF) and CH-2 to TP (SWP) on the main board.
2. Put the set into the test mode (main · servo) and load test tape TY-7252 (8-909-822-00).
3. Press the AMS (▷▷|) key.
   Each part of switches on Test Mode.





4. With the REC MODE switch set to STANDARD (ATF: OFF) and the TIMER switch set to PLAY or REC (OFFSET: + or –), fine adjust the S1 and T1 guides so that the oscilloscope RF signal waveform remains the same when high-low is repeated.



* Finish the adjustment by screwing in.


5. Check the RF signal waveform with the REC MODE switch set to LONG (ATF: ON) and the TIMER switch set to PLAY or REC (OFFSET: + or –).




6. Check the RF signal waveform with the REC MODE switch set to LONG (ATF: ON) and the TIMER switch set to PLAY or REC (OFFSET: 0).
   (1) Confirm theat the RF signal waveform peak value (B) is 60 mV or more.



   (2) Confirm that the undershoot level of the RF signal waveform's flat portion is within 10%.




7. When the measured values are not within the above toleranc repeat items 3 – 6 above.


**Adjustment Point**: mechanism assembly

### DPG Adjustment

Perform the following adjustment without fail when the drum has been replaced.

**Adjustment Procedure:**

1. Connect oscilloscope CH-1 to TP (PBRF) and CH-2 to TP (SWP) on the main board. (Use CH-2 as the trigger. When the CH-2 signal is inverted, the trailing edge can be used for synchronization.)
2. Put the set into the test mode (main · servo) and load test tape TY-7252 (8-909-822-00).
3. Set the REC MODE switch to LONG (ATF: ON) and the TIMER switch to OFF (OFFSET: 0).
4. Press the AMS (▷▷|) key.
5. Press the ◀◀ and ▶▶ keys as appropriate so that the gap between the oscilloscope SWP and RF signals becomes 650 ± 15 µsec. (Hold the ◀◀ and ▶▶ keys down for more than 1 second to perform rough adjustment. Hold them down for approximately 0.2 seconds for fine adjustment.)





### ATF Pilot (GCA) Check

Perform this adjustment after cleaning the heads with a cleaning cassette.

**Check Procedure:**

1. Connect oscilloscope CH-1 to TP (GCA: Gain Control Amp.) and CH-2 to TP (SWP) on the main board. (When the CH-2 signal is inverted, the trailing edge can be used for synchronization.)
2. Put the set into the test mode (main · servo) and load test tape TY-7111 (8-909-812-00).
3. Actuate the PLAY (▶) mode and check that the GCA waveform on the oscilloscope is as follows.




* Slightly changes depending on the state of the head. NG if the GCA waveform is 1V or more or equal to the GND level.

## 3-2. CHECKS FOR DATE FUNCTION

### Clock IC Back-up Check

- When there is the short-circuit position on the pattern around the lithium battery (BAT301) or the clock IC (IC330) or disconnecting CN398 on removing the front panel assembly the clock is reset. (In spite of pressing PRESENT button, the data indication becomes "– –$_{Y}$ – –$_{M}$ – –$_{D}$" "– –$_{H}$ – –$_{M}$ – –$_{S}$")
  At this time, check the back-up function by the procedures given below.

(1) Connect DC voltmeter to TP (BATT+) and TP (BATT –) on the main board.
(2) When the power is off, the voltage value of the item (1) should be less than +30 mV.
(When the voltage value becomes +30 mV or more, Check around IC330 or replace IC330.)
(3) When the power is on, the voltage value of the item (1) should be less than 0 mV (– (minus) indication).
(When the voltage value becomes + (plus) indication, Check around D321 or replace D321.)
(4) When the above voltage values are normal, set the preset date and time (year, month, day, day of the week, hour, minute, second) according to the instruction manual.
(5) After setting the time on the item (4), turn power off and turn power on several seconds later, and check the clock works normally.

### Back-up Battery Replacement

The life of the back-up battery under normal use (normal temperature, normal humidity) is approximately ten years or more. (On the instruction manual, described "approximately seven years".)
Be careful about the following points on the battery replacement.

- Repair the cause of the battery wastage by performing mentioned above "Clock IC Back-up Check".
- The open-circuit voltage of the replaced battery is 3.0 V or more as the new one, and when it is 2.0 V or less, it is completely consumed, replace it with new one.
- After the battery replacement, perform "Clock IC Back-up Check" again and set the time.

### Clock Frequency Adjustment

**Adjustment Procedure:**


1. Connect a frequency counter to pin ⑮ of IC330 and GND on the main board.
2. Turn power on and confirm that the reading on the frequency counter is 2048.00 ± 0.02 Hz. (in normal temperature)
3. Perform "Clock IC Back-up Check" described above.


* Time setting procedure described on page 9.




# SECTION 4
# DIAGRAMS


## 4-1. CIRCUIT BOARDS LOCATION




## 4-2. BLOCK DIAGRAM










## 4-3. WAVEFORMS




❶ FL701 ⑪-⑳pin (1G-20G)
32Vp-p, 2.5ms




❻ IC701 ㊺pin (SI), IC312 ㊳pin (DISP DT O)
5.2Vp-p, 0.64ms




⓫ IC1 ①pin, Q440 Base (PBDT)
PLAY mode 1Vp-p




⓰ IC307 ㊽pin, IC306 ㊾pin (DADO)
PLAY mode
5.2Vp-p, 5µs



❷ IC701 ⑲-㉘pin (10G-1G)
34Vp-p, 2.45ms




❼ IC702 ①pin (DATA)
6.4Vp-p, 0.3µs




⓬ IC01 ⑩pin, IC311 ㊼pin (CFG)
PLAY mode
5Vp-p, 1.5ms




⓱ IC307 ㊻pin, IC306 ㊼pin (ADDT)
REC mode
5.2Vp-p, 5µs




❸ IC701 ㉗-㉚pin, ①-⑱pin (a-v)
38Vp-p, 1.2ms




❽ IC702 ②pin (BCK)
5.2Vp-p, 0.3µs




⓭ IC01 ⑦pin, IC311 ㊾pin (DPG)
PLAY mode
5Vp-p, 10ms




⓲ IC307 ㊺pin (BCK)
5.2Vp-p, 0.1µs




❹ IC701 ㉚pin (XTAL)
5.5Vp-p, 2.5µs




❾ IC702 ③pin (LRCK)
5.7Vp-p, 20µs




⓮ IC01 ③pin, IC311 ㊽pin (DFG)
PLAY mode
5Vp-p, 1.25ms




⓳ IC307 ㊹pin, IC359 ⑮pin (XBCK), IC363 ⑧pin (BCKI)
5.4Vp-p, 0.1µs




❺ IC701 ㉛pin (EXTAL)
5Vp-p, 2.5µs




❿ IC1 ㉗ ㉝pin (HEAD)
REC mode 4.2Vp-p




⓯ IC03 ①, ⑦pin, IC311 ㊻, ㊺pin (FGS, FGT)
FF, REW mode 3.6Vp-p, 0.1ms




⓴ IC307 ㊷pin (LRCK)
5.6Vp-p, 5µs




㉑ IC307 ㊾pin, IC359 ⑭pin (LR03)
5.6Vp-p, 5µs




㉖ IC307 ㊹pin (TX)
PLAY mode
5.3Vp-p, 0.2s




㉛ IC307 ㊲pin, IC311 ㊷pin (RFDT)
PLAY mode
1Vp-p, 10ms




㊱ IC333 ②pin, IC363 ⑩pin (LRCKI)
5Vp-p, 5µs




㊶ IC601 ㊵pin, IC363 ⑰pin (512FS)
4.5Vp-p, 50ns




㊻ Q502 Source (VCO)
2.3Vp-p, 50ns




㊶ IC330 ⑯pin (XIN)
1.2Vp-p, 20µs




㉒ IC307 ㊼pin (XT3I)
0.9Vp-p, 50ns




㉗ IC307 ㊷pin (RX)
5.2Vp-p, 0.5ms




㉜ IC307 ㉑pin, IC311 ㊵pin (DREF)
5Vp-p, 5ms




㊲ IC306 ①pin, IC363 ⑨pin (DATAI)
5Vp-p, 5µs




㊷ IC601 ⑩pin (1024FS)
2.4Vp-p, 50ns




㊼ IC311 ㊹pin (D PWM)
PLAY mode
5Vp-p, 10µs




㊷ IC330 ⑮pin (XINTR)
5.2Vp-p, 0.1µs




㉓ IC307 ㊻pin (X3TO)
2.9Vp-p, 50ns




㉘ IC307 ㊽pin (PLCO)
4.8Vp-p, 0.18ms




㉝ IC307 ⑳pin, IC311 ㉟, ㊶pin, IC312 ㉟pin (MCLK)
5.8Vp-p, 50ns




㊳ IC363 ⑳, ㉑pin (DL, DR)
6Vp-p, 50ns




㊸ IC504 ⑦pin (LRCKI)
4Vp-p, 5µs




㊽ IC311 ㊺, ㊻pin (C PWM, PWMR)
PLAY mode
5Vp-p, 10µs




㉔ IC307 ㊾pin, IC359 ⑳pin (F256)
6.1Vp-p, 50ns




㉙ IC307 ㊸pin (REDT)
REC mode
4.4Vp-p, 0.5µs




㉞ IC307 ⑭pin, (XT1I)
5.6Vp-p, 50ns




㊴ IC363 ㉒pin, IC601 ㊳pin (LRCK)
5.3Vp-p, 0.5µs




㊹ IC504 ⑧pin (1/512FS)
4Vp-p, 5µs




㊾ IC311 ㊼, ㊽pin (TEN PWM, AGC PWM)
PLAY mode
5Vp-p, 10µs




㉕ IC307 ㊽pin (F128)
6Vp-p, 50ns




㉚ IC307 ㊴pin, IC311 ㊸pin (SWP)
PLAY mode
5.2Vp-p, 50ms




㉟ IC307 ⑬pin, (XT1O)
4Vp-p, 50ns



㊵ IC501 ⑩pin, IC601 ㊸pin (128FS)
3.4Vp-p, 50ns




㊺ Q501 Source (VCO)
1.2Vp-p, 50ns




㊿ IC330 ⑰pin (XOUT)
2Vp-p, 20µs

## 4-4. SEMICONDUCTOR LEAD LAYOUTS


**CS5339-KP**





**CX20115A**
**SN74HC4020ANS**





**CXA1364R**





**CXD1136Q**





**CXD2560M**





**CXD2562Q**





**CXD2601AQ**





**CXK1011P**





**CXK58257AM-12L**





**CXP5058H-659Q**
**CXP80524-062Q**
**CXP80524-063Q**





**LF412CN**
**M5238P**
**NE5532P**
**RC4558P**
**μPC358C**





**LM324N**
**SN74HC00ANS**
**SN74HC04ANS**
**SN74HC10ANS**
**SN74HC74ANS**





**LM358M**





**M5218AL**
**M54641L**





**MSM6338RS**





**M5F7808**
**TA7805S**
**TA7812S**
**μPC2406HF**





**PST572C**
**PST572E**





**RP5C62**




**SN74HC00AN**
**SN74HCU04AN**
**SN74HC86AN**
**SN74LS624N**
**μPD4011BC**




**TA79005S**
**TA79012S**





**TC5081AP**





**DTA114ES**
**DTC114ES**
**2SC2603-EF**





**2SA1175-HFE**
**2SC3623A-K**





**2SA1585S-QR**
**2SC4115S-QR**





**2SB734-34**
**2SB774-34**





**2SB798-DL**





**2SB1094-LK**
**2SD2012**





**2SC1623-L5L6**




**2SC2021-Q**





**2SD1387-3**





**2SK241-GR**





**GL-453S**





**GP2S09-C**





**HZS6A1L**
**HZS24-3L**
**RD4.7JS-B3**
**RD5.1JS-B2**
**1SS106**
**1SS168**
**1SS202-1**
**10E2N**
**11ES2**





**KV1310**




**RBA406B**




**PT4850F**




**LN01401C(Q)-3-LF**



• See page 22 for waveforms, 43 for IC block diagrams and 46 for pin functions.

【CONTROL SW BOARD】

FL701
FLUORESCENT INDICATOR TUBE (BG-933GK)

IC704
GP1U50XB
REMOTE SENSOR

IC701
CXP5058H-659Q
DISPLAY CONTROL

IC705
CIRCS/CONTROL-S SELECT

IC703
LC7051TP

IC702
MSM6338RS
DIGITAL PEAK LEVEL METER

Q701-703
2SC2021-Q
GRID DRIVE

R701-703
100K

CP701--100KX8
CP702--100KX8
CP703--100KX8
CP704
100KX8

US, Canadian MODEL

AEP, E MODEL

X701
4.19MHz

X TEST DISP

【MOTOR BOARD】

M901
CASSETTE COMPARTMENT MOTOR

【SW BOARD】

S1 CASSETTE TABLE IN

S2 CASSETTE TABLE OUT

【TOP END SENSOR BOARD】

PH03
PT4850F
TAKE-UP

D01
GL453

【RGN SW BOARD】

S01

Sol-1 CASSETTE IN

Sol-2 REC PROOF

【CAM SLIDER BOARD】

SW2 FWD DET

SW1 STOP DET

【CAM MOTOR BOARD】

M903
CAM MOTOR

【REEL M BOARD】

M905
REEL MOTOR

【RF AMP BOARD】

IC1
CXA1364R
RF AMP

【TIMER SW BOARD】

【INPUT SW BOARD】


【CONTROL (S) BOARD】

【BATTERY BOARD】

B4T 301
R2450 (3V)

FL701 FLUORESCENT INDICATOR TUBE

(See page 40)
(See page 41)
(See page 42)
(See page 39)




**Notes on schematic diagram:**

- All capacitors are in μF unless otherwise noted. pF: μμF 50WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in ohms, 1/4W or less unless otherwise noted.
- △ : Internal component
- ⏦: Fuse resistor

**The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.**
**Replace only with part number specified.**

**Les composants identifiés par une marque ⚠ sont critiques pour la sécurité.**
**Ne les remplacer que par une pièce portant le numéro spécifié.**

- ——— : B+ Line
- - - - - : B− Line
- Voltage are dc with no-signal (STOP) conditions.

No mark : Stop
( ) : PLAY
(( )) : REC
< > : FF
<< >> : REW
[ ] : MOMENTARILY WHEN ▶▶, ◀◀ and ▶ BUTTON IS PRESSED.
[[ ]] : MUTING

- Voltages are taken with a VOM (input impedance 10MΩ). Voltage variations may be noted due to normal production tolerances.
- Circled numbers refer to waveforms.
- Waveforms are taken with a oscilloscope. Voltage variations may be noted due to normal production tolerances.
- Signal path
  ≫ : PB
  ≫ : REC

• See page 18 for circuit boards lo

## ● SEMICONDUCTOR LOCATION

| Ref. No. | Location |
|---|---|
| D01 | F-22 |
| D801 | B-2 |
| D802 | A-2 |
| D905 | I-10 |
| D906 | I-8 |
| D907 | J-9 |
| D908 | J-9 |
| D909 | I-8 |
| D910 | J-10 |
| D911 | H-10 |
| D912 | H-11 |
| D913 | H-10 |
| D914 | H-11 |
| D915 | J-11 |
| D916 | I-11 |
| IC1 | F-14 |
| IC01 | G-18 |
| IC02 | G-19 |
| IC03 | H-20 |
| IC701 | D-8 |
| IC702 | E-10 |
| IC703 | D-10 |
| IC704 | D-5 |
| IC705 | E-5 |
| IC901 | I-7 |
| IC902 | J-7 |
| IC903 | I-10 |
| IC904 | I-11 |
| PH01 | I-19 |
| PH02 | I-19 |
| PH03 | I-22 |
| PH04 | F-22 |
| Q01 | G-19 |
| Q02 | G-19 |
| Q701 | D-7 |
| Q702 | D-7 |
| Q703 | D-7 |
| Q901 | I-9 |


**Notes on printed wiring board:**

- o——: Indicated a lead wire mounted on the component side.
- ■ : Parts mounted on the conductor side
- ● : Through hole
- ▒▒ : Pattern from the side which enables seeing

(The other layers' patterns are not indicated.)

| Caution: | |
|---|---|
| Pattern face side: (Conductor side) | Parts on the pattern face side seen from the pattern face are indicated. |
| Parts face side: (Component side) | Parts on the parts face side seen from the parts face are indicated. |








e 18 for circuit boards location and 25 for semiconductor lead layouts.



ORESCENT INDICATOR TUBE









【TIMER SW BOARD】





【BATTERY BOARD】





MECHANISM ASS'Y TOP VIEW





FL701 FLUORESCENT INDICATOR TUBE





【RF AMP BOARD】(COMPONENT SIDE)





【RF AMP BOARD】(CONDUCTOR SIDE)





【POWER BOARD】




【CAM MOTOR BOARD】





【DISPLAY BOARD】





12, 13 11 - 13 11 - 14


| | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 |
|---|---|---|---|---|---|---|---|---|---|---|





MECHANISM ASS'Y TOP VIEW





MECHANISM ASS'Y BOTTOM VIEW





【MOTOR BOARD】




【SW BOARD】




(See page 38)




】(COMPONENT SIDE)




】(CONDUCTOR SIDE)




【DRUM DRIVE BOARD】




【TOP END SENSOR BOARD】




【RGN SW BOARD】




S01-1
CASSETTE IN

S01-2
REC PROOF

【CAM SLIDER BOARD】




【CAM MOTOR BOARD】




【REEL MOTOR BOARD】

## 4-7. PRINTED WIRING BOARDS

– MAIN SECTION –


• See page 18 for circuit boards location and 25 for semiconductor lead layouts.

### ● SEMICONDUCTOR LOCATION

| Ref. No. | Location | Ref. No. | Location |
|---|---|---|---|
| D101 | F-4 | IC360 | G-5 |
| D102 | F-5 | IC363 | E-8 |
| D201 | F-4 | IC375 | H-6 |
| D202 | F-5 | IC376 | H-7 |
| D306 | F-11 | IC401 | F-2 |
| D307 | J-5 | IC431 | I-7 |
| D308 | J-7 | IC432 | J-7 |
| D314 | F-10 | IC501 | B-6 |
| D321 | F-10 | IC502 | B-7 |
| D322 | F-10 | IC503 | A-7 |
| D324 | F-10 | IC504 | B-8 |
| D350 | J-7 | IC601 | D-6 |
| D403 | G-8 | IC602 | F-6 |
| D501 | C-8 | | |
| D503 | C-7 | Q301 | B-12 |
| | | Q302 | J-10 |
| D601 | B-6 | Q311 | J-7 |
| D602 | C-6 | Q312 | J-5 |
| D603 | F-6 | Q313 | J-5 |
| D701 | I-14 | | |
| D702 | H-14 | Q318 | F-11 |
| | | Q319 | F-11 |
| IC101 | H-4 | Q320 | F-10 |
| IC201 | H-5 | Q321 | F-11 |
| IC301 | B-9 | Q333 | I-8 |
| IC302 | B-10 | | |
| IC303 | B-11 | Q334 | J-8 |
| | | Q335 | J-9 |
| IC304 | B-10 | Q336 | J-11 |
| IC305 | D-9 | Q337 | J-11 |
| IC306 | D-9 | Q338 | I-12 |
| IC307 | D-10 | | |
| IC308 | C-12 | Q339 | J-12 |
| | | Q340 | I-12 |
| IC309 | J-7 | Q341 | J-12 |
| IC310 | E-11 | Q342 | I-8 |
| IC311 | I-11 | Q432 | J-6 |
| IC312 | G-10 | | |
| IC316 | J-10 | Q433 | I-6 |
| | | Q434 | I-7 |
| IC318 | I-9 | Q435 | J-6 |
| IC319 | G-11 | Q436 | J-6 |
| IC320 | G-12 | Q437 | J-6 |
| IC321 | I-8 | | |
| IC322 | E-9 | Q438 | J-6 |
| | | Q439 | J-6 |
| IC330 | F-9 | Q440 | E-11 |
| IC331 | A-10 | Q499 | B-12 |
| IC332 | A-11 | Q501 | B-7 |
| IC333 | J-8 | | |
| IC354 | G-6 | Q502 | B-7 |
| | | Q503 | C-7 |
| IC355 | G-7 | Q601 | B-6 |
| IC356 | J-5 | Q602 | E-6 |
| IC357 | C-4 | Q603 | H-11 |
| IC358 | C-5 | | |
| IC359 | E-4 | | |

**Notes on printed wiring board:**

- ○——: Indicated a lead wire mounted on the component side
- ■ : Parts mounted on the conductor side
- ⊏⊐ : Indicates side identified with part number
- ⊕ : Through hole
- : Pattern from the side which enables seeing
- : Pattern of the rear side



【MAIN BOARD】

DIGITAL IN/OUT

J191 COAXIAL IN

J181 COAXIAL OUT

IC331 OPTICAL IN

J101 LINE IN

J102 LINE OUT

CN393 BLU BLK RED

CN101 WHT (RED) WHT (WHT)

CN106 WHT (RED) WHT (WHT)

CN104 WHT (WHT) WHT (RED)

CN107 WHT RED WHT (WHT) (RED) (WHT)

CN105 WHT (WHT) WHT (RED)

CN572 CN571

IC503 IC502 IC501 IC357 IC358 IC601 IC363 IC306 IC307 IC305 IC322 IC602 IC359 IC360 IC354 IC355 IC376 IC375 IC431 IC309 IC321 IC432 IC312 IC311

Q601 Q602 Q503 Q501 Q505 Q433 Q313 Q312 Q342 Q333 Q434

D321 R395

SONY AU-I-I3 TCD80-P11M

( 4, 6 )

| 9 | 10 | 11 | 12 | 13 | 14 |
|---|---|---|---|---|---|

DIGITAL IN/OUT

AL OUT

IC331 OPTICAL IN

IC332 OPTICAL OUT

IC307

IC310

IC311

IC312

IC322

IC330

IC316

IC303

IC304

IC308

IC320

IC319

IC302

X301

X302

X303

CN333

CN501

CN391

CN308

CN508

CN301

CN576

CN571

CP601

Q499

Q340

Q338

Q339

Q337

Q336

Q341

Q301

SWP

FGS

WHT

RED

BLK

YEL

BLU

(ORG)

(BLU)

【LED BOARD】

Q702

Q701

CN756

1-645-241-

1-645-233-


TO POWER BOARD

TO MD, CASSE-COM, DRUM DRIVE, RF AMP BOARD

TO CONTROL SW/ BATTERY BOARD

(See page 34)

TO MD/ POWER SUPPLY/ DISPLAY SECTION




**Notes on schematic diagram:**

- All capacitors are in µF unless otherwise noted. pF: µµF 50WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in ohms, 1/4W or less unless otherwise noted.
- △ : Internal component
- % : Indicate a permissible margin
- ▭ : Nonflammable resistor

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque ⚠ sont critiques pour la sécurité.
Ne les remplacer que par une piéce portant le numéro spécifié.

- ——— : B+ Line
- - - - : B– Line
- ▭ : Adjustment for repair
- Voltage are dc with respect to ground under no-signal (STOP) conditions.

  No mark : Stop
  ( ) : PLAY
  (( )) : REC
  < > : FF
  << >> : REW
  [ ] : MOMENTARILY WHEN ▶▶, ◀◀ and ▶ BUTTON IS PRESSED.
  [[ ]] : MUTING
- Voltages are taken with a VOM (input impedance 10MΩ). Voltage variations may be noted due to normal production tolerances.
- Circled numbers refer to waveforms.
- Waveforms are taken with a oscilloscope. Voltage variations may be noted due to normal production tolerances.
- Signal path
  ▷▷ : PB
  ▷▷ : REC

block diagrams and 46 for pin functions.

| | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 |
|---|---|---|---|---|---|---|---|---|---|---|---|---|

(See page 29) (See page 28) (See page 27)

| | US, E, Canadian | AEP |
|---|---|---|
| JW615 | ○ | ○ |
| JW616 | X | ○ |

IC304 IC322 IC333 IC307 IC310 IC431 IC432 IC321 IC308 IC359 IC358 IC357 IC355 IC354 IC356 IC602 IC601 IC363 IC311 IC504 IC503

2 To POWER BOARD CN932
3 To CONTROL SW BOARD CN751
4 To CONTROL SW BOARD CN752

IC307 CX02601AQ (E) ERROR CORRECTION, A/D D/A INTERFACE, MODULATION, DEMODULATION, SUB CODE DECODER

IC310 CXK58257M-12L 256K-SRAM

IC311 CXP80524-063Q (S) MECHANISM CONTROLLER

IC333 SN74HCU04AN INVERTER / BUFFER

IC308 SN74LS624N VCO

IC431 SN74HC10ANS MUTE SWITCH

IC432 PST572C-T MUTE

IC321 PST572E-T RESET

IC359 CS5339-KP A/D CONVERTER

IC358 M5F7905L -5V REG

IC357 CX02601AQ +5V REG

IC355 NE5532P ADDER

IC354 NE5532P ADDER

IC356 RC4558P SIGNAL LEVEL DET

IC602 NE5532P

IC601 CX025629 D/A CONVERTER

IC363 CX02560 DIGITAL FILTER

IC504 TC5081AP PHASE COMPARATOR

IC503 SN74HC4020ANS PRESCALER

Q318-321 PLUNGER SWITCH

Q601 REG.

Q602, IC602 REG.

To POWER BOARD CN933 (See page 29)

(See page 29)

(See page 30)

【LED BOARD】

| ※ | US, E, Canadian | AEP |
|---|---|---|
| JW615 | ○ | ○ |
| JW616 | X | ○ |

IC311
1C311
CXP80524-063Q
(S)
MECHANISM CONTROLLER

IC312
1C312
CXP80524-062Q
(M)
MAIN CONTROLLER

IC319
M54641L
LOADING MOTOR DRIVE

IC320
M54641L
CASSETTE-CON MOTOR DRIVE

IC330
RP5C62 CLOCK
REAL TIME CLOCK

IC501
1C501
M5F7808L
+8V REG.

IC502
1C502 (1/2) SN74HCU04ANS BUFFER
1C502 (2/2) SN74HCU04ANS BUFFER

IC503
1C503
SN74HC4020ANS
PRESCALER

IC504
IC504 PHASE COMPARATOR
IC504
TC5081AP

IC316
IC316 (2/4) LM324N — DRUM PWM FILTER
IC316 (3/4) LM324N — CAPSTAN PWM FILTER
IC316 (4/4) LM324N — CAPSTAN PWM DRIVER
IC316 AGC PWM FILTER

IC318
IC318 (2/2) LM358P — REEL PWM FILTER
IC318 (1/2) LM358P — TENSHION PWM FILTER

Q603 2SA1115TP-EF — Q603 LED DRIVE
Q318-321 PLUNGER SWITCH
Q318 2SC3402TP
Q319 2SC3402TP
Q320 2SA1585S
Q321 2SC4115S
Q306 11ES2
Q314 11ES2
Q501 2SK241GR VCO
Q502 2SK241GR BUFFER
Q503 2SA1348TP VCO RANGE SELECTOR
Q333-335 REEL PWM DRIVER
Q336-341 REEL DIRECTION SWITCH
Q342 2SD2012 TENSHION PWM DRIVER
Q302 2SD1387-34 CAPSTAN PWM DRIVER

CN301 PH REG
CN508 30P
CN576 2P DR
CN756 2P
CN398 2P
CN391 2P
CN308 DR

To CAPSTAN MOTOR ASSY
To DRUM DRIVE BOARD CN08
To BATTERY BOARD CN399 (See page 27)
To POWER BOARD CN931 (See page 29)
To MOTOR BOARD CN1 (See page 28)


D701,702 LN01401C(Q)
D702 D701

CP601-100K-X10
AEP MODEL
FWD TORQUE
XTEST MAIN
X304 32.768 kHz

## 4-9. IC BLOCK DIAGRAMS


- **DRUM DRIVE board**

**IC01 CX20115A**





- **RF AMP board**

**IC1 CXA1364R**





- **MAIN board**

**IC306 CXD1136Q**








**IC307 CXD2601AQ**





**IC308 SN74LS624N**





**IC309 SN74HC74ANS**





**IC319,320 M54641L**








**9,320 M54641L**





**IC359 CS5339-KP**




**IC363 CXD2560M**





**IC504 TC5081AP**




**IC601 CXD2562Q**

**IC504 TC5081AP**





## 4-10. PIN FUNCTIONS

### IC306 Digital Attenuator (CXD1136Q)

The captioned attenuator is used with the equipment as a digital attenuator in fade IN and fade OUT.

| Pin No. | Pin Name | I/O | Description |
|---|---|---|---|
| 1 | DIGO | O | Serial data output synchronized with BCK (complement of 2) |
| 2 | DIGI | I | Serial data input synchronized with BCK (complement of 2) |
| 3 | ERFO | O | Signal output for discriminating whether or not DADT has interpolated data (Not in use) |
| 4 | UNDF | O | Detect result for ADDT L, R channel data of –54 dB or less ("L": –54 dB or less) (Not in use) |
| 5 | OVFL | O | Detect result for ADDT L channel overflow ("L": overflow detected) (Not in use) |
| 6 | OVFR | O | Detect result for ADDT R channel overflow ("L": overflow detected) (Not in use) |
| 7 | VSS | — | GND |
| 8 | SUBT | I | Selects whether subcode or 18-bit data is output to ADDT and DIGO ("H" or open: 18-bit data output, "L": subcode output) |
| 9 | LSB1 | I | MSB/LSB fast switching for DADT, ADDT, DIGI, DIGO ("H" or open MSB fast, L: LSB fast) |
| 10 | LSB2 | I | MSB/LSB fast switching for DAC2, ADC2L (ADC2R) ("H" or open MSB fast, L: LSB fast) |
| 11 | OVON | I | Overflow detect result on/off ("H" or open: OVFL, OVFR output valid, L: OVFL, OVFR fixed "H") |
| 12 | LCF | I | Low-cut filter on/off ("H" or open: on) |
| 13 | ADDA | O | "H" in AD mode (DASL = DIAN = "L") (Not in use) |
| 14 | DIAN | I | Sets AD and DA modes |
| 15 | DASL | I | Sets AD and DA modes |
| 16 | MUTE | I | Soft muting on/off ("H": mute on) |
| 17 | ATLV | I | Digital volume range setting ("H" or open: 0 - –60, – ∞ dB, "L": +12 - –48, ∞ dB |
| 18 | ATON | I | Digital volume on/off ("H" or open: off) |
| 19 | ATDN | I | Digital volume level down |
| 20 | ATUP | I | Digital volume level up |
| 21 | ATCK | I | Digital volume level setting clock and soft muting external clock |
| 22 | ATEX | I | Soft muting operation clock selection ("H" or open: internal clock, "L": ATCK) |
| 23 | VDD | — | Power supply (+5 V) |
| 24 | NC | | |
| 25 | VDD | — | Oscillator circuit power supply (+5 V) |
| 26 | SCK | O | Oscillator clock output (Not in use) |
| 27 | NC | | |
| 28 | XTLI | I | Crystal connector and clock input pin |
| 29 | NC | | |
| 30 | XTLO | O | Crystal connector pin (24.576 MHz oscillation frequency possible) (Not in use) |
| 31 | VSS | — | Oscillator circuit GND |
| 32 | CKSL | I | Oscillator clock division selection ("H" or open: no division, "L": 1/2 division) |
| 33 | NC | | |
| 34 | NC | | |
| 35 | DOFF | I | DAC2 digital offset on/off ("H" or open: on) (Not in use) |
| 36 | APSL | I | Aperture correction filter coefficient selection (not valid in AD mode) ("H" or open: correction active) |
| 37 | LRSL | I | L, R channel phase difference correction selection ("H" or open: correction active) (Not in use) |
| 38 | DAC2 | O | Serial data output to 2-times oversampling DA converter (complement of 2) (Not in use) |
| 39 | VSS | — | Power supply (+5 V) |
| 40 | BKSL | I | LRCK, BCK input timing switch ("H" or open: LRCK change point and BCK leading edge synchronized, "L": LRCK change point and BCK trailing edge synchronized) |
| 41 | INSL | I | DADT, DIGI, ADC2L (ADC2R) data incorporation clock selection ("H" or open: BCK, "L": INCK) |
| 42 | ADSL | I | ADC2L, ADC2R data selection ("H" or open: ADC2L, "L": ADC2L and ADC2R switched by LRCK2) |
| 43 | NC | | |
| 44 | WCK2 | O | Clock equivalent to 4fs (Not in use) |
| 45 | LR21 | O | DAC2 L, R channel discrimination signal in I²S format (Not in use) |



| Pin No. | Pin Name | I/O | Description |
|---|---|---|---|
| 46 | APTL | O | Aperture signal (Not in use) |
| 47 | APTR | O | Aperture signal (Not in use) |
| 48 | LRCK2 | O | DAC2, ADC2L (ADC2R) L, R channel discrimination signal (equivalent to 2fs) ("L": L channel, "H": R channel) (Not in use) |
| 49 | XLRCK2 | O | LRCK2 inverted output (Not in use) |
| 50 | XBCK | O | BCK inverted output (Not in use) |
| 51 | BCK | I | Clock equivalent to 64fs for DADT, ADDT, DIGI, DIGO data incorporation |
| 52 | INCK | I | DADT, DIGI, ADC2L (ADC2R) data incorporation clock |
| 53 | VDD | — | Power supply (+5 V) |
| 54 | ADC2L | I | Serial data input from 2-times oversampling AD converter (complement of 2) |
| 55 | ADC2R | I | Serial data input from 2-times oversampling AD converter (complement of 2) |
| 56 | LRCK | I | DADT, ADDT, DIGI, DIGO L, R channel discrimination signal (fs) ("L": L channel, "H": R channel) |
| 57 | ADDT | O | Serial data output synchronized with BCK (complement of 2) |
| 58 | ERFI | I | Signal input for discriminating whether or not DADT has interpolated data (complement of 2) |
| 59 | DADT | I | Serial data input synchronized with BCK (complement of 2) |
| 60 | OVCW | I | Clock input which determines detect time for OVFL, OVFR and UNDF |

### IC307 DAT Signal Processor (CXD2601AQ)

This processor is an LSI to process recording and playback signals of the R-DAT system, in a single chip and provided with digital PLL, modem, error correction circuit, digital I/O, RAM control circuit, etc.

| Pin No. | Pin Name | I/O | Description |
|---|---|---|---|
| 1, 2 | A08, A09 | I/O | RAM address A08, A09 |
| 3 | VDD | — | 5 V |
| 4-6 | A10-A12 | I/O | RAM address A10-A12 |
| 7, 8 | A13, A14 | O | RAM address A13, A14 |
| 9 | XWE | O | RAM write enable signal |
| 10 | XOE | O | RAM output enable signal |
| 11 | XEAN | O | External addressing bus interrupt enable signal (Not in use) |
| 12 | TST1 | I | Test pin (normally "L") |
| 13 | XTIO | O | 18.816 MHz crystal oscillator output |
| 14 | XTII | I | 18.816 MHz crystal oscillator input |
| 15 | VSS | — | GND |
| 16 | XRST | I | Reset pin (normally"H") |
| 17 | CLKO | I/O | 18.816 MHz clock output (Not in use) |
| 18 | XCST | I/O | SYEK (internal system clock) generation CLKO division timing signal (Not in use) |
| 19 | ATSY | I | ATF sync signal input |
| 20 | MCLK | O | 9.408 MHz clock output |
| 21 | DREF | O | Drum servo reference signal |
| 22 | SBPM | O | Discrimination signal determining whether the subcode I/O clock (EXCK) is accepted ("L": accept, "H": ignore) (Not in use) |
| 23 | EXCK | I | Subcode I/O data transfer clock (DUTY50) |
| 24 | SDSI | I | Subcode serial data input |
| 25 | SDSO | O | Subcode serial data output |
| 26 | SBSY | O | Subcode I/O sync signal |
| 27 | COPY | O | Copy data output (Not in use) |
| 28 | EMP | O | Emphasis data output (Not in use) |
| 29 | MUTE | I | Mute pin |
| 30 | MUTM | O | Mute discrimination signal ("H": muted) |
| 31 | UNLK | O | RX PLL lock discrimination signal ("H": locked) |
| 32 | ERMN | O | Detects presence or absence of RF ("H": RF present, "L" during REC) |
| 33 | SYMN | O | C1 check result for RF ("H": OK) (Not in use) |
| 34 | CHER | I | Signal for discriminating whether C2 is 1 or 2 times (C2 → C1 → C2 or C1 → C2) ("H": 1 time, "L": 2 times) (Not in use) |
| 35 | PLCK | I/O | RF PLL clock output (Not in use) |
| 36 | TST2 | I | Test pin (normally "L") |
| 37 | RFDT | I | RF signal input |
| 38 | XCS | I | Subcode I/O chip select ("L": select) |
| 39 | SWP | I | RF switching pulse ("L": A-CH, "H": B-CH) |
| 40 | VSS | — | GND |
| 41 | PIPC | O | REC data PILOT/PCM discrimination signal ("H": PILOT, during playback: always "L") |
| 42 | REPB | O | Record/playback switching signal ("H": record) |
| 43 | REDT | O | Recording signal output, fixed "L" during playback |
| 44 | TST4 | I | Test pin (normally "L") |
| 45 | PDO | O | RX APLL PD output (comparator output) |
| 46 | AMPI | I | RX APLL oscillator cell amp input |
| 47 | AMPO | O | RX APLL oscillator cell amp inverted output |
| 48 | PLCO | I | RX APLL external VCO clock input |

| Pin No. | Pin Name | I/O | Description |
|---|---|---|---|
| 49 | PLVR | O | RX APLL comparison signal when external comparator is active (Vin) Not in use |
| 50 | PLRF | O | RX APLL comparison signal when external comparator is active (Rin) Not in use |
| 51 | MSSL | I | Master/slave setting ("H": master (fixed with the equipment), "L": slave) |
| 52 | RX | I | Digital input |
| 53 | VDD | — | 5 V |
| 54 | TX | O | Digital output |
| 55 | AUDR | I | Audio mode/data recorder mode setting ("H": audio mode, "L": data recorder mode) |
| 56 | EXSY | I/O | Complete copy sync signal (25/3 - 100/3 Hz) |
| 57 | EXSN | I/O | Complete copy sync signal (25/3 - 100/3 Hz) |
| 58 | F128 | I/O | 128fsCK (normal)/256fsCK (×2) (DUTY50) |
| 59 | F256 | O | 256fsCK (normal)/512fsCK (×2) (DUTY50) |
| 60 | F512 | O | 512fsCK (normal)/512fsCK (×2) (DUTY50) |
| 61 | ADLF | I | Signal for discriminating whether ADDT serial data is MSB first or LSB first ("H": LSB first) |
| 62 | DALF | I | Signal for discriminating whether DADT serial data is MSB first or LSB first ("H": LSB first) |
| 63 | XT20 | O | 22.5792 MHz crystal oscillator output |
| 64 | XT21 | I | 22.5792 MHz crystal oscillator input |
| 65 | VSS | — | GND |
| 66 | XT30 | O | 49.152 MHz crystal oscillator output (24.576 MHz in B mode) |
| 67 | XT31 | I | 49.152 MHz crystal oscillator input (24.576 MHz in B mode) |
| 68 | FSEN | I | F128, BCK, LRCK input/output switch ("H": output) |
| 69 | LR03 | O | LR02 inversion |
| 70 | LR02 | O | LRCK 16BCK delay signal |
| 71 | LR01 | O | LRCK 15BCK delay signal |
| 72 | LRCK | I/O | fs (normal)/2fs (×2) ("L": L-CH, "H": R-CH) |
| 73 | WCK | I/O | 2fs (normal)/4fs (×2) (input mode only for testing) |
| 74 | XBCK | O | BCK inversion |
| 75 | BCK | I/O | 64fs (normal)/128fs (×2) |
| 76 | ADDT | I | Serial AD data (complement of 2) |
| 77 | DADT | O | Serial DA data (complement of 2) |
| 78 | DADO | I | Digital output (DA) data input (normally connected to DADT) |
| 79 | ADDI | O | Digital input (AD) data output (normally connected to ADDN) |
| 80 | ADDN | I | Digital input (DA) data input |
| 81 | ERRI | I | Digital output V-FLAG data input (normally connected to ERRF) |
| 82 | ERRF | O | Signal output for discriminating whether or not DADT has interpolated data ("H": interpolated data) |
| 83 | MUTG | O | Error correction status monitor trigger |
| 84-89 | D7-D2 | I/O | RAM data bus D7-D2 |
| 90 | VSS | — | GND |
| 91, 92 | D1, D0 | I/O | RAM data bus D1, D0 |
| 93-100 | A00-A07 | I/O | RAM address A00-A07 |

### IC311 Mechanism/Servo Micon (CXP80524-063Q)

The mechanical deck servo systems are controlled by the captioned micon according to instructions from the main micon (IC312).

| Pin No. | Pin Name | I/O | Connected to | Description |
|---|---|---|---|---|
| 1 | | O | | Not in use |
| 2 | $\overline{\text{BUSY}}$ | O | Main Micon | Busy (Active "L") to the Main Micon |
| 3 | | O | | Not in use |
| 4 | REEL_CCW | O | Mechanism | Reel motor CCW ("L": RVS direction) } *1 |
| 5 | REEL_CW | O | Mechanism | Reel motor CW ("H": FWD direction) } *1 |
| 6 | C_DIR_RVS | O | Mechanism | Capstan Direction ("L": FWD, "H": RVS) |
| 7 | PLN_ON | O | Mechanism | Plunger On |
| 8 | PLN_KICK | O | Mechanism | Plunger Kick |
| 9 | D_ON | O | Mechanism | Drum On ("H": The drum is revolving) |
| 10 | D_DIR_RVS | O | Mechanism | Not in use |
| 11-16 | | O | | Not in use |
| 17 | LE | O | Mechanism | Loading Motor Eject } *2 |
| 18 | LL | O | Mechanism | Loading Motor Load } *2 |
| 19 | CAS_M_OUT | O | Mechanism | Cassette control motor Out } *3 |
| 20 | CAS_M_IN | O | Mechanism | Cassette control motor In } *3 |
| 21-24 | | — | | Not in use |
| 25 | RE_FWD | I | Mechanism | Encoder SW2 } *4 |
| 26 | RE_STOP | I | Mechanism | Encoder SW1 } *4 |
| 27-30 | $\overline{\text{END_LED_ON}}$ | O | Mechanism | End sensor ON Illuminated upon "L" (rectangular wave of about 1kHz). It is not output unless a cassette is mounted ("H"). |
| 31 | MP | I | | Microprocessor mode selected (the equipment is fixed at "L"). |
| 32 | $\overline{\text{RST}}$ | I | | System Reset (low active) |
| 33 | Vss | — | | Power terminal (GND) |
| 34 | XTAL | O | | System Clock Output (Not in use) |
| 35 | EXTAL | I | CXD2601AQ | System Clock Input (9.408 MHz) |
| 36-39 | | — | | Not in use |
| 40 | X_SRV_REQ | I | Main Micon | Request for communication from the Main Micon |
| 41 | MAIN_DT_I | I | Main Micon | Serial Input from the Main Micon |
| 42 | MAIN_DT_O | O | Main Micon | Serial Output to the Main Micon |
| 43 | MAIN_CK | I | Main Micon | Serial Clock with the Main Micon |
| 44 | AVss | — | | GND for A/D |
| 45 | AVref | — | | Reference Voltage for A/D (+5 V) |
| 46 | AVdd | — | | Power Supply for A/D (+5 V) |
| 47 | T_END | I | Mechanism | Take-up side end sensor input (analog) } Magnetic matter: 0V, |
| 48 | S_END | I | Mechanism | Supply side end sensor input (analog) } Leader tape: AC (*5) |
| 49 | CAS_IN | I | Mechanism | Cassette-in switch (S01). "H": Cassette is mounted. |
| 50 | REC_EN | I | Mechanism | Rec-enable switch (S01). "H": REC enabled. |
| 51 | CAS_LCKed | I | Mechanism | Casecon locked Upon completion of loading: "H" |
| 52 | CAS_OUTed | I | Mechanism | Casecon outed Upon completion of loading OUT: "H" |
| 53 | | I | | Not in use |
| 54 | ATF_IN | I | RF Amp | ATF PILOT input |
| 55 | FG_T | I | Mechanism | Reel FG (T Side) } 6/24Hz (Small reel diameter) - |
| 56 | FG_S | I | Mechanism | Reel FG (S Side) } 15/24Hz (Large reel diameter) (In SP FWD) |
| 57 | C_FG | I | Mechanism | Capstan FG SP: 674 Hz, LP: 337 Hz |
| 58 | D_FG | I | Mechanism | Drum FG 400 Hz: LP REC, 800 Hz: Other modes |
| 59 | D_PG | I | Mechanism | Drum PG } Other than LP REC: 800/24Hz |
| 60 | D_REF | I | CXD2601AQ | Drum Reference } In LP REC: 400/24Hz |

| Pin No. | Pin Name | I/O | Connected to | Description |
|---|---|---|---|---|
| 61 | MST_CK | I | CXD2601AQ | Master clock (9.408MHz) |
| 62 | PB_DT | I | RF Amp | PB Data input to create ATF Sync |
| 63 | SWP | O | CXD2601AQ | Switching Pulse "L": Ach, "H": Bch |
| 64 | D_PWM | O | Mechanism | PWM Out for Drum |
| 65 | C_PWM | O | Mechanism | PWM Out for Capstan |
| 66 | PWM_R | O | Mechanism | PWM Out for Reel |
| 67 | TEN_PWM | O | Mechanism | PWM Out for Tension Regulator Plunger |
| 68 | AGC_PWM | O | RF Amp | PWM Out for AGC |
| 69 | $\overline{SBSY}$ | I | CXD2601AQ | ↓ of subsync is detected (XINT2). |
| 70 | $\overline{TEST}$ | I | Pull-up | Test Mode (active "L") |
| 71 | POW_DN | I | | Not in use |
| 72 | Vdd | — | | Power terminal (+5 V) |
| 73 | Vss | — | | Power terminal (GND) |
| 74 | | — | | Not in use |
| 75 | ATF_S2 | O | CXD2601AQ | ATF Sampling Pulse |
| 76-80 | | — | | Not in use |

* 1 Reel motor control

| | CCW (counterclockwise) | CW (clockwise) |
|---|---|---|
| STOP (only in POWER ON) | L | L |
| FWD | L | H |
| RVS | H | L |
| Prohibit | H | H |

*2 Loading motor control


| | LE | LL |
|---|---|---|
| — | L | L |
| LOAD | L | H |
| EJECT | H | L |
| Brake | H | H |

*3 Casecon motor control


| | OUT | IN |
|---|---|---|
| — | L | L |
| IN | L | H |
| OUT | H | L |
| Brake | H | H |

*4 Encoder

| RF-FWD | RE_STOP | Position |
|---|---|---|
| L | L | EJECT |
| L | H | STOP<br>UNLD-STOP |
| H | L | FWD |
| H | H | STOP-FWD |




*5 End sensor




With leader tape

### IC312 Main Micon (CXP80524-062Q)

This Micon generally controls the operation of the equipment while exchanging data with the display micon (IC701) and mechanism/servo micon (IC311) in serial communications, including the DAT signal processor (IC307), digital filter (IC363) and other IC.

| Pin No. | Pin Name | I/O | Connected to | Description |
|---|---|---|---|---|
| 1 | VCO EN | O | VCO Circuit | VCO enable out |
| 2 | L_MUTE | O | Line Out | Line Mute (Active "L") |
| 3 | | O | | Not in use |
| 4 | | O | | Not in use |
| 5 | WRT | O | Clock IC | Write request (Active "L") |
| 6 | RD | O | Clock IC | Read request (Active "L") |
| 7-10 | ADRS_3-0 | O | Clock IC | Address 3-0 (Address BUS) |
| 11-14 | DATA_7-4 | I/O | | DATA 7-4 (DATA BUS). Not in use with the equipment |
| 15-18 | DATA_3-0 | I/O | Clock IC | DATA 3-0 (DATA BUS) |
| 19 | ATT_EXT | O | CXD1136Q | Fade attenuator ck externally selected (Active "L") |
| 20 | DIG/ANA | O | CXD1136Q | Fade In/Out switching for DIG ("L")/ANA ("H") |
| 21 | REC/PB | O | CXD1136Q | Fade In/Out REC switching for ("L")/PB ("H") |
| 22 | ATT_CK | O | CXD1136Q | Clock for fade In/Out |
| 23 | DTR | O | CXD2601AQ | Audio use ("H")/Data Recorder use ("L). Becomes "L" in after-recording and searching. |
| 24 | OPT/COA | O | Digital I/O | Switching for Optical ("L")/Coaxial ("H") |
| 25 | FS32 | O | 1Bit DAC | "H" upon Fs = 32kHz. "L" for others. |
| 26 | RAM_SEL | O | | Not in use |
| 27 | DISP_REQ | O | Display Micon | Request for communication with the Display Micon ("L" Active) |
| 28 | SD_SEL | O | CXD2601AQ | Request for communication with CXD2601 ("L" Active) |
| 29 | SRV_REQ | O | Mechanism Micon | Request for communication with the Mechanism Micon ("L" Active) |
| 30 | CLOCK_SEL | O | Clock IC | Clock IC chip selected |
| 31 | MP | I | | Microprocessor mode selected (fixed at "L" with the equipment) |
| 32 | RST | I | | System Reset ("L" Active) |
| 33 | Vss | — | | Power terminal (GND) |
| 34 | XTAL | O | | System Clock Output (Not in use) |
| 35 | EXTAL | I | CXD2601AQ | System Clock Input (9.048 MHz) |
| 36 | DISP_ACK | I | Display Micon | ACKnowledge (Active "L") |
| 37 | DISP_DT_I | I | Display Micon | Serial Input |
| 38 | DISP_DT_O | O | Display Micon | Serial Output |
| 39 | DISP_CK | I | Display Micon | Serial clock |
| 40 | SBSY | I | CXD2601AQ | Subcode sync |
| 41 | SR_DT_IN | I | CXD2601AQ & Mechanism Micon | Serial Data In |
| 42 | SR_DT_OUT | O | | Serial Data Out |
| 43 | SR_CK | I/O | | Serial clock (In/Out) to Sub Code Interface |
| 44 | AVss | — | | GND for A/D |
| 45 | AVref | — | | Reference Voltage for A/D (+5 V) |
| 46 | AVdd | — | | Power Supply for A/D (+5 V) |
| 47 | | I | | Not in use |
| 48 | | I | | Not in use |
| 49 | BUSY | I | Mechanism Micon | Mechanism servo micon Busy (Active "L") |
| 50 | AU_BUS_IN | I | Pull-up | Not in use |

| Pin No. | Pin Name | I/O | Connected to | Description |
|---|---|---|---|---|
| 51 | TM_IN | I | Clock IC | TM_OUT for clock IC |
| 52 | MUT_MON | I | CXD2601AQ | Mute monitor (Active "H") |
| 53 | LVL_SYNC | I | Audio Block | Start ID is written by entering Level Sync Input audio. |
| 54 | | I | | Not in use |
| 55 | $\overline{\text{TRQ_TEST}}$ | I | Pull-up | Not in use |
| 56 | $\overline{\text{NO_CAS_TEST}}$ | I | Pull-up | Not in use |
| 57 | TIME_$\overline{24}$/12 | I | Pull-up | Time indication "H": 12 hours (AM, PM) "L": 24 hours display |
| 58 | DATE_ORDER | I | Pull-up | Order of DATA display "H": Year, month and day "L": Month, day and year |
| 59-62 | AF_3-0 | I | Pull-up | Not in use |
| 63 | | O | Pull-up | Not in use |
| 64 | $\overline{\text{L_MUTE}}$ | O | | Line Mute (Active "L"). Not in use with the equipment (Not in use) |
| 65 | $\overline{\text{TR_MUTE}}$ | O | Line Out | Transistor Mute (Active "L") |
| 66 | MUTE_1136 | O | CXD1136Q | Mute for CXD1136Q (Active "H") |
| 67 | MUTE_2601 | O | CXD2601AQ | Mute for CXD2601 (Active "H") |
| 68 | A_D_PWR_DWN | O | CS5339 | A/D Converter Power Down Mode (Active "H"). The AD converter is turned OFF upon digital input/output. |
| 69 | ER_MON | I | CXD2601AQ | Error Monitor (Data Valid) |
| 70 | $\overline{\text{TEST}}$ | I | Pull-up | Test Mode (Active "L") |
| 71 | POW_DN | I | +5 V | Not in use |
| 72 | Vdd | — | | Power terminal (+5V) |
| 73 | Vss | — | | Power terminal (GND) |
| 74 | | — | Pull-up | Not in use |
| 75 | D_F_ATT | O | CXD2560M | Communication line (Serial Data) with Digital Filter |
| 76 | D_F_$\overline{\text{SHIFT}}$ | O | CXD2560M | Communication line with Digital Filter (Shift Clock; shifted by ↓ and taken in by ↑) |
| 77 | D_F_$\overline{\text{LATCH}}$ | O | CXD2560M | Communication line (Latch Pulse) with Digital Filter |
| 78, 79 | MODE2, 1 | O | | Mode Control of the RF amplifier (Not in use) |
| 80 | ADRS | O | | Not in use |

**IC330 Real Time Clock (RP5C62)**

The Clock is an IC for clock and calendar and backed up by a lithium battery when the power supply to the set is OFF.

| Pin No. | Pin Name | I/O | Description |
|---|---|---|---|
| 1 | $\overline{\text{CS}}$ | I | Chip select input. Active "L" |
| 2 | CE | I | Chip enable input. Active "H" |
| 3 | TMOUT | O | Interval output |
| 4-7 | A0-3 | I | 4 bit address input |
| 8 | $\overline{\text{RD}}$ | I | Read-out control input |
| 9 | Vss | – | Power terminal (GND) |
| 10 | $\overline{\text{WR}}$ | I | Write-in control input |
| 11-14 | D0-3 | I/O | 4 bit data input/output |
| 15 | $\overline{\text{INTR}}$ | O | Interrupt output. A 2048Hz signal is output here with the equipment. |
| 16 | OSCIN | I | Clock input (32.768kHz) |
| 17 | OSCOUT | O | Clock output |
| 18 | $V_{DD}$ | – | Power terminal (+5 V) |

### IC701 Display Micon (CXP5058H-659Q)

The Micon controls key input, FL tube display, remote control signal input, level meter (IC702) and EEP-ROM (IC703) according to instructions from the Main Micon (IC312).

| Pin No. | Pin Name | I/O | Connected to | Description |
|---|---|---|---|---|
| 1-18 | e_-v_SEG | O | FL tube FL701 | FL Segment 'e'-'v' |
| 19-28 | 10_-1_G | O | FL tube FL701 | FL Grid #10-#1 |
| 29 | $\overline{\text{DSP_REQ}}$ | I | MAIN Micon | Communication request ("L" Active) |
| 30 | XTAL | — | Ceramic oscillator | |
| 31 | EXTAL | I | Ceramic oscillator | 4.19MHz ceramic oscillator |
| 32 | $\overline{\text{RST}}$ | I | | System Reset ("L" active) |
| 33 | NC | — | | Not in use |
| 34 | Vdd | I | | Power terminal (+5 V) |
| 35-42 | AD_0-7 | I | Panel switch | Key input A/D converter input #0 - #7 |
| 43 | NC | — | | Not in use |
| 44 | DISP_CK | O | MAIN Micon | Shift clock |
| 45 | SO | O | MAIN Micon | Serial data OUT |
| 46 | SI | I | MAIN Micon | Serial data IN |
| 47 | $\overline{\text{DSP_ACK}}$ | O | MAIN Micon | Acknowledge (Active"L") |
| 48 | $\overline{\text{TEST}}$ | I | Pull-up | Test mode (Active"L") |
| 49 | COUNTER MODE | I | S704 | MODE (counter) switch (Active"L") |
| 50 | REC MODE | I | S705 | REC MODE "H": Standard, "L": Long |
| 51-54 | LVL_DT_0-3 | I/O | Level Meter IC | Level Meter Data 0-3 |
| 55, 56 | LVL_ADRS_0, 1 | O | Level Meter IC | Level Meter Data 0, 1 |
| 57 | $\overline{\text{LVL_RD}}$ | O | Level Meter IC | Level Meter Read Mode (Active "L") |
| 58 | $\overline{\text{LVL_WR}}$ | O | Level Meter IC | Level Meter Write Mode (Active "L") |
| 59 | $\overline{\text{LVL_SEL}}$ | O | Level Meter IC | Level Meter IC Select (Active "L") |
| 60 | $\overline{\text{RM_SEL}}$ | O | Open | External remote controller selected (not in use) |
| 61 | RMC MON | I | Remote sensor | Remot control signal input |
| 62 | RMC | I | Remote sensor | Remot control signal input |
| 63 | RMC_CAT | I | Pull-down | Remote control category "L": DAT1, "H": DAT2. Fixed at "L" with the equipment. |
| 64 | $\overline{\text{TR_MUTE}}$ | I | IC431 | Level meter mute (Active "L") |
| 65 | $\overline{\text{BUSY}}$ | I | EEPROM | BUSY signal (Active "L") |
| 66 | ROM_DT_IN | I | EEPROM | Data input |
| 67 | ROM_DT_OUT | O | EEPROM | Data output |
| 68 | $\overline{\text{SHIFT_CK}}$ | O | EEPROM | Shift clock |
| 69 | $\overline{\text{CE}}$ | O | EEPROM | Chip enable |
| 70 | DTC/$\overline{\text{XPCM}}$ | I | Pull-up | Equipment model discrimination input. Fixed at "H" with the equipment |
| 71 | Vss | I | | Power terminal (GND) |
| 72 | TX | — | Open | Not in use |
| 73 | NC | — | Open | Not in use |
| 74 | TEX | — | +5 V | Not in use |
| 75 | Vref | I | +5 V | Analog board reference voltage |
| 76 | Vfdp | I | –25 V | FL display tube driving voltage |
| 77-80 | a_-d_SEG | O | FL tube | FL Segment 'a'-'d' |

# SECTION 5
# EXPLODED VIEWS


NOTE:

- -XX, -X mean standardized parts, so they may have some differences from the original one.
- Color Indication of Appearance Parts
  Example:
  KNOB,BALANCE(WHITE)...(RED)
  ↑ ↑
  Parts color Cabinet's color
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.
- Hardware(# mark) list is given in the last of this parts list.

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.


Les composants identifiés par une marque ⚠ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

## 5-1. CABINET SECTION





| Ref.No. | Part No. | Description | Remarks |
|---|---|---|---|
| 1 | X-3365-595-1 | PANEL (CASSETTE) ASSY (AEP:GOLD) | |
| 1 | X-3365-599-1 | PANEL (CASSETTE) ASSY (US, Canadian, E/AEP:BLACK) | |
| 2 | 4-933-446-01 | SCREW (SIDE PANEL) | |
| 3 | X-3365-593-1 | PANEL (L) ASSY, SIDE (AEP:GOLD) | |
| 3 | X-3365-634-1 | PANEL (L) ASSY, SIDE (AEP:BLACK) | |
| 3 | X-3365-636-1 | PANEL (L) ASSY, SIDE (US, Canadian, E) | |
| 4 | X-3365-594-1 | PANEL (R) ASSY, SIDE (AEP:GOLD) | |
| 4 | X-3365-635-1 | PANEL (R) ASSY, SIDE (AEP:BLACK) | |
| 4 | X-3365-637-1 | PANEL (R) ASSY, SIDE (US, Canadian, E) | |
| 5 | 3-704-366-01 | SCREW (CASE) (M3X8) (US, Canadian, E/AEP:BLACK) | |
| 5 | 3-704-366-11 | SCREW (CASE) (M3X8) (AEP:GOLD) | |
| 6 | X-3304-938-2 | FOOT ASSY (US, Canadian, E/AEP:BLACK) | |
| 6 | X-4928-110-1 | FOOT ASSY (AEP:GOLD) | |
| * 7 | 3-382-125-11 | PANEL, BACK (AEP:BLACK) | |
| * 7 | 3-382-125-21 | PANEL, BACK (US, Canadian) | |
| * 7 | 3-382-125-31 | PANEL, BACK (E) | |
| * 7 | 3-382-125-51 | PANEL, BACK (AEP:GOLD) | |
| * 8 | 4-923-873-01 | BRACKET, CORD STOPPER | |
| * 9 | 3-703-244-00 | BUSHING (2104), CORD (AEP) | |
| 9 | 4-916-783-01 | BUSHING, CORD (US, Canadian, E) | |
| ⚠10 | 1-559-297-31 | CODE, POWER (E) | |
| ⚠10 | 1-559-479-11 | CORD, POWER (US, Canadian) | |
| ⚠10 | 1-575-912-11 | CORD, POWER (AEP) | |
| 11 | 4-934-008-01 | CASE (US, Canadian, E/AEP:BLACK) | |
| 11 | 4-934-008-11 | CASE (AEP:GOLD) | |
| 12 | 4-923-836-11 | CUSHION | |
| 13 | 1-590-321-71 | LEAD (WITH CONNECTOR) (CONTROL-S IN) (US, Canadian) | |

## 5-2. FRONT PANEL SECTION




| Ref. No. | Part No. | Description | Remarks |
|---|---|---|---|
| 51 | A-2004-110-A | LID ASSY (US, Canadian, E/AEP:BLACK) | |
| 51 | A-2004-144-A | LID ASSY (AEP:GOLD) | |
| 52 | 3-382-757-01 | PLATE (GROUND) | |
| 53 | 3-354-931-01 | KNOB (DIA. 10) (US, Canadian, E/AEP:BLACK) | |
| 53 | 3-354-931-31 | KNOB (DIA. 10) (AEP:GOLD) | |
| 54 | 3-354-981-01 | SPRING (SUS), RING (US, Canadian, E/AEP:BLACK) | |
| 54 | 3-356-935-01 | SPRING (AEP:GOLD) | |
| 55 | 4-908-848-01 | EMBLEM, SONY (US, Canadian, E/AEP:BLACK) | |
| 55 | 4-908-848-21 | EMBLEM, SONY (AEP:GOLD) | |
| 56 | 3-382-629-01 | WINDOW (FL TUBE) | |
| 57 | 3-382-635-01 | KNOB (REC-R) (US, Canadian, E/AEP:BLACK) | |
| 57 | 3-382-635-11 | KNOB (REC-R) (AEP:GOLD) | |
| 58 | 3-356-957-01 | SPRING | |
| 59 | 3-382-634-01 | KNOB (REC-L) (US, Canadian, E/AEP:BLACK) | |
| 59 | 3-382-634-11 | KNOB (REC-L) (AEP:GOLD) | |
| 60 | 3-382-627-01 | SPRING, RING | |
| 61 | 3-382-649-01 | PANEL (FRONT) (E/AEP:BLACK) | |
| 61 | 3-382-649-11 | PANEL (FRONT) (AEP:GOLD) | |
| 61 | 3-382-649-21 | PANEL (FRONT) (US, Canadian) | |
| * 62 | 1-645-241-11 | LED BOARD | |
| 63 | 3-575-524-00 | COVER, POWER SWITCH | |
| 64 | 4-917-460-01 | KNOB, POWER (US, Canadian, E/AEP:BLACK) | |
| 64 | 4-917-460-51 | KNOB, POWER (AEP:GOLD) | |
| 65 | 3-382-651-01 | KNOB (US, Canadian, E/AEP:BLACK) | |
| 65 | 3-382-651-11 | KNOB (AEP:GOLD) | |
| * 66 | 1-645-243-11 | TIMER SW BOARD | |
| * 67 | 4-922-524-01 | HOLDER (LEFT) | |
| * 68 | 4-922-523-01 | HOLDER (RIGHT) | |
| * 69 | A-2006-811-A | CONTROL SW BOARD, COMPLETE (AEP, E) | |
| * 69 | A-2006-865-A | CONTROL SW BOARD, COMPLETE (US, Canadian) | |
| 70 | 3-382-628-01 | BUTTON (SUB) (US, Canadian, E/AEP:BLACK) | |
| 70 | 3-382-628-11 | BUTTON (SUB) (AEP:GOLD) | |
| 71 | 3-382-644-01 | BUTTON (MAIN) (US, Canadian, E/AEP:BLACK) | |
| 71 | 3-382-644-11 | BUTTON (MAIN) (AEP:GOLD) | |
| 72 | 3-382-623-01 | SPRING, LEAF | |
| 73 | 3-382-639-01 | SHEET (US, Canadian, E/AEP:BLACK) | |
| 73 | 3-382-639-11 | SHEET (AEP:GOLD) | |
| 74 | 3-364-173-11 | KNOB (BAL) (US, Canadian, E/AEP:BLACK) | |
| 74 | 3-364-173-21 | KNOB (BAL) (AEP:GOLD) | |
| * 75 | 1-645-240-11 | INPUT SW BOARD | |
| * 76 | 1-645-239-11 | REC VOL BOARD | |
| 77 | 9-911-839-XX | CUSHION | |
| FL701 | 1-519-672-21 | INDICATOR TUBE, FLUORESCENT | |
| ⚠S901 | 1-554-920-21 | SWITCH, PUSH (AC POWER) (1 KEY) (POWER) | |

## 5-3. CHASSIS SECTION





The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque ⚠ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.


| Ref. No. | Part No. | Description | Remarks |
|---|---|---|---|
| * 101 | 1-645-245-11 | HEADPHONE VOL BOARD | |
| * 102 | 1-645-244-11 | HEADPHONE JACK BOARD | |
| * 103 | 3-382-640-11 | HOLDER (BATTERY) | |
| * 104 | 1-645-242-11 | BATTERY BOARD | |
| * 105 | 3-346-265-11 | HOLDER, PC BOARD | |
| * 106 | 3-670-570-00 | SPACER, SUPPORT | |
| 107 | 1-533-183-11 | HOLDER, FUSE | |
| * 108 | A-2006-819-A | POWER BOARD, COMPLETE | |
| * 109 | 1-645-234-11 | PRIMARY BOARD | |
| 110 | 4-812-134-00 | RIVET NYLON, 3.5 | |
| * 111 | 1-645-237-11 | CONTROL (S) BOARD (US, Canadian) | |
| * 112 | 1-645-235-11 | RELAY BOARD | |
| * 113 | A-2006-863-A | MAIN BOARD, COMPLETE (AEP) | |
| * 113 | A-2006-866-A | MAIN BOARD, COMPLETE (US, Canadian, E) | |
| 114 | 1-590-915-11 | WIRE, FLAT TYPE (30 CORE) | |
| * 115 | 3-703-044-26 | LABEL, CAUTION (US, Canadian) | |
| 116 | 3-701-947-15 | LABEL (T2.5A), FUSE (AEP, E) | |
| 117 | 4-886-821-11 | SCREW, S TIGHT, +PTTWH 3X6 | |
| 118 | 1-590-916-11 | WIRE, FLAT TYPE (10 CORE) | |
| 119 | 1-590-914-11 | WIRE, FLAT TYPE (6 CORE) | |
| * 120 | 4-363-146-71 | HEATSINK, V.OUT | |
| ⚠BAT301 | 1-528-229-11 | BATTERY, LITHIUMCR-2450 | |
| ⚠F901 | 1-532-744-11 | FUSE, GLASS TUBE (2.5A) (US, Canadian) | |
| ⚠F901 | 1-532-286-11 | FUSE, TIME-LAG (T2.5A) (AEP, E) | |
| ⚠T901 | 1-450-556-21 | TRANSFORMER, POWER (US, Canadian) | |
| ⚠T901 | 1-450-557-21 | TRANSFORMER, POWER (AEP) | |
| ⚠T901 | 1-450-558-21 | TRANSFORMER, POWER (E) | |

## 5-4. MECHANISM SECTION 1





| Ref. No. | Part No. | Description | Remarks |
|---|---|---|---|
| 151 | 3-373-224-01 | HOLDER (LOWER) | |
| 152 | 3-373-237-01 | HOLDER (UPPER), CASSETTE | |
| 153 | 3-373-223-01 | SLIDER (L) | |
| 154 | 3-373-222-01 | SLIDER (R) | |
| * 155 | 3-373-217-01 | SHAFT (JOINT) | |
| 156 | 3-345-648-01 | SCREW (M1.4X3.0), TOOTHED LOCK | |
| 157 | 3-318-201-11 | SCREW (B) (1.4X3), TAPPING | |
| 158 | 3-373-218-01 | LEVER (R) | |
| 159 | 3-373-219-01 | LEVER (L) | |
| 160 | 2-623-756-01 | SCREW, (B1.7X3), TAPPING | |
| 161 | 3-632-859-00 | SPRING, BRAKE LEVER RETURN | |
| 162 | 3-318-203-61 | SCREW (B1.7X4), TAPPING | |
| 163 | 3-373-215-01 | SPRING (R), TORSION | |
| 164 | 3-373-216-01 | SPRING (L), TORSION | |
| 165 | 3-382-648-01 | HOLDER (WINDOW) | |
| 168 | 3-373-212-01 | SPRING (HOLDER) | |
| 169 | 4-931-471-01 | SCREW (STEP) | |

## 5-5. MECHANISM SECTION 2





| Ref.No. | Part No. | Description | Remarks |
|---|---|---|---|
| 201 | 4-931-470-01 | BELT (DRIVING) | |
| 202 | 3-373-214-01 | PULLEY | |
| 203 | 2-623-756-01 | SCREW, (B1.7X3), TAPPING | |
| 204 | 3-373-213-01 | GEAR, DRIVING | |
| 205 | 3-373-234-04 | CHASSIS (L) | |
| 206 | 3-373-221-01 | SLIDER (RACK) | |
| * 207 | 1-641-487-11 | SW BOARD | |
| * 208 | 1-641-486-11 | MOTOR BOARD | |
| * 209 | 3-373-235-03 | CHASSIS (R) | |
| 210 | 3-703-150-11 | STOPPER, WIRING | |
| M901 | A-2003-910-A | MOTOR ASSY, CASSETTE (CASSETTE COMPARTMENT) | |

## 5-6. MECHANISM SECTION 3 (DATM-102)




| Ref. No. | Part No. | Description | Remarks |
|---|---|---|---|
| * 301 | 3-368-462-01 | CHASSIS (OUTSERT), MECHANICAL | |
| * 302 | 3-368-390-01 | BASE (#1 GUIDE) | |
| 303 | 3-368-409-01 | JOINT (#1 GUIDE) | |
| 304 | 3-368-413-01 | SCREW, +P (1) B1.4X2.5 | |
| * 305 | 3-368-442-01 | CATCHER | |
| 306 | 3-368-399-01 | GUIDE, ROLLER | |
| 307 | 3-368-428-01 | SHAFT (ROLLER GUIDE) | |
| 308 | 3-368-436-01 | SPRING (#1 GUIDE), COMPRESSION | |
| 309 | X-3337-643-1 | GUIDE (RIC) ASSY, ROLLER | |
| 310 | X-3363-025-1 | PINCH (LEVER) ASSY | |
| 311 | 3-315-384-31 | WASHER, STOPPER | |
| 312 | 3-368-398-01 | BUSHING | |
| * 313 | A-2003-708-A | SLIDER ASSY, CAM | |
| 314 | 3-372-761-01 | SCREW (M1.7X4), TAPPING | |
| 315 | 3-368-427-01 | LEVER (LOAD-T) | |
| 316 | 3-368-426-01 | LEVER (LOAD-S) | |
| 317 | 3-368-444-01 | GEAR (LOAD-T) | |
| 318 | 3-368-443-01 | GEAR (LOAD-S) | |
| 319 | 3-368-415-01 | SHAFT (LOAD LEVER JOINT) | |
| * 321 | 1-639-305-11 | TOP END SENSOR BOARD | |
| * 323 | 1-639-301-11 | RGN SW BOARD | |
| * 324 | 1-639-306-11 | CAM SLIDER BOARD | |
| 325 | 8-848-567-11 | DRUM ASSY DOU-03A | |
| 326 | 9-911-835-XX | SPACER | |
| * 327 | A-2001-587-A | RF COMPLETE ASSY | |
| 328 | 3-368-459-01 | LEVER (CLEANER) | |
| 329 | 3-353-812-01 | COLLAR (ROLLER) | |
| 330 | 3-352-518-01 | ROLLER (CLEANER) | |
| * 331 | A-2056-488-A | DRUM DRIVE BOARD, COMPLETE | |
| 332 | 3-337-626-01 | CAP, PINCH ROLLER | |
| 333 | X-3337-655-1 | ROLLER (CLEANER) ASSY | |
| 334 | 3-321-813-01 | WASHER, COTTER POLYETHYLENE | |
| 336 | 3-337-677-01 | FLANGE | |
| 337 | 3-337-676-01 | GUIDE, FIXED | |
| M902 | 8-835-361-01 | MOTOR, DC U-17B (CAPSTAN) | |

## 5-7. MECHANISM SECTION 4 (DATM-102)




| Ref. No. | Part No. | Description | Remarks |
|---|---|---|---|
| * 351 | A-2003-857-A | CHASSIS (REEL) ASSY | |
| * 352 | 3-368-420-01 | SHAFT (CAM DRIVE GEAR C) | |
| * 353 | 3-368-419-01 | SHAFT (CAM DRIVE GEAR D) | |
| * 354 | 3-368-455-01 | LEVER (GEAR LOCK) | |
| 355 | 3-368-418-01 | TUBE (BREAK) | |
| 356 | 3-368-398-01 | BUSHING | |
| 357 | 3-368-430-01 | SPRING (GEAR LOCK) | |
| 358 | X-3363-022-1 | GEAR (REEL DRIVE) ASSY | |
| * 359 | 3-368-411-01 | SLIDER (REEL LOCK) | |
| * 360 | 3-368-453-01 | LEVER (BRAKE SOLENOID) | |
| * 361 | 3-368-447-01 | LEVER (BRAKE S) | |
| * 362 | 3-368-446-01 | LEVER (BRAKE T) | |
| 363 | 3-368-438-01 | SPRING (BREAK), TENSION | |
| 364 | 3-368-432-01 | SPRING (FF/REW), COMPRESSION | |
| 365 | A-2003-709-A | TABLE (S) ASSY, REEL | |
| 366 | A-2003-710-B | TABLE (T) ASSY, REEL | |
| 367 | 3-578-224-00 | WASHER | |
| 368 | 3-368-435-01 | SPRING (FR LEVER), COMPRESSION | |
| 369 | X-3364-581-1 | LEVER (F/R) ASSY | |
| 370 | 3-315-384-31 | WASHER, STOPPER | |
| 371 | 3-377-332-01 | TUBE (BREAK2) | |
| 375 | 3-368-421-01 | GEAR (CAM DRIVE C) | |
| 376 | 3-373-039-01 | GEAR (CAM DRIVE B) | |
| 377 | 3-368-403-01 | GEAR (CAM DRIVE D) | |
| 378 | 3-368-402-01 | GEAR (CAM DRIVE A, B) | |
| 379 | X-3363-024-1 | LEVER (BT) ASSY | |
| * 380 | 3-368-451-01 | LEVER (BT SOLENOID) | |
| * 381 | 3-368-454-01 | LEVER (BT SELECTION) | |
| * 384 | 3-368-416-01 | BRACKET (B.T SOLENOID) | |
| 385 | 3-368-423-01 | SCREW (M2.6), STEP | |
| 386 | 2-623-736-01 | CLAW (C) (LEFT), REEL | |
| 387 | 2-623-752-01 | CLAW (C) (RIGHT), REEL | |
| 390 | 3-368-431-01 | SPRING (B.T SOLENOID) | |
| 391 | 3-368-417-01 | BELT (170TN10-1.0T), TIMING | |
| * 392 | 1-639-303-11 | CAM MOTOR BOARD | |
| * 393 | 1-639-304-11 | REEL MOTOR BOARD | |
| 394 | 3-738-212-21 | RETAINER, THRUST REEL TABLE | |
| 395 | 3-701-443-11 | WASHER | |
| 396 | 3-701-443-21 | WASHER, 5 DIA. | |
| 397 | 2-623-756-01 | SCREW, (B1.7X3), TAPPING | |
| 398 | 3-701-436-01 | WASHER, 1.6 | |
| 399 | 3-370-480-01 | SPRING (BT), COMPRESSION | |
| M903 | X-3363-109-1 | MOTOR (CAM) ASSY | |
| M905 | X-3363-110-1 | MOTOR (REEL) ASSY | |
| PM902 | 1-454-536-11 | SOLENOID, PLUNGER (BT CONTROL) | |
| PM903 | 1-454-535-11 | SOLENOID, PLUNGER (BRAKE) | |

# SECTION 6
# ELECTRICAL PARTS LIST

**NOTE:**

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque ⚠ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board name.

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX, -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS
  All resistors are in ohms
  METAL : Metal-film resistor
  METAL OXIDE : Metal Oxide-film resistor
  F : nonflammable
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS
  In each case, u : μ, for example :
  uA...: μA..., uPA...: μPA...,
  uPB...: μPB..., uPC...: μPC...,
  uPD...: μPD...
- CAPACITORS
  uF : μF
- COILS
  uH : μH

## BATTERY

| Ref. No. | Part No. | Description | Remarks |
|---|---|---|---|
| * | 1-645-242-11 | BATTERY BOARD | |
| | | ********** | |
| | | < BATTERY > | |
| ⚠BAT301 | 1-528-229-11 | BATTERY, LITHIUM (CR-2450) | |
| | | < CONNECTOR > | |
| * CN371 | 1-564-337-00 | PIN, CONNECTOR 3P (US, Canadian) | |
| * CN381 | 1-564-705-11 | PIN, CONNECTOR (SMALL TYPE) 3P (US, Canadian) | |

**********

## CAM MOTOR

| Ref. No. | Part No. | Description | Remarks |
|---|---|---|---|
| * | 1-639-303-11 | CAM MOTOR BOARD | |
| | | ********** | |
| | | < CAPACITOR > | |
| C06 | 1-163-077-00 | CERAMIC CHIP 0.1uF 10% 25V | |

**********

## CAM SLIDER

| Ref. No. | Part No. | Description | Remarks |
|---|---|---|---|
| * | 1-639-306-11 | CAM SLIDER BOARD | |
| | | ********** | |
| | | < JUMPER RESISTOR > | |
| JW04 | 1-216-296-00 | METAL CHIP 0 5% 1/8W | |
| JW05 | 1-216-296-00 | METAL CHIP 0 5% 1/8W | |
| | | < SWITCH > | |
| SW1 | 1-570-953-11 | SWITCH, PUSH (1 KEY) (STOP DET) | |
| SW2 | 1-570-953-11 | SWITCH, PUSH (1 KEY) (FWD DET) | |

**********

## CONTROL (S)

| Ref. No. | Part No. | Description | Remarks |
|---|---|---|---|
| * | 1-645-237-11 | CONTROL (S) BOARD (US, Canadian) | |
| | | ********** | |
| | 4-870-539-00 | PLATE, GROUND (US, Canadian) | |
| | | < CAPACITOR > | |
| C801 | 1-164-159-11 | CERAMIC 0.1uF | 50V (US, Canadian) |
| C802 | 1-164-159-11 | CERAMIC 0.1uF | 50V (US, Canadian) |
| | | < CONNECTOR > | |
| CN801 | 1-558-350-21 | CORD (WITH CONNECTOR) (US, Canadian) | |
| * CN831 | 1-564-705-11 | PIN, CONNECTOR (SMALL TYPE) 3P (US, Canadian) | |
| | | < DIODE > | |
| D801 | 8-719-107-94 | DIODE 1SS202-1 (US, Canadian) | |
| D802 | 8-719-107-94 | DIODE 1SS202-1 (US, Canadian) | |
| | | < RESISTOR > | |
| R801 | 1-249-393-11 | CARBON 10 5% 1/4W | (US, Canadian) |
| R802 | 1-249-429-11 | CARBON 10K 5% 1/4W | (US, Canadian) |
| R803 | 1-249-429-11 | CARBON 10K 5% 1/4W | (US, Canadian) |
| R804 | 1-249-405-11 | CARBON 100 5% 1/4W | (US, Canadian) |
| R805 | 1-249-429-11 | CARBON 10K 5% 1/4W | (US, Canadian) |
| R806 | 1-249-429-11 | CARBON 10K 5% 1/4W | (US, Canadian) |

**********

## CONTROL SW

| Ref. No. | Part No. | Description | Remarks |
|---|---|---|---|
| * | A-2006-865-A | CONTROL SW BOARD, COMPLETE (US, Canadian) | |
| * | A-2006-811-A | CONTROL SW BOARD, COMPLETE (AEP, E) | |
| | | ********** | |
| | | < CAPACITOR > | |
| C701 | 1-161-379-00 | CERAMIC 0.01uF 20% 25V | |
| C702 | 1-161-379-00 | CERAMIC 0.01uF 20% 25V | |
| C703 | 1-124-584-00 | ELECT 100uF 20% 10V | |
| C704 | 1-161-379-00 | CERAMIC 0.01uF 20% 25V | |
| C705 | 1-161-379-00 | CERAMIC 0.01uF 20% 25V | |
| C706 | 1-161-379-00 | CERAMIC 0.01uF 20% 25V | |
| | | < CONNECTOR > | |
| CN751 | 1-568-853-11 | SOCKET, CONNECTOR 10P | |
| CN752 | 1-568-849-11 | SOCKET, CONNECTOR 6P | |
| * CN771 | 1-564-337-00 | PIN, CONNECTOR 3P | |
| | | < CONPOSITION CIRCUIT BLOCK > | |
| CP701 | 1-233-140-11 | COMPOSITION CIRCUIT BLOCK (100k X 8) | |
| CP702 | 1-233-140-11 | COMPOSITION CIRCUIT BLOCK (100k X 8) | |

# CONTROL SW

| Ref.No. | Part No. | Description | Remarks |
|---|---|---|---|
| CP703 | 1-233-140-11 | COMPOSITION CIRCUIT BLOCK (100k X 8) | |
| CP704 | 1-233-140-11 | COMPOSITION CIRCUIT BLOCK (100k X 8) | |
| | | < FLUORESCENT INDICATOR > | |
| FL701 | 1-519-672-21 | INDICATOR TUBE, FLUORESCENT | |
| | | < IC > | |
| IC701 | 8-752-837-19 | IC CXP5058H-659Q | |
| IC702 | 8-759-995-09 | IC MSM6338RS | |
| IC703 | 8-752-330-59 | IC CXK1011P | |
| IC704 | 8-749-922-36 | IC GP1U50XB | |
| IC705 | 8-759-140-11 | IC uPD4011BC (US, Canadian) | |
| | | < TRANSISTOR > | |
| Q701 | 8-729-902-11 | TRANSISTOR 2SC2021-Q | |
| Q702 | 8-729-902-11 | TRANSISTOR 2SC2021-Q | |
| Q703 | 8-729-902-11 | TRANSISTOR 2SC2021-Q | |
| | | < RESISTOR > | |
| R701 | 1-249-441-11 | CARBON 100K 5% 1/4W | |
| R702 | 1-249-441-11 | CARBON 100K 5% 1/4W | |
| R703 | 1-249-441-11 | CARBON 100K 5% 1/4W | |
| R708 | 1-249-429-11 | CARBON 10K 5% 1/4W | |
| R709 | 1-249-422-11 | CARBON 2.7K 5% 1/4W | |
| R710 | 1-249-424-11 | CARBON 3.9K 5% 1/4W | |
| R711 | 1-249-427-11 | CARBON 6.8K 5% 1/4W | |
| R712 | 1-249-432-11 | CARBON 18K 5% 1/4W | |
| R713 | 1-249-429-11 | CARBON 10K 5% 1/4W | |
| R714 | 1-249-422-11 | CARBON 2.7K 5% 1/4W | |
| R715 | 1-249-424-11 | CARBON 3.9K 5% 1/4W | |
| R716 | 1-249-429-11 | CARBON 10K 5% 1/4W | |
| R717 | 1-249-422-11 | CARBON 2.7K 5% 1/4W | |
| R718 | 1-249-424-11 | CARBON 3.9K 5% 1/4W | |
| R719 | 1-249-427-11 | CARBON 6.8K 5% 1/4W | |
| R720 | 1-249-432-11 | CARBON 18K 5% 1/4W | |
| R721 | 1-249-429-11 | CARBON 10K 5% 1/4W | |
| R722 | 1-249-422-11 | CARBON 2.7K 5% 1/4W | |
| R723 | 1-249-424-11 | CARBON 3.9K 5% 1/4W | |
| R724 | 1-249-427-11 | CARBON 6.8K 5% 1/4W | |
| R725 | 1-249-432-11 | CARBON 18K 5% 1/4W | |
| R726 | 1-249-429-11 | CARBON 10K 5% 1/4W | |
| R727 | 1-249-422-11 | CARBON 2.7K 5% 1/4W | |
| R728 | 1-249-424-11 | CARBON 3.9K 5% 1/4W | |
| R729 | 1-249-427-11 | CARBON 6.8K 5% 1/4W | |
| R730 | 1-249-432-11 | CARBON 18K 5% 1/4W | |
| R731 | 1-249-429-11 | CARBON 10K 5% 1/4W | |
| R732 | 1-249-422-11 | CARBON 2.7K 5% 1/4W | |
| R733 | 1-249-424-11 | CARBON 3.9K 5% 1/4W | |
| R734 | 1-249-429-11 | CARBON 10K 5% 1/4W | |
| R735 | 1-249-422-11 | CARBON 2.7K 5% 1/4W | |
| R736 | 1-249-424-11 | CARBON 3.9K 5% 1/4W | |
| R737 | 1-249-427-11 | CARBON 6.8K 5% 1/4W | |
| R738 | 1-249-432-11 | CARBON 18K 5% 1/4W | |
| R739 | 1-249-429-11 | CARBON 10K 5% 1/4W | |
| R740 | 1-249-422-11 | CARBON 2.7K 5% 1/4W | |
| R741 | 1-249-424-11 | CARBON 3.9K 5% 1/4W | |
| R742 | 1-249-427-11 | CARBON 6.8K 5% 1/4W | |
| R743 | 1-249-432-11 | CARBON 18K 5% 1/4W | |
| R744 | 1-249-437-11 | CARBON 47K 5% 1/4W | |
| R745 | 1-249-437-11 | CARBON 47K 5% 1/4W | |
| R746 | 1-249-437-11 | CARBON 47K 5% 1/4W | |
| R747 | 1-249-437-11 | CARBON 47K 5% 1/4W | |
| R748 | 1-249-437-11 | CARBON 47K 5% 1/4W | |
| R749 | 1-249-437-11 | CARBON 47K 5% 1/4W | |
| R750 | 1-249-437-11 | CARBON 47K 5% 1/4W | |
| R751 | 1-249-437-11 | CARBON 47K 5% 1/4W | |
| R752 | 1-249-437-11 | CARBON 47K 5% 1/4W | |
| R753 | 1-249-437-11 | CARBON 47K 5% 1/4W | |
| R754 | 1-249-437-11 | CARBON 47K 5% 1/4W | |
| R755 | 1-249-437-11 | CARBON 47K 5% 1/4W | |
| R756 | 1-249-437-11 | CARBON 47K 5% 1/4W | (AEP, E) |
| R757 | 1-249-437-11 | CARBON 47K 5% 1/4W | (US, Canadian) |
| R758 | 1-249-409-11 | CARBON 220 5% 1/4W | |
| | | < SWITCH > | |
| S704 | 1-554-937-11 | SWITCH, KEY BOARD (MODE) | |
| S705 | 1-570-974-11 | SWITCH, SLIDE (REC MODE) | |
| S706 | 1-554-937-11 | SWITCH, KEY BOARD (1) | |
| S707 | 1-554-937-11 | SWITCH, KEY BOARD (2) | |
| S708 | 1-554-937-11 | SWITCH, KEY BOARD (3) | |
| S709 | 1-554-937-11 | SWITCH, KEY BOARD (4) | |
| S710 | 1-554-937-11 | SWITCH, KEY BOARD (5) | |
| S711 | 1-554-937-11 | SWITCH, KEY BOARD (6) | |
| S712 | 1-554-937-11 | SWITCH, KEY BOARD (7) | |
| S713 | 1-554-937-11 | SWITCH, KEY BOARD (8) | |
| S714 | 1-554-937-11 | SWITCH, KEY BOARD (9) | |
| S715 | 1-554-937-11 | SWITCH, KEY BOARD (0) | |
| S716 | 1-554-937-11 | SWITCH, KEY BOARD (FADER) | |
| S717 | 1-554-937-11 | SWITCH, KEY BOARD (MUSIC SCAN) | |
| S718 | 1-554-937-11 | SWITCH, KEY BOARD (MARGIN RESET) | |
| S719 | 1-554-937-11 | SWITCH, KEY BOARD (CLEAR) | |
| S720 | 1-554-937-11 | SWITCH, KEY BOARD (DATE RECORDED) | |
| S721 | 1-554-937-11 | SWITCH, KEY BOARD (DATE PRESENT) | |
| S722 | 1-554-937-11 | SWITCH, KEY BOARD (DATE CLOCK SET) | |
| S723 | 1-554-937-11 | SWITCH, KEY BOARD (AUTO) | |
| S724 | 1-554-937-11 | SWITCH, KEY BOARD (RENUMBER) | |
| S725 | 1-554-937-11 | SWITCH, KEY BOARD (WRITE START ID) | |
| S726 | 1-554-937-11 | SWITCH, KEY BOARD (WRITE SKIP ID) | |
| S727 | 1-554-937-11 | SWITCH, KEY BOARD (WRITE END ID) | |
| S728 | 1-554-937-11 | SWITCH, KEY BOARD (ERASE START ID) | |

When indicating parts by reference number, please include the board name.

# CONTROL SW DRUM DRIVE

| Ref.No. | Part No. | Description | Remarks |
|---|---|---|---|
| S729 | 1-554-937-11 | SWITCH, KEY BOARD (ERASE SKIP ID) | |
| S730 | 1-554-937-11 | SWITCH, KEY BOARD (ERASE END ID) | |
| S731 | 1-554-937-11 | SWITCH, KEY BOARD ( ■ ) | |
| S732 | 1-554-937-11 | SWITCH, KEY BOARD ( ▶ ) | |
| S733 | 1-554-937-11 | SWITCH, KEY BOARD (AMS ▯◁◁ ) | |
| S734 | 1-554-937-11 | SWITCH, KEY BOARD (AMS ▷▷▯ ) | |
| S735 | 1-554-937-11 | SWITCH, KEY BOARD ( ◀◀ ) | |
| S736 | 1-554-937-11 | SWITCH, KEY BOARD ( ▶▶ ) | |
| S737 | 1-554-937-11 | SWITCH, KEY BOARD ( ● REC) | |
| S738 | 1-554-937-11 | SWITCH, KEY BOARD ( ▮▮ PAUSE) | |
| S739 | 1-554-937-11 | SWITCH, KEY BOARD ( ○ REC MUTE) | |
| | | < VIBRATOR > | |
| X701 | 1-577-359-21 | VIBRATOR, CERAMIC (4.19MHz) | |
| ********** | | | |
| * | A-2056-488-A | DRUM DRIVE BOARD, COMPLETE | |
| | | ********** | |
| * | 3-343-491-01 | HOLDER (S SENSOR B) | |
| | 4-870-539-00 | PLATE, GROUND | |
| | | < CAPACITOR > | |
| C01 | 1-126-176-11 | ELECT 220uF 20% 10V | |
| C02 | 1-126-157-11 | ELECT 10uF 20% 16V | |
| C03 | 1-124-257-00 | ELECT 2.2uF 20% 50V | |
| C04 | 1-164-161-11 | CERAMIC CHIP 0.0022uF 10% 100V | |
| C05 | 1-164-161-11 | CERAMIC CHIP 0.0022uF 10% 100V | |
| C08 | 1-163-001-11 | CERAMIC CHIP 220PF 10% 50V | |
| C21 | 1-163-001-11 | CERAMIC CHIP 220PF 10% 50V | |
| C31 | 1-163-001-11 | CERAMIC CHIP 220PF 10% 50V | |
| | | < CONNECTOR > | |
| * CN01 | 1-564-704-11 | PIN, CONNECTOR (SMALL TYPE) 2P | |
| * CN02 | 1-564-704-11 | PIN, CONNECTOR (SMALL TYPE) 2P | |
| * CN03 | 1-564-338-00 | PIN, CONNECTOR 4P | |
| * CN04 | 1-564-336-00 | PIN, CONNECTOR 2P | |
| * CN05 | 1-564-336-61 | PIN, CONNECTOR 2P | |
| * CN06 | 1-564-339-00 | PIN, CONNECTOR 5P | |
| CN07 | 1-564-721-11 | PIN, CONNECTOR (SMALL TYPE) 5P | |
| * CN08 | 1-568-872-11 | SOCKET, CONNECTOR 30P | |
| * CN09 | 1-564-706-11 | PIN, CONNECTOR (SMALL TYPE) 4P | |
| * CN10 | 1-564-719-11 | PIN, CONNECTOR (SMALL TYPE) 3P | |
| | | < IC > | |
| IC01 | 8-759-107-68 | IC CX20115A | |
| IC02 | 8-759-502-80 | IC LM358M | |
| IC03 | 8-759-502-80 | IC LM358M | |
| | | < JUMPER RESISTOR > | |
| JW06 | 1-216-296-00 | METAL CHIP 0 5% 1/8W | |
| JW07 | 1-216-296-00 | METAL CHIP 0 5% 1/8W | |
| JW08 | 1-216-296-00 | METAL CHIP 0 5% 1/8W | |
| JW09 | 1-216-296-00 | METAL CHIP 0 5% 1/8W | |
| JW10 | 1-216-296-00 | METAL CHIP 0 5% 1/8W | |
| JW11 | 1-216-296-00 | METAL CHIP 0 5% 1/8W | |
| JW12 | 1-216-296-00 | METAL CHIP 0 5% 1/8W | |
| JW13 | 1-216-296-00 | METAL CHIP 0 5% 1/8W | |
| JW14 | 1-216-296-00 | METAL CHIP 0 5% 1/8W | |
| JW15 | 1-216-296-00 | METAL CHIP 0 5% 1/8W | |
| JW16 | 1-216-296-00 | METAL CHIP 0 5% 1/8W | |
| JW17 | 1-216-296-00 | METAL CHIP 0 5% 1/8W | |
| JW18 | 1-216-296-00 | METAL CHIP 0 5% 1/8W | |
| JW19 | 1-216-296-00 | METAL CHIP 0 5% 1/8W | |
| JW20 | 1-216-296-00 | METAL CHIP 0 5% 1/8W | |
| JW21 | 1-216-296-00 | METAL CHIP 0 5% 1/8W | |
| JW22 | 1-216-296-00 | METAL CHIP 0 5% 1/8W | |
| JW23 | 1-216-296-00 | METAL CHIP 0 5% 1/8W | |
| JW24 | 1-216-296-00 | METAL CHIP 0 5% 1/8W | |
| JW25 | 1-216-296-00 | METAL CHIP 0 5% 1/8W | |
| JW26 | 1-216-296-00 | METAL CHIP 0 5% 1/8W | |
| JW27 | 1-216-296-00 | METAL CHIP 0 5% 1/8W | |
| JW28 | 1-216-296-00 | METAL CHIP 0 5% 1/8W | |
| JW29 | 1-216-296-00 | METAL CHIP 0 5% 1/8W | |
| JW30 | 1-216-296-00 | METAL CHIP 0 5% 1/8W | |
| | | < PHOTO INTERUPTER > | |
| PH01 | 8-719-939-23 | DIODE GP2S09-C | |
| PH02 | 8-719-939-23 | DIODE GP2S09-C | |
| | | < TRANSISTOR > | |
| Q01 | 8-729-120-28 | TRANSISTOR 2SC1623-L5L6 | |
| Q02 | 8-729-101-07 | TRANSISTOR 2SB798-DL | |
| | | < RESISTOR > | |
| R01 | 1-216-061-00 | METAL CHIP 3.3K 5% 1/10W | |
| R02 | 1-216-075-00 | METAL CHIP 12K 5% 1/10W | |
| R03 | 1-216-029-00 | METAL CHIP 150 5% 1/10W | |
| R04 | 1-216-059-00 | METAL CHIP 2.7K 5% 1/10W | |
| R05 | 1-216-057-00 | METAL CHIP 2.2K 5% 1/10W | |
| R06 | 1-216-085-00 | METAL CHIP 33K 5% 1/10W | |
| R07 | 1-216-025-00 | METAL CHIP 100 5% 1/10W | |
| R08 | 1-216-049-00 | METAL CHIP 1K 5% 1/10W | |
| R09 | 1-216-073-00 | METAL CHIP 10K 5% 1/10W | |
| R10 | 1-216-073-00 | METAL CHIP 10K 5% 1/10W | |
| R11 | 1-216-073-00 | METAL CHIP 10K 5% 1/10W | |
| R12 | 1-216-089-00 | METAL CHIP 47K 5% 1/10W | |
| R13 | 1-216-073-00 | METAL CHIP 10K 5% 1/10W | |
| R14 | 1-216-037-00 | METAL CHIP 330 5% 1/10W | |
| R21 | 1-216-073-00 | METAL CHIP 10K 5% 1/10W | |
| R22 | 1-216-081-00 | METAL CHIP 22K 5% 1/10W | |

When indicating parts by reference number, please include the board name.

# DRUM DRIVE | HEADPHONE JACK | HEADPHONE VOL | INPUT SW | LED | MAIN

| Ref.No. | Part No. | Description | | | Remarks |
|---|---|---|---|---|---|
| R23 | 1-216-077-00 | METAL CHIP | 15K | 5% | 1/10W |
| R24 | 1-216-067-00 | METAL CHIP | 5.6K | 5% | 1/10W |
| R25 | 1-216-103-00 | METAL CHIP | 180K | 5% | 1/10W |
| R26 | 1-216-065-00 | METAL CHIP | 4.7K | 5% | 1/10W |
| R31 | 1-216-073-00 | METAL CHIP | 10K | 5% | 1/10W |
| R32 | 1-216-081-00 | METAL CHIP | 22K | 5% | 1/10W |
| R35 | 1-216-103-00 | METAL CHIP | 180K | 5% | 1/10W |
| R36 | 1-216-065-00 | METAL CHIP | 4.7K | 5% | 1/10W |
| ********** | | | | | |
| * | 1-645-244-11 | HEADPHONE JACK BOARD | | | |
| | | ********** | | | |
| | | < CAPACITOR > | | | |
| C180 | 1-162-290-31 | CERAMIC | 470PF | 10% | 50V |
| C280 | 1-162-290-31 | CERAMIC | 470PF | 10% | 50V |
| C451 | 1-126-024-21 | ELECT | 220uF | 20% | 25V |
| C452 | 1-126-024-21 | ELECT | 220uF | 20% | 25V |
| | | < IC > | | | |
| IC401 | 8-759-634-50 | IC M5218AL | | | |
| | | < JACK > | | | |
| J161 | 1-565-327-11 | JACK, LARGE TYPE 1P (PHONES) | | | |
| | | < COIL > | | | |
| L180 | 1-236-163-11 | ENCAPSULATED COMPONENT | | | |
| L280 | 1-236-163-11 | ENCAPSULATED COMPONENT | | | |
| | | < RESISTOR > | | | |
| R128 | 1-259-468-11 | CARBON | 47K | 5% | 1/6W |
| R129 | 1-259-444-11 | CARBON | 4.7K | 5% | 1/6W |
| R130 | 1-259-468-11 | CARBON | 47K | 5% | 1/6W |
| R131 | 1-259-412-11 | CARBON | 220 | 5% | 1/6W |
| R228 | 1-259-468-11 | CARBON | 47K | 5% | 1/6W |
| R229 | 1-259-444-11 | CARBON | 4.7K | 5% | 1/6W |
| R230 | 1-259-468-11 | CARBON | 47K | 5% | 1/6W |
| R231 | 1-259-412-11 | CARBON | 220 | 5% | 1/6W |
| ********** | | | | | |
| * | 1-645-245-11 | HEADPHONE VOL BOARD | | | |
| | | ********** | | | |
| | | < VARIABLE RESISTOR > | | | |
| RV102 | 1-241-537-11 | RES, VAR, CARBON 20K/20K (LEVEL) | | | |
| ********** | | | | | |

| Ref.No. | Part No. | Description | | | Remarks |
|---|---|---|---|---|---|
| * | 1-645-240-11 | INPUT SW BOARD | | | |
| | | ********** | | | |
| | | < CONNECTOR > | | | |
| * CN772 | 1-564-336-00 | PIN, CONNECTOR 2P | | | |
| | | < RESISTOR > | | | |
| R706 | 1-249-427-11 | CARBON | 6.8K | 5% | 1/4W |
| R707 | 1-249-432-11 | CARBON | 18K | 5% | 1/4W |
| | | < SWITCH > | | | |
| S703 | 1-572-758-11 | SWITCH, ROTARY (INPUT) | | | |
| ********** | | | | | |
| * | 1-645-241-11 | LED BOARD | | | |
| | | ********* | | | |
| | | < DIODE > | | | |
| D701 | 8-719-421-98 | DIODE LN01401C(Q)-3-LF | | | |
| D702 | 8-719-421-98 | DIODE LN01401C(Q)-3-LF | | | |
| ********** | | | | | |
| * | A-2006-866-A | MAIN BOARD, COMPLETE (US, Canadian, E) | | | |
| * | A-2006-863-A | MAIN BOARD, COMPLETE (AEP) | | | |
| | | ********** | | | |
| | | < CAPACITOR > | | | |
| C102 | 1-126-233-11 | ELECT | 22uF | 20% | 50V |
| C103 | 1-136-153-00 | FILM | 0.01uF | 5% | 50V |
| C104 | 1-126-059-11 | ELECT | 10uF | 20% | 63V |
| C106 | 1-136-153-00 | FILM | 0.01uF | 5% | 50V |
| C110 | 1-136-275-91 | FILM | 390PF | 5% | 630V |
| C112 | 1-136-437-11 | FILM | 220PF | 5% | 630V |
| C113 | 1-136-437-11 | FILM | 220PF | 5% | 630V |
| C114 | 1-136-433-11 | FILM | 100PF | 5% | 630V |
| C115 | 1-136-433-11 | FILM | 100PF | 5% | 630V |
| C116 | 1-130-475-00 | MYLAR | 0.0022uF | 5% | 50V |
| C117 | 1-130-471-00 | MYLAR | 0.001uF | 5% | 50V |
| C118 | 1-130-478-00 | MYLAR | 0.0039uF | 5% | 50V |
| C120 | 1-126-023-11 | ELECT | 100uF | 20% | 25V |
| C202 | 1-126-233-11 | ELECT | 22uF | 20% | 50V |
| C203 | 1-136-153-00 | FILM | 0.01uF | 5% | 50V |
| C206 | 1-136-153-00 | FILM | 0.01uF | 5% | 50V |
| C210 | 1-136-275-91 | FILM | 390PF | 5% | 630V |
| C212 | 1-136-437-11 | FILM | 220PF | 5% | 630V |
| C213 | 1-136-437-11 | FILM | 220PF | 5% | 630V |
| C214 | 1-136-433-11 | FILM | 100PF | 5% | 630V |
| C215 | 1-136-433-11 | FILM | 100PF | 5% | 630V |
| C216 | 1-130-475-00 | MYLAR | 0.0022uF | 5% | 50V |
| C217 | 1-130-471-00 | MYLAR | 0.001uF | 5% | 50V |

When indicating parts by reference number, please include the board name.

# MAIN

| Ref.No. | Part No. | Description | | | Remarks |
|---|---|---|---|---|---|
| C218 | 1-130-478-00 | MYLAR | 0.0039uF | 5% | 50V |
| C220 | 1-126-023-11 | ELECT | 100uF | 20% | 25V |
| C300 | 1-162-294-31 | CERAMIC | 0.001uF | 10% | 50V |
| C301 | 1-130-834-00 | FILM | 1uF | 10% | 63V |
| C302 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V |
| C303 | 1-162-211-31 | CERAMIC | 33PF | 5% | 50V |
| C304 | 1-126-059-11 | ELECT | 10uF | 20% | 63V |
| C305 | 1-136-153-00 | FILM | 0.01uF | 5% | 50V |
| C306 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V |
| C307 | 1-126-022-11 | ELECT | 47uF | 20% | 10V |
| C308 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V |
| C309 | 1-124-983-11 | ELECT | 330uF | 20% | 6.3V |
| C310 | 1-130-834-00 | FILM | 1uF | 10% | 63V |
| C311 | 1-162-279-31 | CERAMIC | 75PF | 10% | 50V |
| C312 | 1-126-022-11 | ELECT | 47uF | 20% | 10V |
| C313 | 1-126-023-11 | ELECT | 100uF | 20% | 25V |
| C314 | 1-162-199-31 | CERAMIC | 10PF | 5% | 50V |
| C315 | 1-162-294-31 | CERAMIC | 0.001uF | 10% | 50V |
| C316 | 1-162-199-31 | CERAMIC | 10PF | 5% | 50V |
| C317 | 1-162-201-31 | CERAMIC | 12PF | 5% | 50V |
| C318 | 1-162-201-31 | CERAMIC | 12PF | 5% | 50V |
| C319 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V |
| C320 | 1-130-834-00 | FILM | 1uF | 10% | 63V |
| C321 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V |
| C322 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V |
| C323 | 1-162-206-31 | CERAMIC | 20PF | 5% | 50V |
| C324 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V |
| C325 | 1-126-022-11 | ELECT | 47uF | 20% | 10V |
| C326 | 1-162-201-31 | CERAMIC | 12PF | 5% | 50V |
| C327 | 1-162-201-31 | CERAMIC | 12PF | 5% | 50V |
| C328 | 1-124-903-11 | ELECT | 1uF | 20% | 50V |
| C329 | 1-162-294-31 | CERAMIC | 0.001uF | 10% | 50V |
| C330 | 1-162-294-31 | CERAMIC | 0.001uF | 10% | 50V |
| C331 | 1-162-294-31 | CERAMIC | 0.001uF | 10% | 50V |
| C332 | 1-162-293-31 | CERAMIC | 820PF | 10% | 50V |
| C333 | 1-162-283-31 | CERAMIC | 120PF | 10% | 50V |
| C334 | 1-161-375-00 | CERAMIC | 0.0022uF | 20% | 50V |
| C335 | 1-161-375-00 | CERAMIC | 0.0022uF | 20% | 50V |
| C336 | 1-162-289-31 | CERAMIC | 390PF | 10% | 50V |
| C337 | 1-161-329-00 | CERAMIC | 0.0068uF | 30% | 16V |
| C338 | 1-162-306-11 | CERAMIC | 0.01uF | 20% | 16V |
| C339 | 1-162-306-11 | CERAMIC | 0.01uF | 20% | 16V |
| C340 | 1-162-290-31 | CERAMIC | 470PF | 10% | 50V |
| C341 | 1-162-306-11 | CERAMIC | 0.01uF | 20% | 16V |
| C342 | 1-126-059-11 | ELECT | 10uF | 20% | 63V |
| C343 | 1-162-306-11 | CERAMIC | 0.01uF | 20% | 16V |
| C344 | 1-162-306-11 | CERAMIC | 0.01uF | 20% | 16V |
| C345 | 1-162-209-31 | CERAMIC | 27PF | 5% | 50V |
| C346 | 1-162-205-31 | CERAMIC | 18PF | 5% | 50V |
| C347 | 1-162-294-31 | CERAMIC | 0.001uF | 10% | 50V |
| C348 | 1-126-059-11 | ELECT | 10uF | 20% | 63V |
| C362 | 1-126-043-11 | ELECT | 0.47uF | 20% | 50V |
| C363 | 1-126-059-11 | ELECT | 10uF | 20% | 63V |
| C401 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V |
| C402 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V |
| C405 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V |
| C406 | 1-126-059-11 | ELECT | 10uF | 20% | 63V |
| C407 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V |
| C408 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V |
| C409 | 1-126-104-11 | ELECT | 470uF | 20% | 35V |
| C410 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V |
| C411 | 1-126-104-11 | ELECT | 470uF | 20% | 35V |
| C412 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V |
| C413 | 1-126-104-11 | ELECT | 470uF | 20% | 35V |
| C414 | 1-126-104-11 | ELECT | 470uF | 20% | 35V |
| C415 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V |
| C417 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V |
| C426 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V |
| C427 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V |
| C428 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V |
| C429 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V |
| C430 | 1-126-059-11 | ELECT | 10uF | 20% | 63V |
| C431 | 1-126-059-11 | ELECT | 10uF | 20% | 63V |
| C432 | 1-124-273-00 | ELECT | 3.3uF | 20% | 50V |
| C438 | 1-124-983-11 | ELECT | 330uF | 20% | 6.3V |
| C439 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V |
| C440 | 1-126-916-11 | ELECT | 1000uF | 20% | 6.3V |
| C441 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V |
| C442 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V |
| C444 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V |
| C445 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V |
| C446 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V |
| C447 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V |
| C448 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V |
| C449 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V |
| C450 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V |
| C451 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V |
| C460 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V |
| C461 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V |
| C462 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V |
| C470 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V |
| C471 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V |
| C472 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V |
| C473 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V |
| C499 | 1-162-290-31 | CERAMIC | 470PF | 10% | 50V |
| C501 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V |
| C503 | 1-162-199-31 | CERAMIC | 10PF | 5% | 50V |
| C504 | 1-126-023-11 | ELECT | 100uF | 20% | 25V |
| C505 | 1-162-211-31 | CERAMIC | 33PF | 5% | 50V |
| C506 | 1-162-199-31 | CERAMIC | 10PF | 5% | 50V |

When indicating parts by reference number, please include the board name.

| Ref.No. | Part No. | Description | | | | Remarks |
|---|---|---|---|---|---|---|
| C507 | 1-136-153-00 | FILM | 0.01uF | 5% | 50V | |
| C508 | 1-136-158-00 | FILM | 0.027uF | 5% | 50V | |
| C509 | 1-126-023-11 | ELECT | 100uF | 20% | 25V | |
| C511 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V | |
| C512 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V | |
| C513 | 1-126-023-11 | ELECT | 100uF | 20% | 25V | |
| C514 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V | |
| C515 | 1-136-169-00 | FILM | 0.22uF | 5% | 50V | |
| C516 | 1-136-158-00 | FILM | 0.027uF | 5% | 50V | |
| C517 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V | |
| C555 | 1-162-179-11 | CERAMIC | 0.1uF | | 50V | |
| C601 | 1-126-023-11 | ELECT | 100uF | 20% | 25V | |
| C602 | 1-126-023-11 | ELECT | 100uF | 20% | 25V | |
| C603 | 1-126-023-11 | ELECT | 100uF | 20% | 25V | |
| C604 | 1-126-023-11 | ELECT | 100uF | 20% | 25V | |
| C605 | 1-126-023-11 | ELECT | 100uF | 20% | 25V | |
| C606 | 1-126-023-11 | ELECT | 100uF | 20% | 25V | |
| C607 | 1-126-023-11 | ELECT | 100uF | 20% | 25V | |
| C608 | 1-126-023-11 | ELECT | 100uF | 20% | 25V | |
| C609 | 1-126-023-11 | ELECT | 100uF | 20% | 25V | |
| C610 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V | |
| C612 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V | |
| C613 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V | |
| C614 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V | |
| C615 | 1-162-179-11 | CERAMIC | 0.1uF | | 50V | |
| C616 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V | |
| C617 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V | |
| C618 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V | |
| C619 | 1-162-179-11 | CERAMIC | 0.1uF | | 50V | |
| C620 | 1-162-179-11 | CERAMIC | 0.1uF | | 50V | |
| C621 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V | |
| C622 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V | |
| C623 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V | |
| C624 | 1-126-023-11 | ELECT | 100uF | 20% | 25V | |
| C630 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V | |
| C631 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V | |
| C632 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V | |
| C633 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V | |
| C634 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V | |
| C635 | 1-162-179-11 | CERAMIC | 0.1uF | | 25V | |
| C636 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V | |
| C637 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V | |
| C638 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V | |
| C639 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V | |
| C640 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V | |
| C641 | 1-126-023-11 | ELECT | 100uF | 20% | 25V | |

< CONNECTOR >

| | | | |
|---|---|---|---|
| CN104 | 1-564-507-11 | PLUG, CONNECTOR 4P | |
| * CN107 | 1-564-509-11 | PLUG, CONNECTOR 6P | |
| * CN301 | 1-564-706-11 | PIN, CONNECTOR (SMALL TYPE) 4P | |
| * CN308 | 1-564-339-00 | PIN, CONNECTOR 5P | |
| * CN333 | 1-564-514-11 | PLUG, CONNECTOR 11P | |
| * CN398 | 1-564-336-00 | PIN, CONNECTOR 2P | |
| * CN501 | 1-564-716-11 | PIN, CONNECTOR (SMALL TYPE)14P | |
| * CN508 | 1-568-933-11 | SOCKET, CONNECTOR 30P | |
| * CN571 | 1-568-829-11 | SOCKET, CONNECTOR 10P | |
| * CN572 | 1-568-825-11 | SOCKET, CONNECTOR 6P | |
| * CN576 | 1-564-336-00 | PIN, CONNECTOR 2P | |

< CONPOSITION CIRCUIT BLOCK >

| | | |
|---|---|---|
| CP601 | 1-233-006-11 | COMPOSITION CIRCUIT BLOCK (100K X 10) |

< DIODE >

| | | | |
|---|---|---|---|
| D101 | 8-719-107-94 | DIODE | 1SS202-1 |
| D102 | 8-719-107-94 | DIODE | 1SS202-1 |
| D201 | 8-719-107-94 | DIODE | 1SS202-1 |
| D202 | 8-719-107-94 | DIODE | 1SS202-1 |
| D306 | 8-719-200-82 | DIODE | 11ES2 |
| D307 | 8-719-107-94 | DIODE | 1SS202-1 |
| D308 | 8-719-107-94 | DIODE | 1SS202-1 |
| D314 | 8-719-200-82 | DIODE | 11ES2 |
| D321 | 8-719-107-94 | DIODE | 1SS202-1 |
| D322 | 8-719-911-06 | DIODE | 1SS106 |
| D324 | 8-719-911-06 | DIODE | 1SS106 |
| D350 | 8-719-107-94 | DIODE | 1SS202-1 |
| D403 | 8-719-107-94 | DIODE | 1SS202-1 |
| D501 | 8-719-918-45 | DIODE | KV1310 |
| D503 | 8-719-903-27 | DIODE | 1SS168 |
| D601 | 8-719-114-27 | DIODE | RD4.7JS-B3 |
| D602 | 8-719-107-94 | DIODE | 1SS202-1 |
| D603 | 8-719-114-30 | DIODE | RD5.1JS-B2 |

< IC >

| | | | |
|---|---|---|---|
| IC101 | 8-759-602-83 | IC | M5238P |
| IC201 | 8-759-602-83 | IC | M5238P |
| IC301 | 8-759-917-18 | IC | SN74HCU04AN |
| IC302 | 8-759-916-12 | IC | SN74HC00AN |
| IC303 | 8-759-921-10 | IC | SN74HC86AN |
| IC304 | 8-759-135-80 | IC | uPC358C |
| IC305 | 8-759-927-46 | IC | SN74HC00ANS |
| IC306 | 8-759-947-57 | IC | CXD1136Q |
| IC307 | 8-752-339-43 | IC | CXD2601AQ |
| IC308 | 8-759-906-24 | IC | SN74LS624N |
| IC309 | 8-759-925-90 | IC | SN74HC74ANS |
| IC310 | 8-752-337-80 | IC | CXK58257AM-12L |
| IC311 | 8-752-837-18 | IC | CXP80524-063Q |
| IC312 | 8-752-837-17 | IC | CXP80524-062Q |
| IC316 | 8-759-912-77 | IC | LM324N |

When indicating parts by reference number, please include the board name.

# MAIN

| Ref. No. | Part No. | Description | Remarks |
|---|---|---|---|
| IC318 | 8-759-135-80 | IC uPC358C | |
| IC319 | 8-759-633-65 | IC M54641L | |
| IC320 | 8-759-633-65 | IC M54641L | |
| IC321 | 8-759-520-90 | IC PST572E | |
| IC322 | 8-759-231-53 | IC TA7805S | |
| IC330 | 8-759-984-34 | IC RP5C62 | |
| IC331 | 8-749-921-11 | IC GP1F32R (OPTICAL IN) | |
| IC332 | 8-749-921-12 | IC GP1F32T (OPTICAL OUT) | |
| IC333 | 8-759-917-18 | IC SN74HCU04AN | |
| IC354 | 8-759-900-72 | IC NE5532P | |
| IC355 | 8-759-900-72 | IC NE5532P | |
| IC356 | 8-759-945-58 | IC RC4558P | |
| IC357 | 8-759-231-53 | IC TA7805S | |
| IC358 | 8-759-245-79 | IC TA79005S | |
| IC359 | 8-759-504-36 | IC CS5339-KP | |
| IC360 | 8-759-972-47 | IC LF412CN | |
| IC363 | 8-752-342-65 | IC CXD2560M | |
| IC375 | 8-759-900-72 | IC NE5532P | |
| IC376 | 8-759-900-72 | IC NE5532P | |
| IC431 | 8-759-925-78 | IC SN74HC10ANS | |
| IC432 | 8-759-510-43 | IC PST572C | |
| IC501 | 8-759-604-30 | IC M5F7808L | |
| IC502 | 8-759-925-74 | IC SN74HC04ANS | |
| IC503 | 8-759-926-95 | IC SN74HC4020ANS | |
| IC504 | 8-759-250-81 | IC TC5081AP | |
| IC601 | 8-759-044-10 | IC CXD2562Q | |
| IC602 | 8-759-900-72 | IC NE5532P | |
| | | < JACK > | |
| J101 | 1-568-751-61 | JACK, PIN (2P SHIELD TYPE)(LINE IN) | |
| J102 | 1-568-751-61 | JACK, PIN (2P SHIELD TYPE)(LINE OUT) | |
| J181 | 1-565-406-41 | JACK, PIN 1P (COAXIAL OUT) | |
| J191 | 1-568-750-21 | JACK, PIN (1P SHIELD TYPE) (COAXIAL IN) | |
| | | < COIL > | |
| L301 | 1-410-509-11 | INDUCTOR 10uH | |
| L302 | 1-410-498-11 | INDUCTOR 1.2uH | |
| L303 | 1-410-509-11 | INDUCTOR 10uH | |
| L305 | 1-410-515-11 | INDUCTOR 33uH | |
| L306 | 1-410-509-11 | INDUCTOR 10uH | |
| L310 | 1-410-953-11 | INDUCTOR, SMALL TYPE | |
| L320 | 1-236-101-11 | ENCAPSULATED COMPONENT | |
| L329 | 1-236-101-11 | ENCAPSULATED COMPONENT | |
| L501 | 1-426-850-11 | COIL (RF) | |
| L502 | 1-410-509-11 | INDUCTOR 10uH | |
| L504 | 1-410-509-11 | INDUCTOR 10uH | |
| L505 | 1-426-850-11 | COIL (RF) | |
| L602 | 1-239-235-21 | ENCAPSULATED COMPONENT | |
| L603 | 1-410-397-21 | FERRITE BEAD INDUCTOR | |
| L604 | 1-236-058-21 | ENCAPSULATED COMPONENT | |

| Ref. No. | Part No. | Description | Remarks |
|---|---|---|---|
| | | < TRANSISTOR > | |
| Q301 | 8-729-927-11 | TRANSISTOR 2SA1585S-QR | |
| Q302 | 8-729-801-93 | TRANSISTOR 2SD1387-3 | |
| Q311 | 8-729-900-80 | TRANSISTOR DTC114ES | |
| Q312 | 8-729-620-05 | TRANSISTOR 2SC2603-EF | |
| Q313 | 8-729-900-61 | TRANSISTOR DTA114ES | |
| Q318 | 8-729-900-80 | TRANSISTOR DTC114ES | |
| Q319 | 8-729-900-80 | TRANSISTOR DTC114ES | |
| Q320 | 8-729-927-11 | TRANSISTOR 2SA1585S-QR | |
| Q321 | 8-729-927-12 | TRANSISTOR 2SC4115S-QR | |
| Q333 | 8-729-141-83 | TRANSISTOR 2SB1094-LK | |
| Q334 | 8-729-119-76 | TRANSISTOR 2SA1175-HFE | |
| Q335 | 8-729-620-05 | TRANSISTOR 2SC2603-EF | |
| Q336 | 8-729-927-11 | TRANSISTOR 2SA1585S-QR | |
| Q337 | 8-729-927-11 | TRANSISTOR 2SA1585S-QR | |
| Q338 | 8-729-927-12 | TRANSISTOR 2SC4115S-QR | |
| Q339 | 8-729-927-12 | TRANSISTOR 2SC4115S-QR | |
| Q340 | 8-729-900-80 | TRANSISTOR DTC114ES | |
| Q341 | 8-729-900-80 | TRANSISTOR DTC114ES | |
| Q342 | 8-729-209-15 | TRANSISTOR 2SD2012 | |
| Q432 | 8-729-900-80 | TRANSISTOR DTC114ES | |
| Q433 | 8-729-107-85 | TRANSISTOR 2SC3623A-K | |
| Q434 | 8-729-107-85 | TRANSISTOR 2SC3623A-K | |
| Q435 | 8-729-900-61 | TRANSISTOR DTA114ES | |
| Q436 | 8-729-900-80 | TRANSISTOR DTC114ES | |
| Q437 | 8-729-900-61 | TRANSISTOR DTA114ES | |
| Q438 | 8-729-900-80 | TRANSISTOR DTC114ES | |
| Q439 | 8-729-900-80 | TRANSISTOR DTC114ES | |
| Q440 | 8-729-620-05 | TRANSISTOR 2SC2603-EF | |
| Q499 | 8-729-900-80 | TRANSISTOR DTC114ES | |
| Q501 | 8-729-200-56 | TRANSISTOR 2SK241-GR | |
| Q502 | 8-729-200-56 | TRANSISTOR 2SK241-GR | |
| Q503 | 8-729-900-61 | TRANSISTOR DTA114ES | |
| Q601 | 8-729-140-96 | TRANSISTOR 2SD774-34 | |
| Q602 | 8-729-140-96 | TRANSISTOR 2SD774-34 | |
| Q603 | 8-729-119-76 | TRANSISTOR 2SA1175-HFE | |
| | | < RESISTOR > | |
| R102 | 1-247-903-00 | CARBON 1M 5% 1/4W | |
| R103 | 1-249-421-11 | CARBON 2.2K 5% 1/4W | |
| R104 | 1-249-434-11 | CARBON 27K 5% 1/4W | |
| R105 | 1-249-435-11 | CARBON 33K 5% 1/4W | |
| R106 | 1-249-403-11 | CARBON 68 5% 1/4W | |
| R107 | 1-247-854-11 | CARBON 9.1K 5% 1/4W | |
| R108 | 1-247-854-11 | CARBON 9.1K 5% 1/4W | |
| R109 | 1-247-854-11 | CARBON 9.1K 5% 1/4W | |
| R110 | 1-247-854-11 | CARBON 9.1K 5% 1/4W | |
| R111 | 1-247-844-11 | CARBON 3.6K 5% 1/4W | |
| R112 | 1-247-844-11 | CARBON 3.6K 5% 1/4W | |

When indicating parts by reference number, please include the board name.

| Ref.No. | Part No. | Description | | | | Remarks |
|---|---|---|---|---|---|---|
| R115 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W | |
| R116 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W | |
| R117 | 1-249-426-11 | CARBON | 5.6K | 5% | 1/4W | |
| R118 | 1-249-426-11 | CARBON | 5.6K | 5% | 1/4W | |
| R119 | 1-249-426-11 | CARBON | 5.6K | 5% | 1/4W | |
| R120 | 1-249-426-11 | CARBON | 5.6K | 5% | 1/4W | |
| R122 | 1-247-836-11 | CARBON | 1.6K | 5% | 1/4W | |
| R123 | 1-247-836-11 | CARBON | 1.6K | 5% | 1/4W | |
| R124 | 1-249-441-11 | CARBON | 100K | 5% | 1/4W | |
| R125 | 1-249-409-11 | CARBON | 220 | 5% | 1/4W | |
| R126 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W | |
| R127 | 1-249-405-11 | CARBON | 100 | 5% | 1/4W | |
| R153 | 1-247-806-11 | CARBON | 91 | 5% | 1/4W | |
| R180 | 1-249-397-11 | CARBON | 22 | 5% | 1/4W | |
| R202 | 1-247-903-00 | CARBON | 1M | 5% | 1/4W | |
| R203 | 1-249-421-11 | CARBON | 2.2K | 5% | 1/4W | |
| R204 | 1-249-434-11 | CARBON | 27K | 5% | 1/4W | |
| R205 | 1-249-435-11 | CARBON | 33K | 5% | 1/4W | |
| R206 | 1-249-403-11 | CARBON | 68 | 5% | 1/4W | |
| R207 | 1-247-854-11 | CARBON | 9.1K | 5% | 1/4W | |
| R208 | 1-247-854-11 | CARBON | 9.1K | 5% | 1/4W | |
| R209 | 1-247-854-11 | CARBON | 9.1K | 5% | 1/4W | |
| R210 | 1-247-854-11 | CARBON | 9.1K | 5% | 1/4W | |
| R211 | 1-247-844-11 | CARBON | 3.6K | 5% | 1/4W | |
| R212 | 1-247-844-11 | CARBON | 3.6K | 5% | 1/4W | |
| R215 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W | |
| R216 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W | |
| R217 | 1-249-426-11 | CARBON | 5.6K | 5% | 1/4W | |
| R218 | 1-249-426-11 | CARBON | 5.6K | 5% | 1/4W | |
| R219 | 1-249-426-11 | CARBON | 5.6K | 5% | 1/4W | |
| R220 | 1-249-426-11 | CARBON | 5.6K | 5% | 1/4W | |
| R222 | 1-247-836-11 | CARBON | 1.6K | 5% | 1/4W | |
| R223 | 1-247-836-11 | CARBON | 1.6K | 5% | 1/4W | |
| R224 | 1-249-441-11 | CARBON | 100K | 5% | 1/4W | |
| R225 | 1-249-409-11 | CARBON | 220 | 5% | 1/4W | |
| R226 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W | |
| R227 | 1-249-405-11 | CARBON | 100 | 5% | 1/4W | |
| R253 | 1-247-806-11 | CARBON | 91 | 5% | 1/4W | |
| R280 | 1-249-397-11 | CARBON | 22 | 5% | 1/4W | |
| R301 | 1-247-804-11 | CARBON | 75 | 5% | 1/4W | |
| R302 | 1-249-437-11 | CARBON | 47K | 5% | 1/4W | |
| R303 | 1-249-421-11 | CARBON | 2.2K | 5% | 1/4W | |
| R304 | 1-249-441-11 | CARBON | 100K | 5% | 1/4W | |
| R305 | 1-249-421-11 | CARBON | 2.2K | 5% | 1/4W | |
| R306 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W | |
| R307 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W | |
| R308 | 1-249-425-11 | CARBON | 4.7K | 5% | 1/4W | |
| R309 | 1-249-421-11 | CARBON | 2.2K | 5% | 1/4W | |
| R310 | 1-249-441-11 | CARBON | 100K | 5% | 1/4W | |
| R311 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W | |
| R312 | 1-249-421-11 | CARBON | 2.2K | 5% | 1/4W | |
| R313 | 1-249-421-11 | CARBON | 2.2K | 5% | 1/4W | |
| R314 | 1-249-435-11 | CARBON | 33K | 5% | 1/4W | |
| R315 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W | |
| R316 | 1-247-804-11 | CARBON | 75 | 5% | 1/4W | |
| R317 | 1-249-405-11 | CARBON | 100 | 5% | 1/4W | |
| R318 | 1-249-409-11 | CARBON | 220 | 5% | 1/4W | |
| R319 | 1-249-409-11 | CARBON | 220 | 5% | 1/4W | |
| R321 | 1-249-405-11 | CARBON | 100 | 5% | 1/4W | |
| R322 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W | |
| R323 | 1-249-433-11 | CARBON | 22K | 5% | 1/4W | |
| R324 | 1-249-433-11 | CARBON | 22K | 5% | 1/4W | |
| R325 | 1-249-425-11 | CARBON | 4.7K | 5% | 1/4W | |
| R326 | 1-249-409-11 | CARBON | 220 | 5% | 1/4W | |
| R327 | 1-249-425-11 | CARBON | 4.7K | 5% | 1/4W | |
| R328 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W | |
| R330 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W | |
| R331 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W | |
| R332 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W | |
| R333 | 1-249-433-11 | CARBON | 22K | 5% | 1/4W | |
| R334 | 1-249-425-11 | CARBON | 4.7K | 5% | 1/4W | |
| R335 | 1-249-425-11 | CARBON | 4.7K | 5% | 1/4W | |
| R336 | 1-249-425-11 | CARBON | 4.7K | 5% | 1/4W | |
| R337 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W | |
| R338 | 1-249-433-11 | CARBON | 22K | 5% | 1/4W | |
| R339 | 1-249-401-11 | CARBON | 47 | 5% | 1/4W | |
| R340 | 1-247-881-00 | CARBON | 120K | 5% | 1/4W | |
| R341 | 1-247-881-00 | CARBON | 120K | 5% | 1/4W | |
| R342 | 1-247-881-00 | CARBON | 120K | 5% | 1/4W | |
| R343 | 1-247-889-00 | CARBON | 270K | 5% | 1/4W | |
| R344 | 1-247-887-00 | CARBON | 220K | 5% | 1/4W | |
| R345 | 1-247-887-00 | CARBON | 220K | 5% | 1/4W | |
| R346 | 1-249-441-11 | CARBON | 100K | 5% | 1/4W | |
| R347 | 1-249-441-11 | CARBON | 100K | 5% | 1/4W | |
| R348 | 1-249-441-11 | CARBON | 100K | 5% | 1/4W | |
| R349 | 1-249-441-11 | CARBON | 100K | 5% | 1/4W | |
| R350 | 1-249-435-11 | CARBON | 33K | 5% | 1/4W | |
| R351 | 1-249-435-11 | CARBON | 33K | 5% | 1/4W | |
| R352 | 1-249-441-11 | CARBON | 100K | 5% | 1/4W | |
| R353 | 1-249-441-11 | CARBON | 100K | 5% | 1/4W | |
| R354 | 1-249-441-11 | CARBON | 100K | 5% | 1/4W | |
| R355 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W | |
| R356 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W | |
| R357 | 1-249-405-11 | CARBON | 100 | 5% | 1/4W | |
| R358 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W | |
| R359 | 1-249-408-11 | CARBON | 180 | 5% | 1/4W | |
| R360 | 1-215-447-00 | METAL | 12K | 1% | 1/6W | |
| R361 | 1-215-447-00 | METAL | 12K | 1% | 1/6W | |
| R364 | 1-249-406-11 | CARBON | 120 | 5% | 1/4W | |
| R365 | 1-249-425-11 | CARBON | 4.7K | 5% | 1/4W | |

When indicating parts by reference number, please include the board name.

# MAIN

| Ref. No. | Part No. | Description | | | | Remarks |
|---|---|---|---|---|---|---|
| R368 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W | |
| R369 | 1-249-405-11 | CARBON | 100 | 5% | 1/4W | |
| R370 | 1-249-405-11 | CARBON | 100 | 5% | 1/4W | |
| R371 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W | |
| R372 | 1-249-405-11 | CARBON | 100 | 5% | 1/4W | |
| R373 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W | |
| R374 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W | |
| R375 | 1-249-405-11 | CARBON | 100 | 5% | 1/4W | |
| R378 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W | |
| R379 | 1-249-414-11 | CARBON | 560 | 5% | 1/4W | |
| R380 | 1-249-411-11 | CARBON | 330 | 5% | 1/4W | |
| ⚠R381 | 1-215-881-11 | METAL OXIDE | 15 | 5% | 2W | F |
| R382 | 1-249-441-11 | CARBON | 100K | 5% | 1/4W | |
| R383 | 1-249-401-11 | CARBON | 47 | 5% | 1/4W | |
| R384 | 1-249-437-11 | CARBON | 47K | 5% | 1/4W | |
| R385 | 1-249-437-11 | CARBON | 47K | 5% | 1/4W | |
| R386 | 1-249-413-11 | CARBON | 470 | 5% | 1/4W | |
| R387 | 1-249-407-11 | CARBON | 150 | 5% | 1/4W | |
| R388 | 1-249-423-11 | CARBON | 3.3K | 5% | 1/4W | |
| R389 | 1-249-423-11 | CARBON | 3.3K | 5% | 1/4W | |
| R390 | 1-249-423-11 | CARBON | 3.3K | 5% | 1/4W | |
| R391 | 1-249-423-11 | CARBON | 3.3K | 5% | 1/4W | |
| R392 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W | |
| R393 | 1-249-420-11 | CARBON | 1.8K | 5% | 1/4W | |
| R394 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W | |
| R395 | 1-249-425-11 | CARBON | 4.7K | 5% | 1/4W | |
| R396 | 1-249-441-11 | CARBON | 100K | 5% | 1/4W | |
| R406 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W | |
| R407 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W | |
| R408 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W | |
| R409 | 1-249-425-11 | CARBON | 4.7K | 5% | 1/4W | |
| R410 | 1-249-425-11 | CARBON | 4.7K | 5% | 1/4W | |
| R411 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W | |
| R412 | 1-249-441-11 | CARBON | 100K | 5% | 1/4W | |
| R413 | 1-249-437-11 | CARBON | 47K | 5% | 1/4W | |
| R414 | 1-249-413-11 | CARBON | 470 | 5% | 1/4W | |
| R415 | 1-249-437-11 | CARBON | 47K | 5% | 1/4W | |
| R416 | 1-249-437-11 | CARBON | 47K | 5% | 1/4W | |
| R418 | 1-249-413-11 | CARBON | 470 | 5% | 1/4W | |
| R419 | 1-249-413-11 | CARBON | 470 | 5% | 1/4W | |
| R420 | 1-249-413-11 | CARBON | 470 | 5% | 1/4W | |
| R421 | 1-249-413-11 | CARBON | 470 | 5% | 1/4W | |
| R422 | 1-249-413-11 | CARBON | 470 | 5% | 1/4W | |
| R424 | 1-249-411-11 | CARBON | 330 | 5% | 1/4W | |
| R425 | 1-249-411-11 | CARBON | 330 | 5% | 1/4W | |
| R429 | 1-249-407-11 | CARBON | 150 | 5% | 1/4W | |
| R432 | 1-249-393-11 | CARBON | 10 | 5% | 1/4W | |
| R434 | 1-249-836-11 | CARBON | 1.6K | 5% | 1/4W | |
| R435 | 1-249-409-11 | CARBON | 220 | 5% | 1/4W | |
| R436 | 1-249-409-11 | CARBON | 220 | 5% | 1/4W | |
| R437 | 1-249-409-11 | CARBON | 220 | 5% | 1/4W | |
| R438 | 1-249-409-11 | CARBON | 220 | 5% | 1/4W | |
| R439 | 1-249-437-11 | CARBON | 47K | 5% | 1/4W | |
| R440 | 1-249-441-11 | CARBON | 100K | 5% | 1/4W | |
| R441 | 1-249-441-11 | CARBON | 100K | 5% | 1/4W | |
| R442 | 1-249-441-11 | CARBON | 100K | 5% | 1/4W | |
| R443 | 1-249-437-11 | CARBON | 47K | 5% | 1/4W | |
| R444 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W | |
| R445 | 1-249-419-11 | CARBON | 1.5K | 5% | 1/4W | |
| R446 | 1-247-883-00 | CARBON | 150K | 5% | 1/4W | |
| R447 | 1-249-425-11 | CARBON | 4.7K | 5% | 1/4W | |
| R448 | 1-249-413-11 | CARBON | 470 | 5% | 1/4W | |
| R449 | 1-249-424-11 | CARBON | 3.9K | 5% | 1/4W | |
| R451 | 1-247-891-00 | CARBON | 330K | 5% | 1/4W | |
| R462 | 1-247-804-11 | CARBON | 75 | 5% | 1/4W | |
| R490 | 1-249-425-11 | CARBON | 4.7K | 5% | 1/4W | |
| R495 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W | |
| R497 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W | |
| R498 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W | |
| R499 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W | |
| R501 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W | |
| R502 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W | |
| R503 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W | |
| R504 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W | |
| R505 | 1-249-428-11 | CARBON | 8.2K | 5% | 1/4W | |
| R506 | 1-249-441-11 | CARBON | 100K | 5% | 1/4W | |
| R507 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W | |
| R508 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W | |
| R509 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W | |
| R510 | 1-247-806-11 | CARBON | 91 | 5% | 1/4W | |
| R513 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W | |
| R514 | 1-249-423-11 | CARBON | 3.3K | 5% | 1/4W | |
| R515 | 1-249-423-11 | CARBON | 3.3K | 5% | 1/4W | |
| R516 | 1-249-425-11 | CARBON | 4.7K | 5% | 1/4W | |
| R517 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W | |
| R518 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W | |
| R519 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W | |
| R520 | 1-247-903-00 | CARBON | 1M | 5% | 1/4W | |
| R601 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W | |
| R603 | 1-249-405-11 | CARBON | 100 | 5% | 1/4W | |
| R604 | 1-249-419-11 | CARBON | 1.5K | 5% | 1/4W | |
| R605 | 1-249-389-11 | CARBON | 4.7 | 5% | 1/4W | |
| R606 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W | |

< VARIABLE RESISTOR >

| | | |
|---|---|---|
| RV601 | 1-226-773-11 | RES, ADJ, METAL 22K (FWD TORQUE) |

< RELAY >

| | | |
|---|---|---|
| RY301 | 1-515-726-11 | RELAY |

Thé components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque ⚠ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board name.

# MAIN MOTOR POWER RELAY PRIMARY

| Ref. No. | Part No. | Description | | | Remarks |
|---|---|---|---|---|---|
| | | < COIL > | | | |
| T301 | 1-459-795-11 | COIL (WITH CORE) | | | |
| | | < VIBRATOR > | | | |
| X301 | 1-567-816-11 | VIBRATOR, CRYSTAL (18.816MHz) | | | |
| X302 | 1-567-815-11 | VIBRATOR, CRYSTAL (22.5792MHz) | | | |
| X303 | 1-578-667-11 | VIBRATOR, CRYSTAL (49.152MHz) | | | |
| X304 | 1-567-098-00 | OSCILLATOR, CRYSTAL (32.768kHz) | | | |
| ********** | | | | | |
| * | 1-641-486-11 | MOTOR BOARD | | | |
| | | ********** | | | |
| | | < CAPACITOR > | | | |
| C01 | 1-162-851-11 | CERAMIC | 0.1MF | | 16V |
| | | < CONNECTOR > | | | |
| * CN1 | 1-564-498-11 | PIN, CONNECTOR 5P | | | |
| * CN2 | 1-564-337-00 | PIN, CONNECTOR 3P | | | |
| ********** | | | | | |
| * | A-2006-819-A | POWER BOARD, COMPLETE | | | |
| | | ********** | | | |
| | | < CAPACITOR > | | | |
| C907 | 1-126-946-11 | ELECT | 6800uF | 20% | 25V |
| C908 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V |
| C909 | 1-124-473-11 | ELECT | 1000uF | 20% | 10V |
| C910 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V |
| C911 | 1-164-159-11 | CERAMIC | 0.1uF | | 50V |
| C912 | 1-124-473-11 | ELECT | 1000uF | 20% | 10V |
| C913 | 1-126-104-11 | ELECT | 470uF | 20% | 35V |
| C914 | 1-126-104-11 | ELECT | 470uF | 20% | 35V |
| C915 | 1-126-049-11 | ELECT | 22uF | 20% | 50V |
| C916 | 1-126-052-11 | ELECT | 100uF | 20% | 50V |
| C917 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V |
| C918 | 1-130-834-00 | FILM | 1uF | 10% | 63V |
| C919 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V |
| C920 | 1-128-468-51 | ELECT | 4700uF | 20% | 25V |
| C921 | 1-128-468-51 | ELECT | 4700uF | 20% | 25V |
| C922 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V |
| C923 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V |
| C924 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V |
| C925 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V |
| C926 | 1-126-105-11 | ELECT | 1000uF | 20% | 35V |
| C927 | 1-126-105-11 | ELECT | 1000uF | 20% | 35V |
| | | < CONNECTOR > | | | |
| * CN905 | 1-560-338-00 | PIN, CONNECTOR 7P | | | |
| * CN906 | 1-560-061-00 | PIN, CONNECTOR 3P | | | |
| * CN931 | 1-564-505-11 | PLUG, CONNECTOR 2P | | | |
| * CN932 | 1-564-511-11 | PLUG, CONNECTOR 8P | | | |
| * CN933 | 1-564-506-11 | PLUG, CONNECTOR 3P | | | |
| | | < DIODE > | | | |
| D905 | 8-719-312-47 | DIODE | RBA-406B | | |
| D906 | 8-719-107-94 | DIODE | 1SS202-1 | | |
| D907 | 8-719-200-82 | DIODE | 11ES2 | | |
| D908 | 8-719-200-82 | DIODE | 11ES2 | | |
| D909 | 8-719-934-15 | DIODE | HZS24-3L | | |
| D910 | 8-719-933-33 | DIODE | HZS6A1L | | |
| D911 | 8-719-200-77 | DIODE | 10E2N | | |
| D912 | 8-719-200-77 | DIODE | 10E2N | | |
| D913 | 8-719-200-77 | DIODE | 10E2N | | |
| D914 | 8-719-200-77 | DIODE | 10E2N | | |
| D915 | 8-719-107-94 | DIODE | 1SS202-1 | | |
| D916 | 8-719-107-94 | DIODE | 1SS202-1 | | |
| | | < FUSE > | | | |
| ⚠F901 | 1-532-744-11 | FUSE, GLASS TUBE (2.5A) (US, Canadian) | | | |
| ⚠F901 | 1-532-286-11 | FUSE, TIME-LAG (T2.5A) (AEP, E) | | | |
| | | < IC > | | | |
| IC901 | 8-759-148-79 | IC | uPC2406HF | | |
| IC902 | 8-759-231-53 | IC | TA7805S | | |
| IC903 | 8-759-231-58 | IC | TA7812S | | |
| IC904 | 8-759-245-86 | IC | TA79012S | | |
| | | < TRANSISTOR > | | | |
| Q901 | 8-729-140-97 | TRANSISTOR | 2SB734-34 | | |
| | | < RESISTOR > | | | |
| R901 | 1-249-425-11 | CARBON | 4.7K | 5% | 1/4W |
| ⚠R902 | 1-212-849-00 | FUSIBLE | 4.7 | 5% | 1/4W F |
| R903 | 1-249-421-11 | CARBON | 2.2K | 5% | 1/4W |
| ⚠R904 | 1-212-865-00 | FUSIBLE | 22 | 5% | 1/4W F |
| R905 | 1-249-433-11 | CARBON | 22K | 5% | 1/4W |
| ********** | | | | | |
| * | 1-645-235-11 | RELAY BOARD | | | |
| | | ********** | | | |
| ********** | | | | | |
| * | 1-645-234-11 | PRIMARY BOARD | | | |
| | | ********** | | | |
| * | 3-346-266-12 | PLATE, GROUND | | | |

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque ⚠ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board name.

# PRIMARY REC VOL REEL MOTOR RF AMP

| Ref. No. | Part No. | Description | | | Remarks |
|---|---|---|---|---|---|
| | | < CAPACITOR > | | | |
| ⚠C901 | 1-161-744-00 | CERAMIC | 0.01uF | | 400V |
| ⚠C902 | 1-161-742-00 | CERAMIC | 0.0022uF | 20% | 400V |
| ⚠C903 | 1-161-742-00 | CERAMIC | 0.0022uF | 20% | 400V |
| ⚠C904 | 1-161-742-00 | CERAMIC | 0.0022uF | 20% | 400V |
| ⚠C905 | 1-161-742-00 | CERAMIC | 0.0022uF | 20% | 400V(AEP, E) |
| ⚠C906 | 1-161-744-00 | CERAMIC | 0.01uF | | 400V |
| | | < CONNECTOR > | | | |
| * CN901 | 1-564-321-00 | PIN, CONNECTOR 2P | | | |
| CN902 | 1-564-321-00 | PIN, CONNECTOR 2P | | | |
| | | < COIL > | | | |
| ⚠L901 | 1-421-915-11 | COIL, LINE FILTER | | | |
| | | < SWITCH > | | | |
| ⚠S921 | 1-571-722-11 | SWITCH, VOLTAGE SELECTION (VOLTAGE SELECTOR) | | | (E) |
| ********** | | | | | |
| * | 1-645-239-11 | REC VOL BOARD | | | |
| | | ********** | | | |
| | | < CONNECTOR > | | | |
| * CN102 | 1-564-519-11 | PLUG, CONNECTOR 4P | | | |
| | | < RESISTOR > | | | |
| R101 | 1-259-462-11 | CARBON | 27K | 5% | 1/6W |
| R201 | 1-259-462-11 | CARBON | 27K | 5% | 1/6W |
| | | < VARIABLE RESISTOR > | | | |
| RV101 | 1-241-937-11 | RES, VAR, CARBON 20K/20K (REC LEVEL) | | | |
| ********** | | | | | |
| * | 1-639-304-11 | REEL MOTOR BOARD | | | |
| | | ********** | | | |
| | | < CAPACITOR > | | | |
| C07 | 1-163-077-00 | CERAMIC CHIP | 0.1uF | 10% | 25V |
| ********** | | | | | |
| | | RF AMP BOARD, COMPLETE | | | |
| | | ********** | | | |
| | | < CAPACITOR > | | | |
| C1 | 1-124-778-00 | ELECT CHIP | 22uF | 20% | 6.3V |
| C2 | 1-163-019-00 | CERAMIC CHIP | 0.0068uF | 10% | 50V |
| C3 | 1-163-117-00 | CERAMIC CHIP | 100PF | 5% | 50V |
| C4 | 1-162-638-11 | CERAMIC CHIP | 1uF | | 16V |
| C5 | 1-164-299-11 | CERAMIC CHIP | 0.22uF | 10% | 25V |
| C6 | 1-164-004-11 | CERAMIC CHIP | 0.1uF | 10% | 25V |
| C7 | 1-163-009-11 | CERAMIC CHIP | 0.001uF | 10% | 50V |
| C8 | 1-124-778-00 | ELECT CHIP | 22uF | 20% | 6.3V |
| C9 | 1-124-778-00 | ELECT CHIP | 22uF | 20% | 6.3V |
| C10 | 1-163-009-11 | CERAMIC CHIP | 0.001uF | 10% | 50V |
| C11 | 1-164-004-11 | CERAMIC CHIP | 0.1uF | 10% | 25V |
| C12 | 1-164-299-11 | CERAMIC CHIP | 0.22uF | 10% | 25V |
| C13 | 1-162-638-11 | CERAMIC CHIP | 1uF | | 16V |
| C14 | 1-163-117-00 | CERAMIC CHIP | 100PF | 5% | 50V |
| C15 | 1-124-778-00 | ELECT CHIP | 22uF | 20% | 6.3V |
| C16 | 1-163-038-00 | CERAMIC CHIP | 0.1uF | | 25V |
| C17 | 1-163-001-11 | CERAMIC CHIP | 220PF | 10% | 50V |
| C18 | 1-163-117-00 | CERAMIC CHIP | 100PF | 5% | 50V |
| C19 | 1-163-001-11 | CERAMIC CHIP | 220PF | 10% | 50V |
| C20 | 1-164-182-11 | CERAMIC CHIP | 0.0033uF | 10% | 50V |
| C21 | 1-163-005-11 | CERAMIC CHIP | 470PF | 10% | 50V |
| C22 | 1-126-603-11 | ELECT CHIP | 4.7uF | 20% | 35V |
| C23 | 1-163-117-00 | CERAMIC CHIP | 100PF | 5% | 50V |
| C24 | 1-163-038-00 | CERAMIC CHIP | 0.1uF | | 25V |
| C25 | 1-124-778-00 | ELECT CHIP | 22uF | 20% | 6.3V |
| C26 | 1-163-038-00 | CERAMIC CHIP | 0.1uF | | 25V |
| C27 | 1-162-638-11 | CERAMIC CHIP | 1uF | | 16V |
| C28 | 1-164-505-11 | CERAMIC CHIP | 2.2uF | | 16V |
| | | < CONNECTOR > | | | |
| * CN51 | 1-566-207-11 | PIN, CONNECTOR (PC BOARD) 14P | | | |
| * CN52 | 1-564-720-11 | PIN, CONNECTOR (SMALL TYPE) 4P | | | |
| | | < IC > | | | |
| IC1 | 8-752-039-01 | IC CXA1364R | | | |
| | | < COIL > | | | |
| L1 | 1-408-781-00 | INDUCTOR CHIP | 22uH | | |
| L2 | 1-408-789-21 | INDUCTOR CHIP | 100uH | | |
| L3 | 1-408-781-00 | INDUCTOR CHIP | 22uH | | |
| | | < RESISTOR > | | | |
| R1 | 1-216-082-00 | METAL GLAZE | 24K | 5% | 1/10W |
| R2 | 1-216-082-00 | METAL GLAZE | 24K | 5% | 1/10W |
| R3 | 1-216-066-00 | METAL CHIP | 5.1K | 5% | 1/10W |
| R4 | 1-216-066-00 | METAL CHIP | 5.1K | 5% | 1/10W |
| R5 | 1-216-077-00 | METAL CHIP | 15K | 5% | 1/10W |
| R6 | 1-216-077-00 | METAL CHIP | 15K | 5% | 1/10W |
| R7 | 1-216-077-00 | METAL CHIP | 15K | 5% | 1/10W |
| R8 | 1-216-079-00 | METAL CHIP | 18K | 5% | 1/10W |
| R9 | 1-216-075-00 | METAL CHIP | 12K | 5% | 1/10W |
| R10 | 1-216-079-00 | METAL CHIP | 18K | 5% | 1/10W |
| R11 | 1-216-077-00 | METAL CHIP | 15K | 5% | 1/10W |

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque ⚠ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board name.

## RF AMP | RGN SW | SW | TIMER SW | TOP END SENSOR

| Ref.No. | Part No. | Description | | | | Remarks |
|---|---|---|---|---|---|---|
| R12 | 1-216-077-00 | METAL CHIP | 15K | 5% | 1/10W | |
| R13 | 1-216-077-00 | METAL CHIP | 15K | 5% | 1/10W | |
| R14 | 1-216-081-00 | METAL CHIP | 22K | 5% | 1/10W | |
| R15 | 1-216-085-00 | METAL CHIP | 33K | 5% | 1/10W | |
| R16 | 1-216-089-00 | METAL CHIP | 47K | 5% | 1/10W | |
| R17 | 1-216-080-00 | METAL CHIP | 20K | 5% | 1/10W | |
| R18 | 1-216-073-00 | METAL CHIP | 10K | 5% | 1/10W | |
| | | < VARIABLE RESISTOR > | | | | |
| RV1 | 1-238-181-11 | RES, ADJ, CERMET 4.7K | | | | |
| RV2 | 1-238-181-11 | RES, ADJ, CERMET 4.7K | | | | |
| ********** | | | | | | |
| * | 1-639-301-11 | RGN SW BOARD | | | | |
| | | ********** | | | | |
| | | < SWITCH > | | | | |
| S01 | 1-571-878-11 | SWITCH, PUSH (2 KEY) | | | | (CASSETTE IN/REC PROOF) |
| ********** | | | | | | |
| * | 1-641-487-11 | SW BOARD | | | | |
| | | ******** | | | | |
| | | < SWITCH > | | | | |
| S1 | 1-571-958-11 | SWITCH, PUSH (1 KEY) | | | | (CASSETTE TABLE IN) |
| S2 | 1-571-958-11 | SWITCH, PUSH (1 KEY) | | | | (CASSETTE TABLE OUT) |
| ********** | | | | | | |
| * | 1-645-243-11 | TIMER SW BOARD | | | | |
| | | ********** | | | | |
| | | < RESISTOR > | | | | |
| R704 | 1-249-427-11 | CARBON | 6.8K | 5% | 1/4W | |
| R705 | 1-249-432-11 | CARBON | 18K | 5% | 1/4W | |
| | | < SWITCH > | | | | |
| S701 | 1-571-520-11 | SWITCH, SLIDE (TIMER) | | | | |
| S702 | 1-554-937-11 | SWITCH, KEY BOARD ( ⏏ OPEN/CLOSE) | | | | |
| ********** | | | | | | |
| * | 1-639-305-11 | TOP END SENSOR BOARD | | | | |
| | | ********** | | | | |
| * | 3-368-456-01 | HOLDER (END SENSOR LIGHT) | | | | |
| * | 3-368-457-01 | HOLDER (END SENSOR) (RECIEVE) | | | | |
| | | < DIODE > | | | | |
| D01 | 8-719-988-42 | DIODE GL453S | | | | |
| | | < PHOTO INTERUPTER > | | | | |
| PH03 | 8-729-907-25 | TRANSISTOR PT4850F | | | | |
| PH04 | 8-729-907-25 | TRANSISTOR PT4850F | | | | |
| ********** | | | | | | |
| | | MISCELLANEOUS | | | | |
| | | ********** | | | | |
| ⚠10 | 1-559-297-31 | CODE, POWER (E) | | | | |
| ⚠10 | 1-559-479-11 | CORD, POWER (US, Canadian) | | | | |
| ⚠10 | 1-575-912-11 | CORD, POWER (AEP) | | | | |
| 13 | 1-590-321-71 | LEAD (WITH CONNECTOR) (CONTROL-S IN) | | | | |
| 107 | 1-533-183-11 | HOLDER, FUSE | | | | |
| 114 | 1-590-915-11 | WIRE, FLAT TYPE (30 CORE) | | | | |
| 118 | 1-590-916-11 | WIRE, FLAT TYPE (10 CORE) | | | | |
| 119 | 1-590-914-11 | WIRE, FLAT TYPE (6 CORE) | | | | |
| 325 | 8-848-567-11 | DRUM ASSY DOU-03A | | | | |
| M901 | A-2003-910-A | MOTOR ASSY, CASSETTE | | | | (CASSETTE COMPARTMENT) |
| M902 | 8-835-361-01 | MOTOR, DC U-17B (CAPSTAN) | | | | |
| M903 | X-3363-109-1 | MOTOR (CAM) ASSY | | | | |
| M905 | X-3363-110-1 | MOTOR (REEL) ASSY | | | | |
| PM902 | 1-454-536-11 | SOLENOID, PLUNGER (BT CONTROL) | | | | |
| PM903 | 1-454-535-11 | SOLENOID, PLUNGER (BRAKE) | | | | |
| ⚠S901 | 1-554-920-21 | SWITCH, PUSH (AC POWER) (1 KEY) (POWER) | | | | |
| ⚠T901 | 1-450-556-21 | TRANSFORMER, POWER (US, Canadian) | | | | |
| ⚠T901 | 1-450-557-21 | TRANSFORMER, POWER (AEP) | | | | |
| ⚠T901 | 1-450-558-21 | TRANSFORMER, POWER (E) | | | | |
| ********** | | | | | | |
| | | ACCESSORIES & PACKING MATERIALS | | | | |
| | | ********** | | | | |
| | 1-465-737-11 | REMOTE COMMANDER | | | | (US, Canadian, E/AEP:BLACK) |
| | 1-465-777-11 | REMOTE COMMANDER (AEP:GOLD) | | | | |
| | 1-558-271-11 | CORD, CONNECTION | | | | |
| | 3-704-366-01 | SCREW (CASE) (M3X8) | | | | (US, Canadian, E/AEP:BLACK) |
| | 3-704-366-11 | SCREW (CASE) (M3X8) (AEP:GOLD) | | | | |
| | 3-707-584-01 | COVER, BATTERY | | | | |
| | 3-755-612-11 | MANUAL, INSTRUCTION (ENGLISH, FRENCH, SPANISH, PORTUGUESE) (AEP, E) | | | | |
| | 3-755-612-21 | MANUAL, INSTRUCTION (ENGLISH) | | | | (US, Canadian) |
| | 3-755-612-31 | MANUAL, INSTRUCTION (FRENCH) (Canadian) | | | | |
| | 3-755-612-41 | MANUAL, INSTRUCTION (GERMAN, DUTCH, SWEDISH, ITALIAN) (AEP) | | | | |
| | 3-382-950-01 | CUSHION | | | | |
| | 3-383-048-01 | INDIVIDUAL CARTON | | | | |
| | 9-910-999-33 | INSTRUCTION (US) | | | | |
| ********** | | | | | | |

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque ⚠ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board name.

| Ref.No. | Part No. | Description | Remarks |
|---|---|---|---|

## HARDWARE LIST

| | | |
|---|---|---|
| #1 | 7-682-548-09 | SCREW +BVTT 3X8 (S) |
| #2 | 7-685-646-79 | SCREW +BVTP 3X8 TYPE2 N-S |
| #3 | 7-685-134-19 | SCREW (+ PTPWH) (2.6X8) |
| #4 | 7-685-534-19 | SCREW +BTP 2.6X8 TYPE2 N-S |
| #5 | 7-685-645-19 | SCREW +BVTP 3X8 TYPE2 N-S |
| #6 | 7-685-133-19 | SCREW +BTP 2.6X6 TYPE2 N-S |
| #7 | 7-682-147-15 | SCREW, TR |
| #8 | 7-621-775-20 | SCREW +B 2.6X5 |
| #9 | 7-682-560-04 | SCREW +BVTT 4X6 (S) |
| #10 | 7-682-547-04 | SCREW +BVTT 3X6 (S) |
| #11 | 7-621-772-00 | SCREW +B 2X3 |
| #12 | 7-685-102-19 | SCREW +P 2X4 TYPE2 NON-SLIT |
| #13 | 7-621-773-86 | SCREW +B 2.6X4 |
| #14 | 7-627-556-17 | SCREW, PRECISION +P 2.6X3 TYPE1 |
| #15 | 7-621-772-08 | SCREW +B 2X3 |
| #16 | 7-621-772-18 | SCREW +B 2X4 |
| #17 | 7-627-552-47 | SCREW, PRECISION +P 1.7X4 |
| #18 | 7-621-255-20 | SCREW +BVTT 2X4 (S) |
| #19 | 7-627-854-07 | PRECISION SCREW +P 2X2.5 TYPE3 |
| #20 | 7-627-852-27 | +P 1.7X3 |
| #21 | 7-621-255-15 | SCREW +P 2X3 |
| #22 | 7-627-552-27 | SCREW, PRECISION +P 1.7X2 |

9-957-307-11

Sony Corporation
Audio Group



English
92G1986-1
Printed in Japan
© 1992.7
Published by Customer Relations and Service Group