Product: ***STATUS*** **Consoles with Dynamics Option**

Question: **How do you configure the Dynamics Hardware Control Panel?**

Procedure: **To enter the Configuration Screen, hold the GATE button & press BYPASS GATES. The Following is a list of the button functions used to setup the configuration:**

1. **THRESHOLD: Clears the NOV RAM**
2. **CHAN and MIX buttons in the lower right hand column of the panel select the mode for the Dynamics Processor**
   a. **R = Four Input Modules with Dynamics (enter one 'R' for every four Input Modules with Dynamics**
   b. **Note: 'M', 'B', 'A' and 'K' are used for Elite consoles only.**
3. **METER MIX and METER CHAN buttons: Advances cursor '_' for above entry.**
4. **SET ALL: Toggles between PC CONTROL and CONTROL PANEL (Hardware Control Panel will show Blank in top right [ ] of LCD display).**
5. **GATE ON: Sets Meter Style (Not needed w/Hardware Control Panel)**
6. **PRESET: Reboots (or exits and resets) the Control Panel.**

Example: **For a 32 Input Console with Dynamics on all inputs, the LCD screen should read as follows:**

RRRRRRRR

Press 'PRESET' to reboot HCP and Dynamics System.