PART	DESCRIPTION	SCHEMATIC REFERENCE	PART NUMBER
CELEST FILTER BOARD (FAST 5 ONLY)			
Assembly	Celest Filter Board (PA-105)		996-013043
Potentiometer	22K Celest Filter Adj	VR12, 13	925-011329
Transistor	Celest Filter (BC 114)	Q38, 39	991-013044
CONSOLE ASSEMBLY			
Cord	A.C. Power		989-011268
Handle	Cabinet (Fast 4)		930-013024-2
Handle	Cabinet (Fast 5)		930-013024-3
Jack	Headphone		906-013038
Jack	Swell Pedal		906-013039
Knob	Bass Volume (Gray/Silver Cap)		915-011324
Light	Pilot		939-013040
Socket	Bass Pedals		906-013041
Switch	Off/On Power		960-013042
FLUTE FILTER BOARD			
Assembly	Flute Filter Board (PA-97)		996-013046
Potentiometer	22K Flute Filter Adj	VR7-9	925-011329
Transistor	Filter (BC 114)	Q24-26	991-013044
KEYSWITCH ASSEMBLY			
Actuator	Keyswitch (White Plastic)		964-013049
Key	C Natural Black (Bass)		964-013038-C
Key	D Natural Black (Bass)		964-013038-D
Key	E Natural Black (Bass)		964-013038-E
Key	F Natural Black (Bass)		964-013038-F
Key	G Natural Black (Bass)		964-013038-G
Key	A Natural Black (Bass)		964-013038-A
Key	B Natural Black (Bass)		964-013038-B
Key	C Natural Dark Gray (Bass/Treble)		964-013027-C
Key	D Natural Dark Gray (Bass/Treble)		964-013027-D
Key	E Natural Dark Gray (Bass/Treble)		964-013027-E
Key	F Natural Dark Gray (Bass/Treble)		964-013027-F
Key	G Natural Dark Gray (Bass/Treble)		964-013027-G
Key	A Natural Dark Gray (Bass/Treble)		964-013027-A
Key	B Natural Dark Gray (Bass/Treble)		964-013027-B
Key	C Natural Gray (Treble)		964-013028-C
Key	D Natural Gray (Treble)		964-013028-D
Key	E Natural Gray (Treble)		964-013028-E
Key	F Natural Gray (Treble)		964-013028-F
Key	G Natural Gray (Treble)		964-013028-G
Key	A Natural Gray (Treble)		964-013028-A
Key	B Natural Gray (Treble)		964-013028-B
Key	All Sharps (White)		964-013029
Spring	Actuator Pull Down		975-013050
Spring	Key Contact		975-013051