000	**BYPASS**		**multi effect**	**MIX**	Chorus level	00 - 99
001	**concert hall**	reverb only			Delay level	00 - 99
002	**bright plate**	reverb only			Reverb level	00 - 99
003	**dark plate**	reverb only		**CHORUS**	Chorus mode	Mode 1 - Mono chorus
004	**live room**	reverb only				Mode 2 - Stereo flanger
005	**chs - dly - rev 1**	multi effect				Mode 3 - Stereo chorus
006	**chs - dly - rev 2**	multi effect				Mode 4 - Voice chorus
007	**st - chorus**	chorus only			Chorus depth	00-99
008	**st - flange**	chorus only		**DELAY**	Degree of ducking / compression	-, dck1, dck2, dck3, dck4, cmp1, cmp2, cmp3, cmp4
009	**ping - pong 1**	delay only			Delay type	Mono
010	**ping - pong 2**	delay only				Stereo 01 - 99
011	**ping - pong 3**	delay only			Delay character	clean, warm, dark
012	**chs - rev 1**	multi effect			Delay feedback	00 - 99
013	**chs - rev 2**	multi effect			Delay time	000 - 739
014	**chs - rev 3**	multi effect		**REVERB**	Reverb decay	00 - 99
015	**space echo -1**	multi effect			reverb balance	-4 / +4
016	**space echo -2**	multi effect				
017	**multi - tap 1**	multi tap	**reverb only**	**REVERB**	Reverb decay	00 - 99
018	**multi - tap 2**	multi tap			Reverb type	room, plate, hall, large hall
019	**multi - tap 3**	multi tap			Reverb character	dark, warm, standard, bright
020	**multi - tap 4**	multi tap				
021	**garage**	reverb only	**delay only**	**DELAY**	Delay type	mono, stereo, pinpong
022	**theatre**	reverb only			Delay description	short, medium, long
023	**blues room**	reverb only			Delay time	0000 - 1660
024	**big reverb**	reverb only			Delay feedback	00 - 99
025	**800 m. sec**	delay only	**multi tap**	**VOICE**	Level	00 - 99
026	**1660 m. sec**	delay only			Pan	0 - 9 left right
027	**200 - 220 m. sec**	delay only			Modulation	00 - 99
028	**400 - 420 m. sec**	delay only		**FEEDBACK**	Feedback left	00 - 99
029	**800 - 820 m. sec**	delay only			Feedback right	00 - 99
030	**st - double**	delay only		**DELAY**	Delay time 1	010 - 730
031	**flange - dly**	multi tap			Delay time 2	010 - 730
032	**flange - echo**	multi tap			Delay time 3	10 - 730
033	**chorus blues**	chorus only			Delay time 4	10 - 730
034	**flange blues**	chorus only			Delay time 5	10 - 730
035	**ambience**	multi effect			Delay time 6	10 - 730
036	**mod - delay**	multi tap	**chorus only**		mono chorus, stereo chorus, voice chorus, mono flanger, stereo flanger	
037	**six voice 1**	chorus only			Speed	0 - 9 slow fast
038	**six voice 2**	chorus only			Depth	00 - 99
039	**memory man**	multi effect			Resonnance (flanger)	00 - 99
040	**delay duck**	multi effect			Filter	0 - 9
041	**metal chorus**	chorus only			Duck	00 - 99
042	**metal flange**	chorus only				
043	**country slap**	multi effect				
044	**fade left**	delay only				
045	**fade right**	delay only				