Setting up the DM3200 Or the DM4800:

IF YOU ARE POWERING UP THIS UNIT FOR THE FIRST PLEASE SKIP THIS RESET PROCEDURE.

FACTORY RESET:

1) Power Down the DM3200 or DM4800
2) At the same time hold down the **Shift button, the 1 and 2** button under the **OUT PUT ASSIGN**

