Roland®

AX-Synth

Erratum

To our regret, the AX-Synth owner's manual requires the following correction.

Page 27, table in the left column

(Old version in the owner's manual.)

MIDI messages that can be transmitted/received

The most important MIDI messages the AX-Synth can transmit and receive are:

Message	Remarks
Note On/Off	
Velocity	Transmission: striking force of the AX-Synth's keys
Aftertouch	Transmission: channel aftertouch via AFTER TOUCH knob (not from the keyboard). Reception: polyphonic & channel aftertouch.
Program Change	Transmission also without changing sounds on AX-Synth
Bank Select	Transmission: cannot be specified on the AX-Synth.
Pitch Bend	Transmission: TOUCH CONTROLLER and/or D Beam
Modulation	CC01, transmission: MODULATION BAR
Volume	CC07, transmission: VOLUME knob
Hold/Sustain	CC64, HOLD button & optional footswitch connected to FOOT PEDAL
CC01~31, CC33~95	Transmission: the control change number assigned to the D BEAM ASSIGNABLE button.

Please delete this row.

(Correct version.)

MIDI messages that can be transmitted/received

The most important MIDI messages the AX-Synth can transmit and receive are:

Message	Remarks
Note On/Off	
Velocity	Transmission: striking force of the AX-Synth's keys
Aftertouch	Transmission: channel aftertouch via AFTER TOUCH knob (not from the keyboard). Reception: polyphonic & channel aftertouch.
Program Change	Transmission also without changing sounds on AX-Synth
Bank Select	Transmission: cannot be specified on the AX-Synth.
Pitch Bend	Transmission: TOUCH CONTROLLER and/or D Beam
Modulation	CC01, transmission: MODULATION BAR
Hold/Sustain	CC64, HOLD button & optional footswitch connected to FOOT PEDAL
CC01~31, CC33~95	Transmission: the control change number assigned to the D BEAM ASSIGNABLE button.

The AX-Synth's VOLUME knob cannot transmit MIDI messages, because it is analog.

We apologize for the inconvenience this may cause.