Table of Contents

About this manual iii
Data handling iii

Introduction 1

Introducing the TRITON 1
Main features 1
Overview of the modes 3

Front and rear panel 5
Front panel 5
Rear panel 8

Names and functions of objects in the LCD screen 10

Basic operation of the TRITON 12
1. Selecting modes 12
Selecting a page 12
2. Selecting pages and tabs 12
Selecting a tab 12
VALUE controllers 13
3. Setting a parameter 13
[BANK] keys 13
[COMPARE] key 14
Popup buttons and popup menus 14
Keyboard input 14

Connections 15
1. Connecting the power cable 15
2. Connecting audio output devices 15
3. Connecting audio input devices 15
4. Connecting pedals etc. 16
5. Connections to MIDI equipment 16
6. Connections to a computer 16
7. Connections to a SCSI device 16

Quick Start 17

Turning the power on / off 17
1. Turning the power on 17
2. Turning the power off 17

Listening to a demo song 18
1. Loading the demo song data in Disk mode . . . 18
2. Selecting and playing a demonstration song in Sequencer mode 19
3. Playing a cue list 20

Selecting and playing a program 21
Selecting a program 21

Selecting and playing a combination 23
Selecting a combination 23

Using controllers to modify the sound 25
Joystick 25
Ribbon controller 25
SW1, SW2 25
The Lock function 25
Realtime control knobs [1], [2], [3], [4] 26
A mode controls 26
B mode controls 27
[VALUE] slider 27
Keyboard 27
Foot pedals 28
ARPEGGIATOR [TEMPO] knob, [GATE] knob, [VELOCITY] knob 28

Using the arpeggiator while you play 29
Using the arpeggiator in Program mode 29
Settings using controllers 29
Settings in the LCD screen 30
Using the arpeggiator as you play in Combination mode 31
Settings in the LCD screen 31

Playing with the RPPR (Realtime Pattern Play / Recording) function 33

Simple program editing 34
Performance Edit 34
Realtime controls 34

Simple combination editing 35
An example of editing 35
Selecting the program for a timbre 35
Adjusting the stereo position 36
Adjusting the volume 36

Basic functions 37

Saving data 37
Types of data that can be saved 37
Writing to internal memory 37
Writing a program or combination 38
Writing global settings, user drum kits, and user arpeggio patterns 39
Saving on external media 40
MIDI data dump 41

Restoring the factory settings 42
Loading the preload data 42

Program mode 43
About the pages in Program mode 43
Playing a program 43
P0: Play 43
How a program is organized 44
P1: Edit-Basic
Oscillator settings 45
Basic program editing 45
P2: Edit-Pitch
Pitch settings 47

P3: Edit-Filter
Filter settings 48
P4: Edit-Amp
Amplifier settings 49
P5: Edit-Common LFO
LFO settings 50
P7: Edit-arpeggiator
Arpeggiator settings 51
P8: Edit-Insert Effect
Insert Effect settings 51
P9: Edit Master Effect
Master Effect settings 51
More about Alternate Modulation 51

Combination mode 52
Pages in Combination mode 52
Playing a combination 52
P0: Play 52
How a combination is structured 53
Basic combination editing 53
P1: Edit-Program / Mixer
Timbre 1–8 program, pan and volume 54
P2: Edit-Trk Param
Settings for status, MIDI channel, and playing mode 55
P3: Edit-MIDI Filter
MIDI filter settings 56
P4: Edit-Zone / Ctrl
Layer, split, and velocity switch settings . . 56
P7: Edit-Arpeggiator
Arpeggiator settings 57
P8: Edit-Insert Effect
Insert Effect settings 57
P9: Edit Master Effect
Master Effect settings 57

Sequencer mode 58
Features of the sequencer 58
About each page in Sequencer mode 60
The structure of Sequencer mode 60
Songs 60
Patterns 61
Cue List 61
Playback 62
Playing a song (Play) 62
Other playback 62
Recording 63
Recording on a track, and recording on a pattern 63
Realtime recording on a track 64
Realtime recording to a pattern 68
Step recording on a track or pattern 69
Editing 70
Track editing 70
Pattern editing 70
Song editing 70
Creating and playing a Cue List 70
RPPR (Realtime Pattern Play / Recording) function 72
RPPR settings 72
RPPR playback 73
Realtime recording an RPPR performance 73

Sampling mode 75
Features of sampling mode 75
Pages in Sampling mode 76
How Sampling mode is organized 76
In Sampling mode 76
Samples and Multisamples 77
Sampling (recording a sample) 78
Preparations for sampling 78
Manual sampling 79
Auto sampling 80
Creating multisample indexes and sampling 81
Loop settings 82
The grid display 82
Sample (waveform data) editing 83
Multisample editing 84
Editing the indices 84
Modifying the settings of an index 84
Converting a multisample to a program 84

Song Play mode 85
The pages in Song Play mode 85
The structure of Song Play mode 85
Playing SMF data 86
Playback using the Jukebox function 87
Saving a Jukebox list 88
Playing along with SMF data 88

Global mode 89
About the pages in Global mode 89
Creating a drum kit 90
About drum kits 90
Editing a drum kit 90

Disk mode 92
How Disk mode is organized 92
The pages of Disk mode 92
Types of media that can be used 92
Loading data 92
Types of data that can be loaded 92
Data loading procedure 92
Saving data 94
Types of data that can be saved 94
Formatting media 94
Cautions when handling floppy disks 95

Arpeggiator settings 96
Arpeggiator settings for a program 96
Arpeggiator settings in Combination, Song, and Song Play modes 98
Creating an user arpeggio pattern 100
About user arpeggio patterns 100
Editing a user pattern 100
Dual arpeggiator editing 104
About arpeggiator synchronization 105

Effects settings 106
Effects in each mode 106
Routing settings and effect settings 107
Effect settings for a program 107
Effect settings in Combination, Song, and Song Play modes 108
Effect settings in Sampling mode 109

Effect settings for the AUDIO INPUT. 109
About dynamic modulation (Dmod) 110

MIDI applications 111
About MIDI. 111
Connecting MIDI devices / computers (MIDI connectors) 111
Controlling an external MIDI tone generator from the TRITON 111
Controlling the TRITON's tone generator from an external MIDI device 111
Controlling two or more external MIDI tone generators from the TRITON. 111
Connecting a computer (TO HOST connector) 112
Connecting an external MIDI sequencer or computer etc. 112
Connecting an IBM PC (compatible). 112
Connecting an Apple Macintosh 113
Messages transmitted and received by the TRITON. 114
MIDI channels 114
Note on / off. 114
Program Change / Bank Select 114
After touch 115
Pitch bender 115
Control change 115
Using RPN to edit 119
Controlling the arpeggiator (NPRN) 120
About system exclusive messages. 120
If notes are "stuck" 121
Playing the TRITON multi-timbrally from an external device 122
Synchronizing the playback of the arpeggiator or sequencer 122
Recording musical data from an external device 122
About GM / GS / XG 123
About standard MIDI files 123

Other functions 125
Tuning to another instrument / Transposing . . . 125
Bypassing the effects 125
Specifying the function of the ASSIGNABLE Switch and ASSIGNABLE Pedal 125
Adjusting the way in which velocity or after touch will affect the volume or tone 126
Creating original scales 126
Changing the scale. 126
Setting the function of [SW1] and [SW2] 127
Setting the B-mode functions of REALTIME CONTROLS [1]–[4] 127
Adjusting the contrast (brightness) of the LCD screen 127
Sounding a beep when the LCD screen is pressed. 127
Using the TRITON as a data filer 127
Shortcuts 128

Appendices 129

Installing and setting up the Korg MIDI Driver . 129
Installing the Korg MIDI Driver into Windows 95 / 98 and making settings 129
Installing the Korg MIDI Driver into Windows 95 / 98. 129
Korg MIDI Driver settings 130
Setting up the Korg MIDI Driver (Windows) 130
Installing the Korg MIDI Driver into a Macintosh 131
Setting up the Korg MIDI Driver (Macintosh) 131
Wiring diagram for special connection cables 132

Troubleshooting. 133

Specifications and options 135
Specifications 135
Options 136
MIDI implementation chart 137