Problem: Power LED lights but the LEDs on the front panel do not scroll on and off when the unit is initially turned on.

Fix: Replace the 100uF capacitors indicated in the picture below with a 100uF 25Volt capacitor. The capacitor on the left of this picture may be a 47uF capacitor; you still want to replace it with a 100uF capacitor.

