Hot Keys for the MasterLink 9600
Software Version 1.00

Hot Key Combination	Action	Description
Record + Play	Restore Defaults	Try this first to fix minor crashes and software errors. Resets system variables such as input sample rate, word length, current playlist, etc. to their default values.
Utility + Create CD	Initialize File System	Initializes the Audio File System. Use if the Masterlink repeatedly displays "FS Error XX". This will erase ALL audio files on the hard disk.
Utility + HDCD	Jump to OS Loader	Force the Masterlink System Software to look for an O.S. disc and load new software. Try this if the Masterlink does not recognize an O.S. disc in normal operating mode.
HDCD + Track End	Jump to OS loader	Force the Masterlink Boot Software to look for an O.S. disc and load new software. In the case where the software on the hard disk gets corrupted, this will force the Masterlink to load new software using the boot EPROM. This also will automatically initialize the File System after the new software is loaded.
Record + Track Start	Zero entire Hard Disk	This will completely erase the hard disk. Use this only in extreme cases. New software will need to be loaded after performing this function. The File System will automatically be initialized after the new software is loaded.
Utility + Playlist Edit	Production Tests	Automated self-diagnostics mode.
Playlist Edit + Track End	Diagnostics Tests	Manual self-diagnostics mode.
Cursor Left + Create CD	Test Burn	Performs a "test" burn of a CD. Goes through all the steps for burning a Redbook or CD24 disc without actually writing to the disc. Use to diagnose disc burning problems.