RESTORING THE SYSTEM PARAMETERS TO THE FACTORY SETTINGS

NOTE

User settings are saved on the hard disk, but they will be initialized when you execute the following procedure.

1. Turn on the power of the MV-8000, and start it up in the normal way.
2. Press the [SYSTEM] button to enter the System menu, and press the [F5] (SYSTEM INFO) button.
3. When you press the [F3] (INITIALIZE) button, all parameters in the system menu will be initialized to their factory-set condition.

PROCEDURE FOR UPDATING THE SYSTEM SOFTWARE

Upating via CD-ROM

Required items

- UPDATE CD-ROM (#17041402)

Procedure

1. While holding down the MV-8000's [INSTRUMENT] and [DISK/USB] buttons, press the [POWER] switch. CD-ROM update mode will start up.
2. Press the eject button of the CD-RW drive to open the CD tray, and insert the update CD-ROM.
3. Close the tray, and the update file will automatically be loaded from the CD-ROM.
4. The tray will open automatically when loading is completed, but the update process will continue, so be careful not to turn off the power yet.
5. When the update is completed, the version number will be displayed, and all LEDs will blink.
6. Press the [POWER] switch to turn off the power of the MV-8000.

Upating via USB

Required items

- UPDATE CD-ROM (#17041402)
- A computer that is running Windows XP, and which fulfills the MV-8000's operating requirements
- USB Cable

Procedure

1. Copy the program file "MV8000.PRG" from the update CD-ROM to your computer.
2. Use a USB cable to connect your computer to the MV-8000, and turn on the power switch of the MV-8000.
   The MV-8000 will start-up in its normal state.
3. Press the [DISK/USB] button.
4. Press the [F3 (USB)] button.
5. Press the [F5 (Connect)] button.
   A message of "Save Project?" will appear; simply press the [F1 (No)] button.
6. When the MV-8000 hard disk has been detected by your computer, copy "MV8000.PRG" to the root directory of the MV-8000's hard disk.
   If an identically-named file exists, overwrite it.
7. When the copy has been completed, break the connection to the MV-8000 from your computer (use "Remove Hardware," or drag the drive into the trash). Then press the MV-8000's [F5 (Disconnect)] button.
8. Turn off the power of the MV-8000.
9. While holding down the [SEQUENCE] and [DISK/USB] buttons, turn on the power of the MV-8000 once again.
   The MV-8000 will start up in Hard Disk Update mode.
10. The update file on the hard disk will be loaded automatically, and the update will be performed.

NOTE

Never turn off the power while the update is in progress.

11. When the update has been completed, the version number will be displayed, and all LEDs will blink.
12. Turn off the power of the MV-8000.

NOTE

When you fail in update, start the updating from the beginning.