tc electronic

Nova System Factory Presets

Bank	Name	Effects used
F0-1	Stevie's Blues	(Plate Reverb, Overdrive)
F0-2	Subtle Detune	(Detune, Dual Delay)
F0-3	Gary's Lead	(Distortion, Clean Delay, Room)
F1-1	Big Lead	(Distortion, Compressor, Phaser, Detune)
F1-2	Blues Room	(Overdrive, Room)
F1-3	Wet Delay	(Chorus, Detune, Dual Delay, Hall)
F2-1	Straight Up Lead	(Distortion, Compressor, Detune, Hall)
F2-2	Tape Delay Lead	(Overdrive, Tape Delay, Room)
F2-3	Unchanged	(Distortion, Flanger, Room)
F3-1	Squashed Comp	(Compressor)
F3-2	Start Me Up	(Distortion, Plate Reverb)
F3-3	Sustaining Lead	(Overdrive, Compressor, Dynamic Delay)
F4-1	Soft Trem'n' Verb	(Tremolo, Spring Reverb)
F4-2	Allan's Fatigue	(Distortion, Reverb, Shifter)
F4-3	Metal Octave	(Distortion, Octaver)
F5-1	A Musical Road	(Compressor, Chorus, Tape Delay, Hall)
F5-2	Animal	(Distortion, Pitch Shifter)
F5-3	Trash Rhythm	(Distortion, Eq, Gate, Detune)
F6-1	Fazer Lead	(Distortion, Phaser, Hall)
F6-2	VibraVerb	(Vibrato, Spring Reverb)
F6-3	On the Edge	(Compressor, Chorus, Detune, Delay, Hall)
F7-1	Jet Flanger	(Distortion, Flanger, Analog Delay)
F7-2	3 Guitars in C	(Overdrive, Intelligent Pitch Shifter, Room)
F7-3	Faux Vibe	(Overdrive, Chorus)
F8-1	Slap & Comp	(Compressor, Analog Delay, Plate Reverb)
F8-2	OctaFuzz	(Distortion, Octaver)
F8-3	Tap Tremolo	(Tremolo, Spring Reverb)
F9-1	Ambient Crunch	(Distortion, Compressor)
F9-2	Woman Tone	(Overdrive, Plate Reverb)
F9-3	All Bypassed	(No FX)



User banks 00-19 have 3 memory locations each which can be used to store your own presets.

Furthermore you can store up to 4 instant effects variation settings for each FX block, so you can easily exchange single effects and try out different combinations on the fly.

This becomes very handy when creating your own presets. Once you have found a particular effects setting you like, store it as a variation (press and hold one of the Variation buttons).

Next time you wish for this setting to be added to any other preset, just press the selected FX button and the variation button will load and replace the current FX setting of your selected FX block.

For more information please refer to the Nova System User Manual.