





HK AUDIO		Date 15.10.99
Title: Powerworks Bass Power Supply		
Page 1/4	Checked BY F.S.	Date



HK AUDIO		Date 20.08.1999
Title: Powerworks Bass Power Supply		
Page 2/4	Checked BY F.S.	Date




HK AUDIO		Date 31.08.1999
Title: Powerworks Bass Power Amplifier Bass		
Page 3/4	Checked BY F.S.	Date




HK AUDIO		Date 20.08.1999
Title: Powerworks Bass Power Amplifier Bass		
Page 4/4	Checked BY F.S.	Date

Preamp


HK AUDIO AEIP11-1.01
R15
C28
Plug8
C41
C40
C21
Plug9
C6
C10
C11
Plug1
Plug12
R2
D1
C2
BR5
BR1
D5
D7
C24
R29
R19
R14
R12
IC2
D8
D6
R9
R7
BR3
C26
C23
C37
Plug8
C5
R52
IC1
R51
C22
J2
C31
R18
R13
C17
C16
R5
C15
C7
R11
C14
C1
C13
P1
C20
R20
BR6
J3
S1
C9
C3
D3
D4
R53
R4
B2
R3
C12
Plug17
Plug15
F1
J1
Rel1
R1
C4
Plug7
Plug4
Plug2
Plug5
Plug11

Poweramp


HK AUDIO AE250 1.01
CAUTION !
Replace fuses
only with same
type and rating
Speaker -
Plug1
Plug3
Plug5
Plug6
Plug7
Plug8
Plug9
F1
F2
SB4000mA
T4A
IC3
TR2
TR3
C1
C2
C3
C4
C5
C6
C7
C8
C9
C10
C11
C12
C13
C15
C16
C17
C18
C19
C20
C21
C22
C24
C25
C26
C27
C28
C30
C31
C33
C35
C36
C40
D1
D2
D3
D4
D5
D6
D7
D8
D9
D10
D11
D12
D13
D14
D15
D16
R1
R2
R3
R4
R5
R6
R7
R8
R9
R10
R11
R12
R14
R15
R16
R17
R18
R19
R20
R21
R22
R23
R24
R25
R26
R27
R28
R29
R30
R31
R32
R33
R36
R40
R41
R43
R44
R45
R46
R47
R48
R49
R50
R51
R52
R53
R54
R55
R56
R57
R59
R61
R67
R68
R69
R70
R72
R73
R79
R85
R86
R90
R91
R92
R93
R94
R95
R96
T1
T4
T5
T6
T7
T8
T10
T11
T12
T14
T15
T16
T17
T19
T21
T23
BR1
BR2
BR3
BR4
BR5
BR6
BR7
BR8
BR9
BR11
BR12
BR13
TR1
TR4
Speaker +
or bridge +
Speaker +
or bridge -