Specifications

User Memory

- Patterns: 96 (2 banks x 3 groups x 16 patterns)
- Tracks: 8 (2 banks x 4 tracks)
- Kit: 1

Steps

- 16 steps with 16 sub steps

Instruments

- BASS DRUM
- SNARE DRUM
- LOW TOM
- MID TOM
- HI TOM
- RIM SHOT
- HAND CLAP
- CLOSED/OPEN HI HAT
- CRASH CYMBAL
- RIDE CYMBAL

Controllers

- VOLUME knob
- START button
- STOP/CONT button
- LAST STEP button
- SCALE button
- SHUFFLE/FLAM button
- CLEAR button
- INSTRUMENT SELECT button
- SHIFT button
- TOTAL ACCENT knob
- TEMPO dial
- TRACK 1–4 buttons
- PATTERN 1–3 buttons
- COMP button
- TEMPO button
- BACK button
- FWD button
- AVAILABLE MEAS button
- CYCLE/GUIDE button
- MENU button
- ENTER button
- Main keys 1–16 (16 step buttons)
- BASS DRUM: TUNE, LEVEL, ATTACK, DECAY knobs
- SNARE DRUM: TUNE, LEVEL, TONE, SNAPPY knobs
- LOW/MID/HI TOM: TUNE, LEVEL, DECAY knobs
- RIM/CLAP: LEVEL knob
- HI HAT: LEVEL, CH DECAY, OH DECAY knob
- CRASH CYMBAL: LEVEL, CRASH TUNE knob
- RIDE CYMBAL: LEVEL, RIDE TUNE knob

Effects

- Compressor

Indicators
- 7 segments, 4 characters (LED)
- Scale LED

Connectors
- TRIGGER OUT jack: Mono miniature phone type
- PHONES jack: Stereo miniature phone type
- OUTPUT jack: Stereo miniature phone type
- MIX IN jack: Stereo miniature phone type
- MIDI (IN, OUT) connectors
- USB port: Micro-B type (Audio, MIDI)

Power Supply
- Rechargeable Ni-MH battery (AA, HR6) x 4
- Alkaline battery (AA, LR6) x 4
- USB bus power

Current Draw
- 500 mA (USB bus power)

Expected battery life under continuous use
- Rechargeable Ni-MH battery: Approx. 6 hours
- * This can vary depending on the specifications of the batteries, capacity of the batteries, and the conditions of use.

Accessories
- Owner's Manual
- DK-01 Owner's Manual
- Leaflet "USING THE UNIT SAFELY"
- Alkaline battery (AA, LR6) x 4

Size and Weight

Width
- 308 mm
- 12-1/8 inches

Depth
- 130 mm
- 5-1/8 inches

Height
- 51 mm
- 2-1/16 inches

Weight
- 980 g
- 2 lbs 3 oz