

Middlesex, NJ 08846
106 Eagle Ave.
Jersey Technical

Service Center

Warranty service is only available by first contacting D'Andrea Inc. for a Return Authorization Number and then sending the unit, postage pre-paid, with the original sales receipt. This warranty is available in the USA only.

This warranty does not apply to failure of the Product due to misuse, abuse, accident, negligence, mishandling, improper repair, repair attempted by anyone other than an authorized service agent, operation under any conditions other than those recommended or voltage than the voltage indicated on the unit, or wear from ordinary use. Any attempts at repair by unauthorized persons or purchaser will render this warranty void.

Improper installation or operation, incorrect voltage, or alteration of the product, damage of any kind resulting from defects, malfunctions misuse, not be liable for any personal injury, property damage, or any incidental or consequential damage resulting from the use of the Product.

If defective, D'Andrea Inc.'s entire liability, and purchaser's exclusive remedy, is the replacement or repair of the Product as described herein. D'Andrea Inc. shall replace any defective part which, upon inspection by an authorized service center, proves to have failed in the ordinary course of use due to defects in material or workmanship.

LIMITED WARRANTY

Try our entire line of snarling wah pedals and stomp boxes:



WHINE-O™ WAH PLUS



SUPER BAWL™ WHINE-O WAH



FIRE BAWL™ WAH



BAWL BUSTER™ WAH



BLUES BAWLS™



EROGENOUS MOAN™



WONDER™ WAH



MOLD SPORE™



VERY-TONE™ DOG



BLACK DOG™



TWEED E. DOG™



BLUE DOG™

D'Andrea USA

D'Andrea Inc.

115 Eileen Way, Syosset, NY 11791 USA
Ph: 516-496-2200 • Fax: 516-496-2425
email: customerservice@dandreainc.com
web: www.snarlingdogs.com • www.dandreadicks.com
Snarling Dogs® is a registered trademark of D'Andrea Inc.

Snarling Dogs® is a registered trademark of D'Andrea Inc.



Best Regards,

Our pedal designer is Kenny Segall. Kenny hopes you try all of our Snarling Dogs stomp boxes and wahs. Check out our website for info on our lastest pedal designs!

Snarling Dogs strings
Snarling Dogs effects
Snarling Dogs wahs

Check out our website www.snarlingdogs.com to see:


Please read the trouble shooting section before contacting us. In the event that you pedal does not function properly, read this manual carefully to learn how to use all the controls and the features of the pedal. Please read this manual carefully to give you many years of trouble-free operation. Please manufacture to replace the entire unit with another new or reconditioned unit; or (2) to replace any defective part which, upon inspection by an authorized service center, proves to have failed in the ordinary course of use due to defects in material or workmanship.

Snarling Dogs Super Bawl Whine-O™ with TMHBS was designed and thank you for purchasing the TMHBS!



SUPER BAWL WHINE-O-WAH
True Hard Mechanical Bypass Switch

SNARLING INSTRUCTION MANUAL



IMPORTANT!

If you will be powering your Snarling Dogs pedal with a 9 volt adapter, it is important for you to use a SOUND-SENSE regulated adapter or other regulated adapter. Non-regulated adapters will cause the unit to be noisy and may cause harm to the unit. Your dealer can purchase SOUND SENSE Adapters through D'Andrea Inc. If your dealer does not carry these, alkaline batteries offer extended life, and may enhance the sound qualities of the pedal.

GETTING STARTED

1. To install a battery, simply unscrew the battery access plate on the bottom of the unit. Make sure the battery clips are securely attached to the battery.
2. For cable hook-up, plug your guitar cable into the 1/4 inch jack marked INPUT.
3. Plug the cable leading to your amplifier into the 1/4 inch jack marked OUTPUT.
4. To activate the pedal, depress the footswitch. When the pedal is activated, the Snarling Dogs eyes will light up. Depressing the switch again will bypass the pedal's signal.

Wah Controls

1. WAH Selector -

- a) White Room - Rich, bassy, "Creamy" wah tone.
- b) Voo Doo - Midrange, crunchy wah tone.
- c) Shaft - Classic "Waka-Chu-Waka-Chu-Waka" wah sound. Bright, funky tone.

2. WAH Volume - Allows adjustment to output volume of wah pedal.

Super Bawl Controls

3. Hormone Control - You control how aggressive your sound gets. Testosterone is very aggressive while estrogen is tamer.

4. Patent Applied For Twinductor Footswitch -

Switches between normal, one inductor sound (one eye lit) and two inductor sound (two eyes lit).

A. On/Off Switch — TMHBS

The on/off switch located under the second toe from the left (next to the "big" toe) is a TRUE MECHANICAL HARD BYPASS SWITCH (TMHBS).

The importance of the TMHBS is that it allows the PURE guitar signal to be heard when the pedal is in the off position. Unlike electronic switching, or standard mechanical switching, with our TMHBS, you will not experience any of the "tone soak" you experience with other pedals. At the same time, you will still have the convenience of the Snarling Dogs LED eyes alerting you when the pedal is on or off.

The importance of TMHBS becomes especially important when you have a chain of effects. Without TMHBS, each pedal in the chain will soak up a portion of your original signal. The more pedals in your chain, the more your original tone will be diminished.

Trouble Shooting

Symptom	Possible Cause	Remedy
No sound	Dead battery?	Replace battery
No sound	Is there a broken cable?	Check cables and replace if broken
No sound	Is 1/4" cable(s) not pushed all the way in?	Push cable(s) all the way in
No sound	Is instrument cable attached to "in" jack and amp cable attached to "out" jack?	Reconnect cables properly
No sound	Adapter not plugged in	Make sure adapter is properly plugged into working wall outlet and pedal
Distorted or poor sound quality	Weak/dead battery?	Replace battery
LEDS/eyes not lighting up	Weak/dead battery?	Replace battery

Symptom	Possible Cause	Remedy
No sound	Dead battery?	Replace battery
No sound	Is there a broken cable?	Check cables and replace if broken
No sound	Is 1/4" cable(s) not pushed all the way in?	Push cable(s) all the way in
No sound	Is instrument cable attached to "in" jack and amp cable attached to "out" jack?	Reconnect cables properly
No sound	Adapter not plugged in	Make sure adapter is properly plugged into working wall outlet and pedal
Distorted or poor sound quality	Weak/dead battery?	Replace battery
LEDS/eyes not lighting up	Weak/dead battery?	Replace battery