Tronical COMPONENTS

TRONICALTUNE

ASSEMBLY INSTRUCTION

1 SCOPE OF DELIVERY



6 x ROBO-HEADS
1 x CONTACTING PCB
1 x LiPo BATTERY
1 x CHARGER INCL. WALL-PLUG
6 x LOCK NUTS & RING WASHERS
1 x SPANNER
1 x QUICK START GUIDE

2 PREPARATION



AT FIRST REMOVE ALL ORIGINAL HEADSTOCK-PARTS OF YOUR GUITAR.

3 GETTING STARTED »



REMOVE THE HEX-NUTS.
REMOVE THE SLEEVES (TRANSPORT LOCK).

4



PLACE THE CONTACTING PCB ON THE NECK OF THE GUITAR, THE BATTERY COMPARTMENT HAS TO FACE TOWARDS THE TOP OF THE HEADSTOCK.

5



MAKE SURE THAT ALL PCB DRILL HOLES ARE IN ALIGNMENT WITH THE NECK´S TUNER HOLES. PUT THE ROBOHEADS THROUGH THE RESPECTIVE HOLES.

6



MOUNT THE RING WASHERS & HEX-NUTS.

7



USE THE OPEN-END WRENCH WHICH COMES WITH THE SET TO SCREW TIGHT THE HEX NUTS OF THE ROBOHEADS.

8 READY TO TUNE



NOW TRONICAL TUNE IS READY TO STRING UP YOUR GUITAR.
FOLLOW THE INSTRUCTIONS OF THE MANUAL.

9 DOWNLOAD MAUAL

Download Tronical Tune Manual for detailed instructions and important safty warnings.

www.tronical.com/downloads

Tronical-Components GmbH • Heselstücken 18
22453 Hamburg Germany

© Copyright 2012 Tronical-Components GmbH.
All rights reserved.

Tronical COMPONENTS

TRONICALTUNE

ASSEMBLY INSTRUCTION

1 SCOPE OF DELIVERY



6 x ROBO-HEADS
1 x CONTACTING PCB
1 x LiPo BATTERY
1 x CHARGER INCL. WALL-PLUG
6 x LOCK NUTS & RING WASHERS
1 x SPANNER
1 x QUICK START GUIDE

2 PREPARATION



AT FIRST REMOVE ALL ORIGINAL HEADSTOCK-PARTS OF YOUR GUITAR.

3 GETTING STARTED »



REMOVE THE HEX-NUTS.
REMOVE THE SLEEVES (TRANSPORT LOCK).

4



PLACE THE CONTACTING PCB ON THE NECK OF THE GUITAR, THE BATTERY COMPARTMENT HAS TO FACE TOWARDS THE TOP OF THE HEADSTOCK.

5





MAKE SURE THAT ALL PCB DRILL HOLES ARE IN ALIGNMENT WITH THE NECK´S TUNER HOLES. PUT THE ROBOHEADS THROUGH THE RESPECTIVE HOLES.

6



MOUNT THE RING WASHERS & HEX-NUTS.

7



USE THE OPEN-END WRENCH WHICH COMES WITH THE SET TO SCREW TIGHT THE HEX NUTS OF THE ROBOHEADS.

8 READY TO TUNE



NOW TRONICAL TUNE IS READY TO STRING UP YOUR GUITAR.
FOLLOW THE INSTRUCTIONS OF THE MANUAL.

9 DOWNLOAD MAUAL

Download Tronical Tune Manual for detailed instructions and important safty warnings.

www.tronical.com/downloads

Tronical-Components GmbH • Heselstücken 18
22453 Hamburg Germany

© Copyright 2012 Tronical-Components GmbH.
All rights reserved.