SYSTEM SOFTWARE UPDATING INSTRUCTIONS

Roland FC-300

Checking the Version Number

1. Turn on the power when holding down the PARAMETER [<] and [>] simultaneously.
The version number is displayed on the right of bottom in the screen.
If the version is 1.02 or later, this update is not needed.

System Update Instructions

This procedure updates the FC-300's system using a computer or other such device to play back the SMF data for update, which is then received by the FC-300.

Required Items

- FC-300
- Computer (Windows PC/Mac OS X)
- MIDI Cables with USB MIDI interface
- Software Sequencer: UpdSMF.exe (Windows) or UpdSMF.app (Mac OS X)

System Update Procedure

1. Connect the computer's MIDI OUT to the FC-300's MIDI IN (use an USB MIDI interface.
2. Simultaneously hold down [EXIT] and [WRITE] and turn on the power.
"Upd" appears in the BANK/NUMBER display.
3. Start up the application for transmitting MIDI data on the computer (e.g., UpdSMF), and transmit the MIDI data for update.
4. Double click the "UpdSMF" icon and select the "MIDI Out Device" in the window. Assign the uncompressed "FC300_102" folder to the SMF Path.
5. Click [Scan SMF] button in the window (for Windows OS only), then click [Send] button in the window to start sending the Data.
6. When the update is finished, "End" appears in the display.
*Never turn off the power before the display indicates "End."
7. Turn the power off and disconnect the MIDI cables. Hold down [EXIT] and [WRITE] simultaneously and turn the power on again. Confirm the new version number 1.02 is displayed then turn off the power.