v1.0

	Roland E28 MIDI MAP			
	MIDI Channel		Timbre	Remarque
1	1		Piano (11) Rv	x
2	2		Piano (11) Rv + Ch	x
3	3		Piano (11) Rv	x
4	4	Upper 1	preset UP1	Tones A/B
5	5		Piano (11) Rv	x
6	6		Piano (11) Rv	x
7	7		Piano (11) Rv	x
8	8	BASS	bass (**)	non assignable
9	9		Piano (11) Rv	x
10	10	DRUM	STD kit	Standard kit
11	11	LWR	preset LWR	Tones A/B
12	12		Piano (11) Rv	x
13	13	Upper 2	preset UP2	Tones A/B
14	*14*	NU	NU	x
15	*15*	NU	NU	x
16	10	DRUM	DRM	Kit 1-8