SYSTEM-1 Update

Update procedure

1. **Hold down the [KEY HOLD] button and switch on the power.**
2. **Connect your computer to the SYSTEM-1's USB port via USB cable.**
3. **Open the "SYSTEM-1" drive folder on your computer.**
4. **Copy the SYSTEM1_UPD.BIN update file into the "SYSTEM-1" drive.**
5. **After copying is completed, remove the USB drive from your computer.**

   Windows 8/7

   Right-click on the "SYSTEM-1" icon in "My Computer" and execute "Eject."

   Mac OS

   Drag the "SYSTEM-1" icon to the Trash icon in the Dock.
6. **Disconnect the USB cable.**
7. **Press the [DOWN] button to start updating the file.**
8. **Turn the SYSTEM-1 power off after the update process has completed.**

Contents of Ver.1.10

Take a snapshot of all controllers.

Pressing and holding the [MANUAL] button executes batch output as Control Change messages of setting information for the volume knob, sliders, and buttons.

Data backup/restore

● Backup

1. **Hold down [ARPEGGIO] and switch on the power.**
2. **Connect your computer to the SYSTEM-1's USB port via USB cable.**
3. **Open the "SYSTEM-1" drive folder on your computer.**
4. **Copy the SYSTEM-1 Memory files in "BACKUP" folder into your computer.**

SYSTEM-1	SYSTEM1_PATCH1.PRM - SYSTEM1_PATCH8.PRM
PLUGOUT	PLUGOUT_PATCH1.PRM - PLUGOUT_PATCH8.PRM

5. **After copying is completed, disconnect the USB cable.**

   Windows 8/7

   Right-click on the "SYSTEM-1" icon in "My Computer" and execute "Eject".

   Mac OS

   Drag the "SYSTEM-1" icon to the Trash icon in the Dock.
6. **Turn the SYSTEM-1 power off.**

● Restore

1. **Hold down [ARPEGGIO] and switch on the power.**
2. **Connect your computer to the SYSTEM-1's USB port via USB cable.**
3. **Open the "SYSTEM-1" drive folder on your computer.**
4. **Copy the SYSTEM-1 memory files into the "RESTORE" folder.**
5. **After copying is completed, disconnect the USB cable.**

   Windows 8/7

   Right-click on the "SYSTEM-1" icon in "My Computer" and execute "Eject".

   Mac OS

   Drag the "SYSTEM-1" icon to the Trash icon in the Dock.
6. **Turn the SYSTEM-1 power off.**

Improved the LPF CUTOFF resolution

The increment size of "LPF CUTOFF" when "MODE = SYSTEM-1" was modified.

The behavior of the volume knob or sliders were improved

The plug-out function was improved

Change pitch bend range

Turn the [TYPE] knob while holding down the [LEGATO] button.
The range is from 1 to 24.

e.g.)

The range is 12 when "10" and "2" are on.
The range is 24 when "10" blinks and "4" is on.

MIDI Local On/Off and MIDI Controller mode

Turn the [TYPE] knob while holding down the [SYSTEM-1] button and the [PLUG-OUT] button.

LOCAL ON ("2" blinks)	It produces sound through any operation including external MIDI message.
LOCAL OFF ("1" blinks)	It produces sound only through external MIDI message.
MIDI CONTROLLER("3" blinks)	It doesn't produce sound through any operation, only outputs MIDI message.

Copyright © 2014 ROLAND CORPORATION