	ARTURIA BSP (défaut)		Default YAMAHA RX11			*modifiés YAMAHA RX11*			Modifiés YAMAHA RX15		
	Pad	Value	Pad	Value	MIDI note	Pad	Value	MIDI note	Pad	Value	MIDI note
1	C2	36	SD1	52	E3	SD1	38	D2	KICK BD	36	C2
2	D	37	SD2	49	C#3	SD2	40	E2	RIMSHOT	37	C#2
3	E	38	TOM 1 (H)	53	F3	TOM 1 (H)	48	C3	SD	38	D2
4	F	39	TOM 2	50	D3	TOM 2	47	B2	CLAPS	39	D#2
5	G	40	TOM 3	48	C3	TOM 3	45	A2	TOM 1 H	48	C3
6	A	41	TOM 4 (L)	47	B2	TOM 4 (L)	43	G2	TOM 2 M	47	B2
7	B	42	BD1	45	A2	BD1	36	C2	TOM 3 L	45	A2
8	C3	43	BD2	44	G#2	BD2	41	F2	HH OPEN	46	A#2
9	C#	44	HH OPEN	59	B3	HH OPEN	46	A#2	HH CLOSED	42	F#2
10	D#	45	HH CLOSED	57	A3	HH CLOSED	42	F#2	RIDE	51	D#3
11	minor	46	RIDE	62	D4	RIDE	51	D#3	CRASH	49	C#3
12	F#	47	CRASH	60	C4	CRASH	49	C#3	SHAKER	44	G#2
13	G#	48	COWBELL	55	G3	COWBELL	56	G#3	COWBELL	56	G#3
14	A#	49	RIMSHOT	51	D#3	RIMSHOT	37	C#2			
15	OCT-	50	SHAKER	56	G#3	SHAKER	44	G#2			
16	OCT+	51	CLAPS	54	F#3	CLAPS	39	D#2			

Procédure SysEx (RX11) :

MIDI IN > CH INFO AVAILABLE / OMNI
MIDI OUT > CH IN AVAILABLE / SYS EXCL AVAIL
<u>Changement note MIDI de Pad</u> (RX11 & RX15):
MIDI IN > OMNI ON, pui appuyer sur le Pad, puis changer avec Data Entry (not. FR page

Y. RX11	*Timbres*	Y. RX15
SD1/SD2	***SD HEAVY***	x
SD1/SD2	***SD MEDIUM***	SD
SD1/SD2	***SD LIGHT***	x
SD1/SD2	***SD HI TUNE 1***	x
SD1/SD2	***SD HI TUNE 2***	SD
SD1/SD2	***SD HI TUNE 3***	x
SD1/SD2	***SD HI TUNE 4***	x
SD1/SD2	***SD HI TUNE 5***	x
TOM 1	***TOM 1***	TOM 1
TOM 2	***TOM 2***	TOM 2
TOM 3	***TOM 3***	TOM 3
TOM 4	***TOM 4***	x
BD1/BD2	***BD HEAVY***	x
BD1/BD2	***BD MD 1***	BD
BD1/BD2	***BD MD 2***	x
HH OPEN	***HH OPEN 1***	HH OPEN
HH OPEN	***HH OPEN 2***	x
HH CLOSED	***HH CLOSED 1***	HH CLOSED
HH CLOSED	***HH CLOSED 2***	x
HH CLOSED	***HH PEDAL***	HH CLOSED
RIDE	***RIDE***	RIDE
CRASH	***CRASH***	CRASH
COWBELL	***COWBELL 1***	SHAKER/COWBELL
COWBELL	***COWBELL 2***	x
RIMSHOT	***RIMSHOT 1***	RIMSHOT
RIMSHOT	***RIMSHOT 2***	x
SHAKER	***SHAKER***	SHAKER/COWBELL
CLAPS	***CLAPS 1***	CLAPS
CLAPS	***CLAPS 2***	x